



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

# Huba Control

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## BRAND'S PRODUCTS

Product	Description
<a href="#">100064</a>	Connection set
<a href="#">101999</a>	Mounting bracket including M4 screws
<a href="#">103510</a>	socket with seal
<a href="#">105836</a>	food cover
<a href="#">506.933A23101W</a>	Relative pressure transmitter for refrigeration type 506
<a href="#">528.930003241N</a>	relative pressure transmitter
<a href="#">528.9310031111</a>	Pressure transmitter
<a href="#">528.931003141N</a>	PRESSURE TRANSMITTER
<a href="#">528.9320033411</a>	(Relativdruck-Transmitter Typ 528)
<a href="#">604.9010030</a>	Pressure switch
<a href="#">604.9000020</a>	Pressure Switch
<a href="#">604.9200020</a>	Differential pressure switch
<a href="#">620.9100</a>	Pressure switch Type 620
<a href="#">620.9136</a>	Druckschalter
<a href="#">625.6532</a>	vacuum switch
<a href="#">625.6540</a>	Vacuum switch
<a href="#">625.9040</a>	PRESSURE SWITCH
<a href="#">625.9040W 8/2mbar</a>	pressure switch
<a href="#">625.9132</a>	Pressure switch
<a href="#">630.940027</a>	differential pressure switch
<a href="#">652.91410000101</a>	Differential pressure transmitter
<a href="#">691.92200712</a>	Relativdruck-Transmitter Typ 691
<a href="#">691.93300716W 0...35 bar</a>	Drucktransmitter
<a href="#">692.900007141</a>	Pressure transmitter
<a href="#">692.914007141</a>	Differential Pressure Transmitter
<a href="#">692.918001001</a>	Differential Pressure sensor/transmitter
<a href="#">692.918107141</a>	Pressure transmitter
<a href="#">STECKDOSE DIN: 103510</a>	socket
<a href="#">604.9002000</a>	Differential pressure switch
<a href="#">604.9202000</a>	
<a href="#">699.915015010</a>	pressure sensor
<a href="#">691.51500711</a>	Pressure transmitter
<a href="#">691.9220071L</a>	Relative pressure transmitter
<a href="#">528.9311031811</a>	Pressure transmitter
<a href="#">Abdeckhaube 105836</a>	
<a href="#">Schraubklemmenset: 103491</a>	

<b>Product</b>	<b>Description</b>
<a href="#">520.943S033421</a>	Relativdruck-Transmitter Typ 520
<a href="#">528.9150031911</a>	Drucktransmitter
<a href="#">528.815101L411</a>	Pressure sensor
<a href="#">630.930127</a>	differential pressure switch
<a href="#">604.9000001</a>	Pressure switch
<a href="#">528.9170021711W</a>	Drucktransmitter
<a href="#">604.9210032</a>	Differential pressure switch
<a href="#">625.6510</a>	Pressure switch
<a href="#">680.804323104</a>	Drucktransmitter
<a href="#">699.914215042</a>	differential pressure transmitter
<a href="#">528.9310033411</a>	Drucktransmitter
<a href="#">691.90600713</a>	Drucktransmitter
<a href="#">528.9170033711W -1...5 bar</a>	Drucktransmitter
<a href="#">528.9300033711</a>	Drucktransmitter
<a href="#">528.9110033411</a>	Pressure transmitter
<a href="#">520.955S031921</a>	Pressure Transmitters
<a href="#">699.911015010</a>	differential pressure transmitter
<a href="#">699.916021112</a>	Differenzdrucktransmitter
<a href="#">520.930S023721</a>	Pressure Transmitter
<a href="#">528.9300081721</a>	Drucktransmitter
<a href="#">528.9170021711W -1</a>	Drucktransmitter
<a href="#">604.9000000</a>	Pressure Switch
<a href="#">501.930023151</a>	Relativ-Drucktransmitter
<a href="#">528.9110033411W</a>	Pressure transmitter
<a href="#">691.9240071L</a>	Pressure Transmitter
<a href="#">699.916021010</a>	Differenzdrucktransmitter
<a href="#">699.915015012</a>	Differenzdrucktransmitter
<a href="#">528.9170031411</a>	pressure transmitter
<a href="#">528.9140031411W</a>	Drucktransmitter
<a href="#">210911441K</a>	
<a href="#">699.911013012</a>	differential pressure transmitter
<a href="#">691.91000713</a>	
<a href="#">528.9330031311W</a>	pressure transmitter
<a href="#">604.9110030</a>	Mechanical pressure switch
<a href="#">604.9400020</a>	differential pressure switch
<a href="#">511.811603741 OEM</a>	TRANSMITTER PRESSURE 511
<a href="#">528.932103L411</a>	Drucktransmitter
<a href="#">506.932A22101W</a>	relative pressure transmitter for refrigeration
<a href="#">604.9000010</a>	Differential pressure switch
<a href="#">625.9032W 2/1 mbar</a>	Druckschalter
<a href="#">604.9400000</a>	Pressure Switch
<a href="#">4770207M</a>	High pressure sensor
<a href="#">699.916015010</a>	differential pressure transmitter
<a href="#">520.954S071421</a>	pressure transmitter
<a href="#">691.93010102</a>	

Product	Description
<a href="#">528.930101LJ12</a>	Pressure-transmitter relative pressure
<a href="#">528.930102LJ11</a>	Relative and absolute pressure transmitter type 528
<a href="#">528.9330031811</a>	Pressure transmitter
<a href="#">Typ 525 (0 ... 0.05 -0.6 bar)</a>	
<a href="#">604.9100000</a>	Pressure switch
<a href="#">610.9.5520U</a>	pressure switch
<a href="#">511.943002542</a>	Pressure sensor
<a href="#">604.9210000</a>	Differenzdruck-Schalter Typ 604
<a href="#">520.943S02M42N</a>	
<a href="#">520.933S03000NW</a>	pressure transmitter
<a href="#">699.917215012</a>	Pressure sensor /Differential pressure transmitter
<a href="#">699.917215010</a>	Differential Pressure Transmitter
<a href="#">699.914011012</a>	
<a href="#">520.933S03M00NW</a>	Precision Transducer
<a href="#">699.931226113</a>	transmitter
<a href="#">520.942S03142</a>	
<a href="#">699.911011010</a>	Differential pressure transmitter
<a href="#">7176778</a>	Pressure transmitter
<a href="#">699.931225012</a>	Differential pressure transmitter
<a href="#">699.914225012</a>	Differential pressure transmitter
<a href="#">520.943S033401W</a>	
<a href="#">528.9170031511</a>	
<a href="#">402.9400021</a>	Differential pressure transmitter
<a href="#">699.C26021140</a>	
<a href="#">520.931S03000N</a>	
<a href="#">520.932S03000NW</a>	Pressure transmitter
<a href="#">699.917014040</a>	pressure transmitter
<a href="#">528.9310023811</a>	Sensor
<a href="#">699.912225113</a>	Sensor
<a href="#">604.9110020</a>	Relative and differential pressure switch
<a href="#">520.933S02L00NW</a>	
<a href="#">699.916014010</a>	transmitter
<a href="#">528.83100632311W</a>	pressure transmitter
<a href="#">604.99118 oem</a>	
<a href="#">525.9240031811</a>	
<a href="#">Typ 625.9964</a>	
<a href="#">520.954S031401</a>	Drucktransmitter
<a href="#">620.9112</a>	Pressure switch
<a href="#">604.9010002</a>	Relative and differential pressure switch
<a href="#">699.B32015010</a>	Differential pressure transmitter
<a href="#">528.9310031811</a>	relative and absolute pressure transmitters
<a href="#">528.9300033411</a>	Pressure Transmitter
<a href="#">630.930227R</a>	pressure switch
<a href="#">604.9100022</a>	Pressure Switch
<a href="#">210.920441N</a>	Sensor

Product	Description
<a href="#">692.919007101</a>	Pressure Transmitter
<a href="#">604.9510022</a>	
<a href="#">620.9216R</a>	Air pressure switch
<a href="#">699.912211012</a>	
<a href="#">114564</a>	
<a href="#">699.913215040</a>	
<a href="#">604.9400002</a>	pressure switch
<a href="#">604.9213020</a>	pressure switch
<a href="#">501.910002141 OEM</a>	
<a href="#">525.9280021411</a>	Relative pressure transmitter
<a href="#">625.9740</a>	Pressure switch
<a href="#">625.9044</a>	Druckschalter
<a href="#">604.9100002</a>	Pressure switch
<a href="#">604.9010020</a>	Differential air pressure switch
<a href="#">113780</a>	Anschlusset DN20 mit Adapter Rp 3/4"
<a href="#">112122</a>	Clip für DN20
<a href="#">112723</a>	O-Ring 21.89x02.62 EPDM
<a href="#">112661</a>	DN20 ADAPTER FÜR 3/4" ROHR
<a href="#">699.917015012</a>	Pressure transmitter
<a href="#">692.932107144W</a>	Differential pressure transmitter
<a href="#">699.916013040</a>	Differenzdruck-Transmitter Typ 699
<a href="#">610.7120</a>	
<a href="#">610.5020</a>	
<a href="#">402.9300021</a>	Differential pressure transmitter
<a href="#">604.S200020</a>	pressure switch
<a href="#">680.700321103N</a>	Transmitter
<a href="#">680.700320103N</a>	Transmitter
<a href="#">528.9300021711</a>	
<a href="#">699.915225110</a>	Differential pressure transmitter
<a href="#">699.915215015</a>	
<a href="#">604.9010022</a>	Switch
<a href="#">528.9300023721</a>	Relative and absolute pressure transmitter Type 528
<a href="#">604.S4200300 + 100098</a>	Set (Differential Pressure Switch + Mounting bracket)
<a href="#">680.802320105N</a>	Pressure transmitter 680
<a href="#">525.9240031J11</a>	Pressure sensor
<a href="#">528.9150031411</a>	Pressure sensor
<a href="#">699.917026040</a>	
<a href="#">528.9H01030411</a>	Pressure transmitter
<a href="#">525.9250031911</a>	
<a href="#">625.6440</a>	
<a href="#">625.6130</a>	pressure switch
<a href="#">604.9212020</a>	
<a href="#">604.S220030</a>	
<a href="#">210.910241K</a>	
<a href="#">525.9261032911</a>	pressure transmitter

Product	Description
<a href="#">604.S500002</a>	Differential pressure switch
<a href="#">699.912225110W</a>	Differential pressure transmitter
<a href="#">210.810451N</a>	flow sensor
<a href="#">680.802322103N</a>	Relative and absolute pressure transmitter
<a href="#">528.9171081911</a>	Pressure transmitter
<a href="#">210.920341K</a>	Flow rate without temperature
<a href="#">210.808741K</a>	
<a href="#">210.815741K</a>	
<a href="#">625.9340</a>	pressure switch
<a href="#">699.916224010</a>	
<a href="#">520.931S03100N</a>	relative pressure transmitter
<a href="#">520.932S03100N</a>	relative pressure transmitter
<a href="#">528.9301081911</a>	Pressure transmitter
<a href="#">692.900107004</a>	DIFFRENTIONAL PRESSURE TRANSMITTER
<a href="#">520.933S03000N</a>	Pressure Transmitter
<a href="#">528.9301031311</a>	Pressure transmitter
<a href="#">604.9210020</a>	Differential Pressure Switch
<a href="#">528.9311081911W</a>	Pressure transmitters
<a href="#">692.900007121</a>	Differential pressure transmitter
<a href="#">699.B17215013</a>	Differential pressure transmitter
<a href="#">699.C13515013</a>	Differential pressure transmitter
<a href="#">604.9500000</a>	pressure switch
<a href="#">604.9200021</a>	PRESSURE SWITCH
<a href="#">7176781</a>	
<a href="#">699.912014010</a>	differential pressure sensor
<a href="#">528.9330031911W</a>	Pressure Transmitter
<a href="#">625.9642</a>	pressure switch
<a href="#">604.9400030</a>	PRESSURE SWITCH 604
<a href="#">520.930S03000N</a>	Relative pressure transmitter
<a href="#">236.615351K</a>	Flow Sensor
<a href="#">528.830103142</a>	
<a href="#">520.931S03100NW0...6bar/4...20mA</a>	
<a href="#">506.931A01101 - OEM/customized</a>	pressure switch
<a href="#">520.931S01100N</a>	Pressure sensor
<a href="#">604.9110080</a>	PRESSURE SWITCH
<a href="#">604.9401002</a>	Pressure switch
<a href="#">528.9010023411W</a>	pressure transmitter
<a href="#">692.902007141</a>	Differential pressure transmitter
<a href="#">692.9121071A1W</a>	Differential pressure transmitter
<a href="#">692.919101041</a>	Pressure Switch
<a href="#">625.9634</a>	pressure switch
<a href="#">528.9320071411</a>	Relative and absolute pressure transmitter
<a href="#">692.931107101</a>	Differential pressure transducer
<a href="#">620.9110W</a>	Pressure switch
<a href="#">520.954S043401</a>	

Product	Description
<a href="#">652.94410000001</a>	
<a href="#">604.9410030</a>	pressure sensor 500-2000 pa.
<a href="#">210-9-20-35-1-G</a>	FLOW SENSOR
<a href="#">210-9-06-3-4-1-G</a>	FLOW SENSOR
<a href="#">401.95000 / 895461</a>	Pressure sensor
<a href="#">699.914225110</a>	DIFFERENTIAL PRESSURE TRANSMITTER
<a href="#">528.9170023411</a>	Pressure sensor
<a href="#">692.9000070B1</a>	
<a href="#">604.9210030</a>	Relative and differential pressure switch
<a href="#">692.916100001</a>	Relative and differential pressure transmitter
<a href="#">699.917025110</a>	
<a href="#">402.9110031</a>	Differential Pressure Transmitters
<a href="#">210.508551K</a>	Flow sensor
<a href="#">699.913015030</a>	
<a href="#">520.9C2S02L00NW175...300psi/0...10V</a>	Relative Pressure Transmitter
<a href="#">67STCK01</a>	Pressure sensor connector
<a href="#">630.940124</a>	pressure switch
<a href="#">699.917015010</a>	Differential Pressure Transmitters
<a href="#">2085909</a>	Pressure transmitter
<a href="#">528.9310032311</a>	
<a href="#">604.9000002</a>	Mechanical Pressure Switch
<a href="#">528.9150022411W</a>	Type 528 relative and absolute pressure transmitters
<a href="#">604.92010C1</a>	
<a href="#">692.9071071A1</a>	RELATIVE AND DIFFERENTIAL PRESSURE TRANSMITTERS
<a href="#">692.912107B1</a>	Differential Pressure Transmitters
<a href="#">525-922-00-3-1-j11</a>	Relative Pressure Transmitter Type 525
<a href="#">699.913015012</a>	pressure switch
<a href="#">604.9200002</a>	Standard climate set
<a href="#">625.9140</a>	pressure switch
<a href="#">699.912221011</a>	Differential Pressure Transmitters
<a href="#">692.917107161</a>	differential pressure sensor
<a href="#">604.S 02 00 30</a>	
<a href="#">t110u+++ 605.99898</a>	
<a href="#">v-5610r-041</a>	
<a href="#">699.917226045</a>	differential pressure transmitter
<a href="#">699.916211010</a>	
<a href="#">520.930S081901</a>	relative pressure transmitter
<a href="#">698.0110000001</a>	
<a href="#">604.9210010</a>	Relative and differential pressure switch
<a href="#">540.943S052401</a>	
<a href="#">699.914221010</a>	Differential pressure transmitter
<a href="#">520.933S03N201W0</a>	
<a href="#">550.954S03P321</a>	
<a href="#">520.933S031110N</a>	
<a href="#">520.931S031110N</a>	



Product	Description
<a href="#">528.9D00012321W</a>	
<a href="#">520.954S031421</a>	Relative pressure transmitter
<a href="#">699.916224113</a>	pressure transmitter
<a href="#">520.933S031401</a>	Pressure transmitter
<a href="#">528.9302021411</a>	RELATIVE PRESSURE TRANSMITTER
<a href="#">9651053</a>	PRESSURE SENSOR
<a href="#">604.9500002</a>	Standard air conditioning set type 604
<a href="#">699.B14215014</a>	
<a href="#">520.940S03500NW</a>	PRESSURE TRANSDUCERS
<a href="#">699.931225112</a>	
<a href="#">91.110.1381/01</a>	Sensor PIEZR GAUG PRES
<a href="#">528.9300081421</a>	Pressure transmitter
<a href="#">236.932441K</a>	Flow sensor
<a href="#">506.932A23101W</a>	pressure transmitter
<a href="#">135015187</a>	PRESSURE SENSOR
<a href="#">210.906441K</a>	
<a href="#">692.9000071B1</a>	differential pressure transmitter
<a href="#">699.917011040</a>	pressure transmitter
<a href="#">402.9510021</a>	differential pressure transmitter
<a href="#">625.9314W</a>	
<a href="#">506.930A23101W</a>	pressure transmitter
<a href="#">528.9320473211W</a>	Pressure Transmitter
<a href="#">520.933S07K201W</a>	Low Pressure Transducer
<a href="#">520.940S07K201W</a>	Medium Pressure Transducer
<a href="#">520.942S07K201W</a>	High Pressure Transducer
<a href="#">520.933S03K201W</a>	Low pressure transducer
<a href="#">520.940S03K201W</a>	Ration
<a href="#">520.942S03K201W</a>	High pressure transducer
<a href="#">528.9141031811W</a>	Relative and absolute pressure transmitter
<a href="#">604.9202021</a>	RELATIVE AND DIFFERENTIAL PRESSURE SWITCH TYPE 604
<a href="#">525.9260031J11</a>	
<a href="#">528.9320031911</a>	
<a href="#">525.9220031811</a>	pressure transmitter
<a href="#">699.912025010</a>	differential pressure transmitter
<a href="#">525.9280031811</a>	Relative pressure transmitter
<a href="#">699.912025110</a>	Pressure transducer
<a href="#">528.812003MC11W</a>	Level sensor
<a href="#">210.908241G</a>	
<a href="#">528.932003142</a>	
<a href="#">114604</a>	connection cable
<a href="#">699.B17015013</a>	pressure transmitter
<a href="#">210.92544K9</a>	
<a href="#">699.912221315</a>	pressure transmitter
<a href="#">604.9110000</a>	Pressure Sensor
<a href="#">520.954S037421</a>	Pressure transmitter type 520



Product	Description
<a href="#">520.955S03P421</a>	
<a href="#">699.912025145</a>	differential pressure transmitter
<a href="#">699.934225144</a>	
<a href="#">620.9202</a>	Pressure switch
<a href="#">699.913011010</a>	Pressure Transducer
<a href="#">604.9200180</a>	difference pressure switch
<a href="#">604.9022170</a>	pressure switch
<a href="#">236.632351K</a>	sensor
<a href="#">620.9530</a>	wicket
<a href="#">692.918007101</a>	Differential pressure transmitter
<a href="#">604.9200012</a>	
<a href="#">117312</a>	socket cable quick fitting
<a href="#">520.933S31110N</a>	
<a href="#">520.931S31110N</a>	
<a href="#">699.914025140</a>	transducer
<a href="#">699.915025140</a>	transducer
<a href="#">604.9210021</a>	
<a href="#">520.940S133301</a>	Pressure Transmitter
<a href="#">520.930S433401</a>	Pressure sensor
<a href="#">680.708333101N</a>	pressure transmitter
<a href="#">210.910441G</a>	flow sensor
<a href="#">402.9100011</a>	Relative and differential pressure transmitter
<a href="#">692.9190071A1</a>	
<a href="#">692.9180071A1</a>	
<a href="#">692.9160071A1</a>	
<a href="#">625.6132</a>	vacuum switch
<a href="#">400.95100 OEM</a>	
<a href="#">210.920241K</a>	Liquid flow sensor
<a href="#">402.9300031</a>	
<a href="#">625.9540</a>	pressure switch
<a href="#">699.915215010</a>	
<a href="#">625.9730</a>	Pressure switch
<a href="#">652.90010000000</a>	pressure transmitter
<a href="#">528.9321031811</a>	Relative and absolute pressure transmitter
<a href="#">604.9211022</a>	Mechanical Pressure Switch
<a href="#">503.93100001 OEM</a>	transducer
<a href="#">210.620351N</a>	flow sensor
<a href="#">692.940007121</a>	Pressure Transmitter
<a href="#">625.9032</a>	pressure switch
<a href="#">236.925341G</a>	flow sensor
<a href="#">520.954S03L301</a>	PRESSURE TRANSMITTER
<a href="#">699.911213012</a>	Differential pressure transmitter
<a href="#">692.9070071B4</a>	Differential pressure transmitter
<a href="#">625.6140</a>	
<a href="#">520.930S02M701</a>	Relative pressure transmitter

Product	Description
<a href="#">604.S500000</a>	Relative and differential pressure switch
<a href="#">95509231</a>	transducer
<a href="#">652.90410001002</a>	differential pressure sensor
<a href="#">604.9200000</a>	Relative and differential pressure switch
<a href="#">520.954S081801</a>	
<a href="#">520.955S031801</a>	
<a href="#">620.9116W</a>	Relative pressure switch
<a href="#">630.960127</a>	pressure switch
<a href="#">210.920441K</a>	Flow sensor
<a href="#">604.9001000</a>	pressure switch
<a href="#">625.9030</a>	pressure switch
<a href="#">528.9170433511</a>	pressure transmitter
<a href="#">620.9500W</a>	Relative pressure switch
<a href="#">699.914013010</a>	Relative and differential pressure transmitter
<a href="#">528.9310031411</a>	
<a href="#">699.914024141</a>	differential pre pressure transmitter
<a href="#">528-9011033411W</a>	pressure transmitter
<a href="#">692.915207101</a>	Relative and differential pressure transmitter
<a href="#">104551</a>	test report
<a href="#">692.9120071C1</a>	pressure transmitter
<a href="#">VES0023</a>	PRESSURE TRANSDUCER
<a href="#">528.9170031411W</a>	pressure transmitter
<a href="#">520.930S03N221W</a>	gauge pressure transmitter
<a href="#">692.9300071A1</a>	Relative and differential pressure transmitter
<a href="#">699.912225114</a>	differential pressure transmitter
<a href="#">699.914021112</a>	
<a href="#">699.914014041</a>	differential pre pressure transmitter
<a href="#">630.930123W</a>	
<a href="#">520.930S031101</a>	pressure sensor
<a href="#">699.914211012</a>	Differential pressure transmitter
<a href="#">Typ 505.91530 / 7843803</a>	pressure sensor
<a href="#">699.913225012</a>	differential pressure transmitter
<a href="#">520.930S03P00NW</a>	sensor
<a href="#">230.525551A</a>	flow sensor
<a href="#">520.931S033401</a>	relative pressure transmitter
<a href="#">520.930031K01W</a>	pressure transmitter
<a href="#">699.914215010</a>	differential pressure transmitter
<a href="#">699.912215010</a>	differential pressure transmitter
<a href="#">528.9300031411</a>	Relative and absolute pressure transmitter
<a href="#">679.912224160W</a>	Volume flow transmitter
<a href="#">210.611351N</a>	flow sensor
<a href="#">620.6312</a>	Pressure switch Type 620
<a href="#">692.900007101</a>	Relative and differential pressure transmitter
<a href="#">112282</a>	cable for the Huba pressure sensor 400.91100
<a href="#">692.911007141</a>	pressure transmitter

Product	Description
<a href="#">520.933S031101</a>	pressure transmitter
<a href="#">520.931S031101</a>	pressure transmitter
<a href="#">692.919101001W</a>	Relative and differential pressure transmitter
<a href="#">692.918101001W</a>	Relative and differential pressure transmitter
<a href="#">692.917101001W</a>	Relative and differential pressure transmitter
<a href="#">692.900017104</a>	Differential pressure Transmitter
<a href="#">520.930S032401</a>	Pressure transmitter
<a href="#">699.911011040</a>	differential pressure transmitter
<a href="#">604.9000030</a>	Relative and differential pressure switches
<a href="#">525.9260033J11</a>	pressure transmitter
<a href="#">210.611251N</a>	Flow sensor for liquid media
<a href="#">210.920441G</a>	Flow sensor
<a href="#">699.917211040</a>	differential pressure transmitter
<a href="#">699.B15224010</a>	differential pressure transmitter
<a href="#">528.9320033711W</a>	pressure transmitter
<a href="#">692.9121071B1</a>	Pressure transmitter
<a href="#">520.930S033901</a>	Pressure transmitter
<a href="#">605.99527</a>	
<a href="#">520.940S03300N</a>	
<a href="#">114605</a>	cable connector
<a href="#">113776</a>	connection set
<a href="#">520.954S030301</a>	Pressure transmitter
<a href="#">528.9330031C11W</a>	Pressure Transmitter
<a href="#">604.9110032</a>	pressure switch
<a href="#">402.9110021</a>	Relative and differential pressure transmitter
<a href="#">520.930S031301</a>	Sensor
<a href="#">699.C16215040</a>	Pressure sensor
<a href="#">630.940127</a>	pressure switch
<a href="#">630.940225</a>	pressure switch
<a href="#">520.954S03P421</a>	
<a href="#">210.910241G</a>	flow sensor
<a href="#">699.930221311</a>	pressure transmitter -
<a href="#">402.9100031</a>	Differential Pressure Transmitter
<a href="#">699.917011010W</a>	pressure transmitter
<a href="#">548.93300100D01301</a>	Pressure Transmitter
<a href="#">620.9102</a>	Relative pressure switch
<a href="#">520.932S030301W</a>	Control Pressure Transmitter
<a href="#">212.908420M1K</a>	flow sensor
<a href="#">236.915441K</a>	flow sensor
<a href="#">520.932S021201</a>	
<a href="#">210.915641K</a>	flow sensor
<a href="#">210.815651K</a>	flow sensor
<a href="#">210.915741K</a>	flow sensor
<a href="#">210.815751K</a>	flow sensor
<a href="#">604.S110020</a>	pressure switch

Product	Description
<a href="#">699.917025010</a>	pressure transmitter
<a href="#">604.9010000</a>	pressure switch
<a href="#">520.943S0C1401</a>	
<a href="#">699.915011040</a>	
<a href="#">525.9220031911</a>	
<a href="#">528.9311031711W</a>	
<a href="#">402.9200021</a>	sensor
<a href="#">511.914603131W</a>	Pressure sensor
<a href="#">520.917S030301W0</a>	Relative pressure transmitter
<a href="#">506.940A03101W</a>	pressure transmitter
<a href="#">230.615351A</a>	FLOW SENSOR
<a href="#">1THBCA0023</a>	
<a href="#">625.9132R</a>	PRESSURE SWITCH
<a href="#">210.915241N</a>	Flow sensor for liquid media
<a href="#">692.9000071D1</a>	pressure transmitter
<a href="#">7170310 7822897</a>	
<a href="#">528.931003141W</a>	
<a href="#">210.8.10.2.5.1.G</a>	flow sensor
<a href="#">525.925003P411</a>	Relative pressure transmitter
<a href="#">692.916007141</a>	pressure transmitter
<a href="#">528.9140030311W</a>	Pressure transmitter
<a href="#">652.92410000001</a>	differential pressure transmitter
<a href="#">528.9110030311</a>	relative and absolute pressure transmitters
<a href="#">528.9111133321W</a>	transmitter
<a href="#">528.9121133321W</a>	transmitter
<a href="#">528.9171133321W</a>	transmitter
<a href="#">680.803320105</a>	seniore pressure
<a href="#">692.919207301</a>	pressure transmitter
<a href="#">520.906S062301</a>	Relative pressure transmitter
<a href="#">528.9110030411</a>	pressure transmitter
<a href="#">520.932S03030W</a>	
<a href="#">520.931S033421</a>	Pressure Transmitter
<a href="#">520.940S03300NW</a>	Pressure transmitter
<a href="#">520.914S03340N</a>	Relative pressure transmitter
<a href="#">699.932225110</a>	differential pressure transmitter
<a href="#">692.919107182w</a>	
<a href="#">520.954S0334O1</a>	Pressure transmitter
<a href="#">692.940107161</a>	relative and differential pressure transmitter
<a href="#">692.917007001</a>	
<a href="#">Type 528</a>	
<a href="#">625.9122</a>	Relative pressure switch
<a href="#">520.954S03340N</a>	
<a href="#">528.811003LE11W</a>	
<a href="#">506.933A06101W0</a>	
<a href="#">520.933S06100NW</a>	Relative pressure transmitter

<b>Product</b>	<b>Description</b>
<a href="#">625.9146R</a>	Pressure Switch
<a href="#">699.910025110</a>	RELATIVE AND DIFFERENTIAL PRESSURE TRANSMITTER
<a href="#">625.64B2R</a>	pressure switch
<a href="#">699-B31221110</a>	
<a href="#">699.912013010</a>	differential pressure transmitter
<a href="#">699.916013010</a>	differential pressure transmitter
<a href="#">620.9400</a>	pressure switch
<a href="#">400.97100</a>	
<a href="#">528.8150033111</a>	Pressure transmitter
<a href="#">699.91702414</a>	
<a href="#">699.917025111</a>	Pressure Transmitter
<a href="#">604.92400C2R</a>	Pressure Transmitter
<a href="#">522.9335043401</a>	Relative pressure transmitter for shipbuilding
<a href="#">699.930225113</a>	pressure transmitter
<a href="#">604.9111130</a>	air pressure switch
<a href="#">528.9321031411</a>	
<a href="#">699.916013041</a>	
<a href="#">680.801310105N</a>	Relative and absolute pressure transmitter
<a href="#">604.9510020</a>	Relative and differential pressure switch
<a href="#">403.98000</a>	Relative and differential pressure transmitters
<a href="#">210.908441G</a>	Flow sensor for liquid media
<a href="#">528.9170023422W</a>	Pressure transmitter
<a href="#">525.9282013H11W</a>	Relative pressure transmitter
<a href="#">692.912007141</a>	Pressure transmitter
<a href="#">236.910542K</a>	flow sensor
<a href="#">528.9140031711W</a>	Relative and absolute pressure transmitter
<a href="#">212.82651CM1N</a>	flow sensor
<a href="#">212.80851CM1N</a>	Flow sensor
<a href="#">550.954S03P421</a>	
<a href="#">528.931008L411</a>	
<a href="#">4730097A</a>	
<a href="#">4730191P</a>	
<a href="#">520.940S03100NW</a>	Relative pressure transmitter
<a href="#">528.9170033411W</a>	
<a href="#">69.146.6001</a>	Differential pressure sensor
<a href="#">692.912107101</a>	Differential Pressure Transmitter
<a href="#">Adapter cable sensor.Miss bend 60B1</a>	
<a href="#">210.925441G</a>	flowmeter
<a href="#">520.917S031401</a>	
<a href="#">604.9230022U</a>	
<a href="#">699.911211010</a>	differential pressure transmitter
<a href="#">210.915441K</a>	flow sensor
<a href="#">712.D14124214W</a>	transmitter
<a href="#">520.931S18140N</a>	Pressure Sensor
<a href="#">699.912214.010</a>	Relative and differential pressure transmitter

<b>Product</b>	<b>Description</b>
<a href="#">692.914101141</a>	transmitter
<a href="#">680.706311103N</a>	Relative and absolute pressure transmitters
<a href="#">520.941S041421</a>	pressure transmitter
<a href="#">625.91A4</a>	Relative pressure switch
<a href="#">625.6432</a>	pressure switch
<a href="#">699.913215010</a>	Differential Pressure Transmitter
<a href="#">2546146</a>	
<a href="#">520.954S173501</a>	Ratiometric Sensor
<a href="#">528.9310031311</a>	Relative and absolute pressure transmitter
<a href="#">652.91410020000</a>	Pressure transmitter
<a href="#">528.8170021411W</a>	
<a href="#">520.933S03300NW</a>	Pressure transmitter
<a href="#">604-S210030</a>	flow monitor
<a href="#">6273610</a>	
<a href="#">699.913615010</a>	Differential Pressure Transmitter
<a href="#">212.906420M1K</a>	flow sensor
<a href="#">505.931B1 //BI1592115</a>	Primary Circuit Pressure Switch
<a href="#">402.9500021</a>	Pressure transmitter
<a href="#">699.931211042</a>	differential pressure sensor
<a href="#">699.914024140</a>	Pressure transmitter
<a href="#">528.9110031511</a>	pressure sensor
<a href="#">699.913021012</a>	differential pressure transmitter
<a href="#">525.9260031911</a>	
<a href="#">236.610351M</a>	flow sensor
<a href="#">699.933214022</a>	differential pressure transmitter
<a href="#">699.B12025110</a>	Differential pressure transmitter
<a href="#">604.9210002</a>	pressure switch
<a href="#">604.9001130</a>	Relative and differential pressure switch
<a href="#">692.915007141</a>	pressure transmitter
<a href="#">210.906442K</a>	
<a href="#">401.99001</a>	pressure switch
<a href="#">7822897</a>	
<a href="#">520.933S03100NW</a>	relative pressure transmitter
<a href="#">692.9180071B1W</a>	Relative and differential pressure transmitter
<a href="#">620.9512</a>	Flow Pressure Switch