



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Avs Römer

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">P/N: 342033 Type: 930P-22-3/4</a>	Screw-in angle V, rotatable
<a href="#">606009</a>	Part 3/2-way solenoid valve
<a href="#">XGV-3000-000-D13FO-04</a>	P-lock unit
<a href="#">P/N: 610546 Type: XGV-3000-000-D13PO-04</a>	P-closing unit
<a href="#">XGV-2000-000-D12PP-04</a>	P-Verschluss-Einheit
<a href="#">p/n: 610841 type: XGV-1000-000-D20FO-04</a>	p-lock unit
<a href="#">p/n: 610850 type: XGV-1000-000-D20FP-04</a>	p-lock unit
<a href="#">XGV-1000-000-D32FO-04</a>	p-lock unit
<a href="#">613721 / EGV-111-B96-3/4BP-00</a>	Part 2/2-way solenoid valve
<a href="#">695901</a>	Type: MSV-311-O50-1 / 8 5/3-way valve lever spring
<a href="#">70001138 // E22-024/= -M0 (720016)</a>	solenoid coil
<a href="#">E22-024/= -H0 / 720006</a>	solenoid coil IP00
<a href="#">E22-024/= -M9 (720216)</a>	solenoid coil
<a href="#">720031</a>	Magnetspule IP00
<a href="#">E22-230/50-60-H0</a>	Solenoid Coil for above Solenoid Valve
<a href="#">E22-230/50-60-H0</a>	solenoid coil
<a href="#">EAV-211-B15-1/8B-00</a>	Part-2/2-way solenoid valve
<a href="#">EAV-211-D15-1/8B-00</a>	Part 3/2-way solenoid valve
<a href="#">70350881 // EAV-221-C15-1/8B-00 (606159)</a>	partial 3/2-way solenoid valve
<a href="#">609851 / EAV-411-D12-FL5B-00</a>	Partial 3/2-way flange MV
<a href="#">609883 / EAV-451-C12-FL5B-00</a>	Partial 3/2-way flange MV
<a href="#">P/N: 684026 Type: EDV-113-A60-3/8B-00</a>	part 2/2-way magnetic valve
<a href="#">EGV-111-A78-2 PN-00</a>	Part 2/2-way solenoid valve
<a href="#">EGV-111-A78-3/4PN-00</a>	Part 2/2 way solenoid valve
<a href="#">EGV-111-AH9-1BN-00</a>	2/2-way flange
<a href="#">EGV-111-B96-3/4BP-00</a>	Part 2/2-way solenoid valve
<a href="#">EGV-112-A78-1CG-00</a>	Teil-2/2-Wege-Magnetventil
<a href="#">650686</a>	Partial 2/2-way solenoid valve
<a href="#">EGV-161-BLH-D20HL-00</a>	2/2 way solenoid valve
<a href="#">70233193 - EGV-211-A79-1/2BN-00</a>	2/2-way solenoid valve
<a href="#">EGV-211-A79-3/8PN-00</a>	
<a href="#">EGV-311Q-A78-1/2FR-00 / 613486</a>	Part 2/2-way solenoid valve
<a href="#">ESG-122-09-N-G13</a>	Conductor socket
<a href="#">610001</a>	Teil-4/2-Wege-Magnetventil
<a href="#">EWV-111-G60-1/4B-00 BestellNr.: 610001</a>	Teil-4/2-Wege-Magnetventil
<a href="#">614392</a>	

Product	Description
<a href="#">626206</a>	Valve
<a href="#">PKV-137-F71-3/4B</a>	3/2-way valve
<a href="#">RFO-133-A60-1/4 (635682)</a>	throttle valve
<a href="#">XGV-1000-000-D20BO-04-10</a>	
<a href="#">XGV-1000-000-D20CG-04 E-VERSCHLUSS-EINHEIT</a>	
<a href="#">XGV-3000-000-D13FN-04-10</a>	e-lock unit
<a href="#">P/N: 610450 Type: XGV-3000-000-D13FP-04</a>	p-lock unit
<a href="#">720016, E22-024</a>	Coil IP00
<a href="#">EGV-111-A78-5/4BN-00 BestellNr.: 613571</a>	Magnetventil
<a href="#">XGV-1000-000-D32CL-04-10 BestellNr.: 611967</a>	10er-Pack P-Verschluss-Einheit
<a href="#">262X4-1/4F (AISI316) BestellNr.: 356527</a>	fastener screw
<a href="#">EWV-141-G60-1/4B-00</a>	Teil-4/2-Wege-Magnetventil
<a href="#">XGV-3000-000-D13CL-04-10 (611423)</a>	10er-Pack P-Verschluss-Einheit
<a href="#">EOX-230/50-60-HO (600501)</a>	Magnet-Spule
<a href="#">PKH-214-A25- 1 T-I2</a>	2/2-Wege-Pneumo-Kugelhahn
<a href="#">EAV-321/04-C15-M05B-00</a>	Valve
<a href="#">163M-11-M5N</a>	1 bolt, short
<a href="#">322M-M5S-M5</a>	Schwenk-Ringstück
<a href="#">254M-M5</a>	Muffe
<a href="#">266N-M5x1</a>	PA-Dichtring
<a href="#">XGV-2000-000-D12FP-04</a>	Locking unit
<a href="#">EAV-221-C18-1/8B-00 / 606165</a>	Partial 3/2-way solenoid valve
<a href="#">E22-024/= -H9 (720206)</a>	Magnetspule IP65
<a href="#">P/N: 720211 Type: E22-230/50-M9</a>	magnetic coil
<a href="#">EAV-211-A18-1/8FK-00</a>	Teil-2/2-Wege-Magnetventil
<a href="#">RFO-133-A20-1/8</a>	Drosselventil
<a href="#">RFO-133-A30-1/8</a>	butterfly valve
<a href="#">VNR-133-M60-1/4F</a>	Valve
<a href="#">383A-1/2-1/4</a>	Verteiler-Block
<a href="#">303A-1/2</a>	Kreuz-Stück
<a href="#">PA-10/8-blau</a>	Polyamid-Schlauch
<a href="#">PA-8/6-blau</a>	Polyamid-Schlauch
<a href="#">PA-22/18-transparent</a>	Polyamid-Schlauch
<a href="#">PV-10/8-blau</a>	PVC-Gewebe-Schlauch
<a href="#">951M-12-3/8</a>	Gerade Einschraub-V.
<a href="#">951M-12-1/2</a>	Gerade Einschraub-V.
<a href="#">950M-10-D3/8K</a>	Winkel-Einschraub-V.
<a href="#">950M-10-D1/2K</a>	Winkel-Einschraub-V.
<a href="#">PGV-131-B76-3/4BO</a>	2/2-Wege-Ventil, druckbetätigt
<a href="#">REG-215-1/4</a>	Druckregler (mit Manometer)
<a href="#">613154 , EGV-213-A79-1/2CG-00</a>	Section 2/2 way magnetic valve
<a href="#">617127</a>	
<a href="#">E22-024/= -HO</a>	Magnetspule
<a href="#">XGV-2000-000-D12BP-04</a>	P-Verschluss-Einheit
<a href="#">252012</a>	Winkel-Stück

Product	Description
<a href="#">250187</a>	Einschraub-Tülle
<a href="#">250188</a>	Einschraub-Tülle
<a href="#">250454</a>	Doppel-Reduziernippel
<a href="#">250855</a>	Reduziernippel
<a href="#">251057</a>	Muffe
<a href="#">252057</a>	Winkel-Stück
<a href="#">252153</a>	T-Stück
<a href="#">252253</a>	T-Stück
<a href="#">254031 (302M-1/8)</a>	Angle screw-in piece
<a href="#">254081</a>	T-Einschraub-Stück
<a href="#">252157</a>	T-Stück
<a href="#">250257</a>	Doppelnippel
<a href="#">250657</a>	Reduziernippel
<a href="#">319903</a>	Doppelnippel, lösbar
<a href="#">340516</a>	Gerade Einschraub-V.
<a href="#">340521</a>	Gerade Einschraub-V.
<a href="#">340817</a>	Gerade Aufsraub-V.
<a href="#">340821</a>	Gerade Aufsraub-V.
<a href="#">341016</a>	Winkel-Einschraub-V.
<a href="#">341017</a>	Winkel-Einschraub-V.
<a href="#">341018</a>	Winkel-Einschraub-V.
<a href="#">341021</a>	Winkel-Einschraub-V.
<a href="#">341022</a>	Winkel-Einschraub-V.
<a href="#">348816</a>	Gerade Schott-Verschraubung
<a href="#">347414</a>	T-Steck-Verbindung
<a href="#">347415</a>	T-Steck-Verbindung
<a href="#">EGV-111-Z76-3/4FP-00</a>	Valve
<a href="#">EGV-161-Z56-1 BP-00</a>	Wege-Magnetventil
<a href="#">P/N: 720011 Type: E22-230/50-MO</a>	magnetic coil
<a href="#">XGV-1000-000D32FO-04 610891</a>	Sealing unit
<a href="#">XGV-3000-000-D13FO-04 P/610411</a>	sealing unit
<a href="#">XGV-1000-000-D32BN-04 / 610876</a>	E-lock unit
<a href="#">P/N: 616321 Type: EGV-111-AH9-3/4BN-00</a>	Electrovalve
<a href="#">EGV-111-A78-1/2BN-00 (613501)</a>	Part 2/2-way solenoid valve
<a href="#">EOX-110/50-60-HO (600504)</a>	solenoid coil
<a href="#">E22-024/= -LO</a>	Magnetspule IP00
<a href="#">258414</a>	568M-9 Kupplungsstecker NG8
<a href="#">720016 (E22-024/= -MO Magnetspule IP00)</a>	
<a href="#">EGV-111-AH9-3/4BN-00 Teil-2/2-Wege-Flansch-MV (616321)</a>	2/2-Wege-Magnetventil-Batterie
<a href="#">PN: 460881 / FIL-161-ML-1 1/2</a>	compressed air filter
<a href="#">600504 EOX-110/50-60-HO</a>	magnetic coil
<a href="#">EGV-713-A79-1FN-00</a>	2/2-Way Solenoid Valve - Type EGV Series 700
<a href="#">P/N: 616701 Type: EGV-311-AH9-1/2BN-00</a>	part 2/2-way flange MV
<a href="#">SCS-233-A40-1/8B (636231)</a>	Doppel-Rückschlagventil
<a href="#">XGV-3000-000-D13CL-04</a>	DIAPHRAGM

Product	Description
<a href="#">XGV-2000-000-D12CL-04</a>	P-Verschluss-Einheit
<a href="#">617446</a>	
<a href="#">451091 / REG-125-3/8</a>	Pressure regulator (with pressure gauge)
<a href="#">614313</a>	2/2-Wege-Ventil
<a href="#">610001 E WV-111-G60-1/4B-00</a>	4/2-Wege-Magnetventil
<a href="#">Magnetic coil 24V 8W for EGV-112-A78 valve</a>	Magnetic coil
<a href="#">613505 / EGV-111-A78-1/2FN-00</a>	Part-2/2-way solenoid valve
<a href="#">613601</a>	
<a href="#">P/N: 606041 Type: EAV-213-C18-1/8F-00</a>	3/2 way valve
<a href="#">E22-230/50-M0 (720011)</a>	solenoid coil
<a href="#">EGV-112-A78-1/2PR-00 Teil-2/2-Wege-Magnetventil</a>	Teil-2/2-Wege-Magnetventil
<a href="#">E30-230/50-60-PO (730040)</a>	E30-230/50-60-PO Magnetspule IP00
<a href="#">E22-230/50-M0</a>	Solenoid coil IP00
<a href="#">E22-024/= -M0, Art N: 720016</a>	Magnetspule IP00
<a href="#">P/N: 635682 Type: RFO-133-A60-1/4</a>	throttle valve
<a href="#">605233</a>	Teil-2/2-Wege-Magnetventil
<a href="#">XGV-1000-000-D20HL-04-10</a>	
<a href="#">XGV-1000-000-D32HL-04-10 (611989)</a>	10-pack P-lock unit
<a href="#">70226992</a>	2/2-way valve without coil
<a href="#">PKV-132-A31-1/2F</a>	2/2-way coax valve
<a href="#">SCS-233-A40-1/8B</a>	double check valve
<a href="#">616301 (EGV-111-AH9-1/2BN-00)</a>	2/2-way flange valve
<a href="#">652695</a>	
<a href="#">650685</a>	
<a href="#">720216</a>	
<a href="#">EAV-213-A20-M05BK-00</a>	
<a href="#">EGV-112-A78-1/2PR-00</a>	
<a href="#">Art. Nr. 613558 , type EGV-111-A78-1 CG-00</a>	Teil-2/2-Wege-Magnetventil
<a href="#">EGV-121-C78-3/4BN-00</a>	Part 2/2-way solenoid valve
<a href="#">613521 / EGV-111-A78-3/4BN-00</a>	Part-2/2-way solenoid valve
<a href="#">EGV-111-A78-5/4BN-00</a>	2/2-way Solenoid valve
<a href="#">p/n: 70265126 type: EGV-111Q-A78-3/4BN-00</a>	Section 2/2-way magnetic valve
<a href="#">E30-024/= -PO</a>	Magnetspule IP00
<a href="#">610563 , XGV-2000-000-D12CG-04</a>	E-Verschluss-Einheit
<a href="#">EGV-112-A78-1/2PR-00 (650686)</a>	
<a href="#">955P-14 (347319)</a>	Winkel-Steck-Verbindung
<a href="#">720266 (E22-024/= -L9)</a>	
<a href="#">70017893</a>	2/2-Wege-Teil-Magnetventil
<a href="#">PKV-137-C61-1/2B (626601)</a>	3/2-way valve, pressure-operated
<a href="#">EAV-213-A30-1/8 FK-00</a>	Teil-2/2-Wege-Magnetventil
<a href="#">EAV-213-A30-1/8 FK-00 (250pcs)</a>	
<a href="#">EAV-213-A30-1/8 FK-00 (100pcs)</a>	
<a href="#">XGV-1000-000-D20CL-04</a>	P lock unit
<a href="#">70001138 - E22-024/= -M0 Solenoid coil IP00</a>	Magnetic coil
<a href="#">652663</a>	

Product	Description
<a href="#">70001138 - E22-024/=</a>	MO solenoid IP00
<a href="#">955V-10-8FF</a>	Angle plug connection
<a href="#">ITS-958P3-4FF-NTC47</a>	Temperatursensor
<a href="#">EGV-111-AHL-D50PR-00</a>	
<a href="#">ITS-958P3-6FF-NTC47</a>	Temperatursensor
<a href="#">EAV-211/V4-A18-1/8FK-00</a>	Part-2/2-way MV, 4-way
<a href="#">MSV-321-C50-1/8</a>	3/2-way valve
<a href="#">613911</a>	
<a href="#">606041</a>	
<a href="#">PGV-231-B77-3/8BP</a>	2/2-way valve, pressure-operated
<a href="#">605003</a>	
<a href="#">E30-024</a>	
<a href="#">340029</a>	
<a href="#">P/N: 347324 Type: 955P-22</a>	Angle plug connection
<a href="#">E22-012/= -H0 (70229880)</a>	
<a href="#">E22-024/= -H0 (70229881)</a>	
<a href="#">623054</a>	
<a href="#">613515</a>	
<a href="#">610411</a>	
<a href="#">P/N: 610555 Type: XGV-2000-000-D12PP-04</a>	P Lock unit
<a href="#">EGV-111-AH9-3/4CG-00 / 616328</a>	Partial 2/2-way flange MV
<a href="#">720034</a>	Solenoid coil
<a href="#">Nr.: 730001 Type: E30-230/50-PO</a>	solenoid
<a href="#">P/N: 720031, Type: E22-230/50-60HQ</a>	Magnetspule IP00
<a href="#">EGV-111-AH9-3/4BN-00</a>	
<a href="#">EAV-211-B18-1/8B-00</a>	2/2-Wege-Magnetventil
<a href="#">p/n: 613511 type: EGV-111Q-A78-1/2BN-00</a>	partial 2/2 way solenoid valve
<a href="#">P/N: 613558 Type: EGV-111-A78-1CG-00</a>	2/2-Wegeventil
<a href="#">70332124</a>	valve
<a href="#">702521 (ESG-122-07-N-G13)</a>	conduit socket
<a href="#">7 166 001</a>	Vessel 1&2 air outlet check valve 1" 1/2 Size
<a href="#">0000-K515-027 ( 479024) (OEM product)</a>	
<a href="#">0000-K515-025 ( 49023)</a>	Filter
<a href="#">70001153 / EGV-112-A78-1/2CG-00</a>	Part-2/2-way solenoid valve
<a href="#">EGV-311-A78-1/2BN-00</a>	Part 2/2 way solenoid valve
<a href="#">EGV-111-Z76-1/2BO-00</a>	Solenoid Valves
<a href="#">EGV-111-Z76-3/4BO-00</a>	Solenoid valves
<a href="#">E22-230/50-60-H9</a>	
<a href="#">EGV-1035-A78-3/4PN-00</a>	solenoid valve
<a href="#">0001-K517-006 (OEM)</a>	
<a href="#">EDV113-A60-3/8B-024=-D9</a>	
<a href="#">954P-8</a>	T-Steck-Verbindung
<a href="#">955P-8</a>	Winkel-Steck-Verbindung
<a href="#">E22-024/=H0 24V DC/8W (70011713)</a>	solenoid coil
<a href="#">EWV-111-G60-1/4B-00</a>	Part 4/2-way solenoid valve



Product	Description
<a href="#">EOX-110/50-60-HO</a>	Magnet-Spule
<a href="#">EAV-213-C18-1/8</a>	
<a href="#">E22-024/= -M0 Magnetspule IP00</a>	
<a href="#">EAV-311-C15-FL1F-00</a>	
<a href="#">EGR-152-1C78-3/4CG-00</a>	Valve
<a href="#">EGV-161-Z58-1/2BO-00</a>	magnetic valve
<a href="#">EGR-152-1C78-3/4CG-00 (654348)</a>	Teil-2/2-Wege-Magnetventil
<a href="#">EMD-S1/4-E30-6F-024/= -NG</a>	electro valve / Elektroprn. Dosierpumpe, 4-fach
<a href="#">P/N: 652662 Type: EGV-161Q-BLH-D20HL-00</a>	magnetic valve
<a href="#">P/N: 627351 Type: ETV-222-A15-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 627363 Type: ETV-222-A20-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 627353 Type: ETV-222-A25-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 627401 Type: ETV-211-B15-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 627409 Type: ETV-211-B20-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 627421 Type: ETV-217-C15-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 627427 Type: ETV-217-C20-4PF-024/= -U0</a>	solenoid valve
<a href="#">P/N: 652661 Type: EGV-161Q-ALH-D20HL-00</a>	magnetic valve
<a href="#">EKH-S01-A12-1/2T-230/50-Y0</a>	ball valve
<a href="#">EGV-3015-A78-1/2BN-00</a>	magnetic valve
<a href="#">VNR-133-M60-1/4B (635004)</a>	non-return valve
<a href="#">D-82548</a>	2/2 way valve
<a href="#">EGV-211-A79-3/8FN-00</a>	Part 2/2-way solenoid valve
<a href="#">E30-024/= -P0 / 730006</a>	Coil
<a href="#">E22-024/=LO (720066)</a>	solenoid coil IP00
<a href="#">EAV-213-C18-1/8B-00 (606040)</a>	part 3/2 way solenoid valve
<a href="#">P/N: 720012 Type: E22-024/= -M0</a>	Coil
<a href="#">P/N: 606010 Type: EAV-211-C15-1/8F-00</a>	solenoid valve
<a href="#">P/N: 626205 Type: PKV-131-A11-1/2F</a>	Coaxial valve
<a href="#">300500 Type: 15M-6/4-M6</a>	Straight Adaptor-Male
<a href="#">ICS-958P3-6FF</a>	conductivity sensor
<a href="#">EGR-151Q-6A78-1/2BN-00</a>	Magnetic valve
<a href="#">652851 / EGV-151-Y58-5/4BO-00</a>	Partial 2/2-way solenoid valve
<a href="#">P/N: 606046 Type: EAV-213-C20-1/8B-00</a>	Valve
<a href="#">P/N: 347524 Type: 954P-22</a>	T-plug connection
<a href="#">P/N: 340033 Type: 951M-22-3/4</a>	FITTING,STRAIGHT,PUSH
<a href="#">P/N: 347124 Type: 958P-22</a>	Straight plug connection
<a href="#">611939. XGV-1000-000-D50HL-04</a>	P-Lock unit
<a href="#">P/N: 720015 Type: E22-012/= -M0</a>	Magnetic coil
<a href="#">P/N: 610896 Type: XGV-1000-000-D32BP-04</a>	P-Verschluss-Einheit
<a href="#">P/N: 610846 Type: XGV-1000-000-D20BP-04</a>	P-lock unit
<a href="#">EGV-111/V2-AH9-1/2BN-00</a>	
<a href="#">E22-110/50-60-H0</a>	coil
<a href="#">EGV-151-Y58-5/4BO-00 (652851)</a>	valve
<a href="#">151M-6/4-M6 (300500)</a>	Straight screw-V.
<a href="#">605403 // EAV-211-B12-1/8B-00</a>	Solenoid valve

Product	Description
<a href="#">EGV-2003-B97-3/8CL-00</a>	magnetic valve
<a href="#">EAV-211-A30-1/8BK-00 (605031)</a>	solenoid valve
<a href="#">P/N: 610826 Type: XGV-1000-000-D20BN-04</a>	Membrane
<a href="#">EGV-100-A78-1BN-01</a>	partial 2/2 way solenoid valve
<a href="#">EGV-111-A78-5/4PR-00</a>	
<a href="#">730002</a>	
<a href="#">652933</a>	2/2 way solenoid valve
<a href="#">ETV-222-A25-6FF-024/=U0</a>	2/2-way solenoid valve
<a href="#">70276216</a>	straight solder-in fitting
<a href="#">360014 (151X4-6/4-1/8)</a>	Straight screw-in screw connection
<a href="#">360029 (151X4-10/8-1/8)</a>	Straight screw-in screw connection
<a href="#">PSV-331-C50-1/8</a>	Valve
<a href="#">E22-024/= -M9</a>	magnet coil for EGV-311Q-A78-1/2FR-00
<a href="#">EGV-111-A78-1/2PN-00</a>	2/2-way solenoid valve
<a href="#">E22-230/50-M9</a>	MAGNETIC COIL
<a href="#">p/n: 650685 type: EGV-112-A78-3/4PR-00</a>	2/2-way solenoid valve
<a href="#">300010</a>	Straight Adaptor - Male
<a href="#">250152</a>	Hosetail Adaptor
<a href="#">340010</a>	Straight Adaptor - Male
<a href="#">370010</a>	Banjo Fitting
<a href="#">E22-024/50-M0 720012</a>	magnetic coil
<a href="#">EGV-111-A78-1/2BN-00</a>	solenoid valve
<a href="#">E22-110/50-M0</a>	Solenoid coil
<a href="#">EGV-311Q-A78-1/2FR-024/50-M0</a>	Solenoid Valve
<a href="#">ITS-958P3-6FF-PT100</a>	Temperature sensor
<a href="#">IPS-V05-958P3-6FF-016-51</a>	Pressure sensor
<a href="#">652916, Type: EGV-151-Y56-6/4BO-00</a>	Solenoid valve
<a href="#">EAV-211-C15-1/8B-00</a>	valve
<a href="#">EGV-111/V3-AH9-1/2BN-00</a>	Part-2/2-way MV, 3-pack battery
<a href="#">Nr. 250222 Type 260M-20-1/2</a>	Screw-in nozzle
<a href="#">USV-321-C50-1/8 3/2 / 695124</a>	3/2-way valve
<a href="#">PGV-131-B76-3/4FO</a>	Valve
<a href="#">EAV-211-A30-1/8BK-00</a>	Part-2/2-way solenoid valve
<a href="#">EGV-111-AH9-5/4BN-00 (616421)</a>	Part-2/2-way flange-MV
<a href="#">EGV-111-A78-1/2BN-00 (70001152)</a>	2/2-way part solenoid valve G1/2I
<a href="#">70302880 E22-024/50-M9</a>	Magnetic coil
<a href="#">EGR-351-1A78-1/2BN-00 PN: 654051</a>	2/2-way solenoid valve
<a href="#">EGV-1035/V2-AH9-3/4PN-00</a>	Valve
<a href="#">610557 / XGV-2000-000-D12HL-04</a>	P-Lock Unit
<a href="#">XGV-1000-000-D20HL-04</a>	P-Lock Unit
<a href="#">610413 / XGV-3000-000-D13HL-04</a>	P-Lock Unit
<a href="#">610826</a>	E-lock unit
<a href="#">501033</a>	O-ring
<a href="#">EAM-201-A00-000BK-00</a>	Part-2/2-way magnetic system
<a href="#">EGV-100-A78-3/4BN-01</a>	Piece-2/2-way solenoid valve



Product	Description
<a href="#">623552</a>	
<a href="#">E22-024/= -H0 / PN: 720006</a>	Solenoid coil IP00
<a href="#">Artikel 450141 Type FIL-161-1</a>	Compressed air filter
<a href="#">EAV-213-D18-1/8B-00 (606340)</a>	solenoid valve
<a href="#">PGV-131-BH7-3/4CL</a>	2/2-way flange V.
<a href="#">Artikel 400351 Type XIL5-160-060</a>	Filter Element
<a href="#">XGV-2000-000-D12PP-04 P</a>	Slatch unit
<a href="#">PGV-131-B76-2BO</a>	2/2 directional valve
<a href="#">XGV-1000-000-D20BN-04 E</a>	Shutter unit
<a href="#">EGV-211-A79-3/8BN-00</a>	Part-2/2-way solenoid valve
<a href="#">PGV-131/V2-BH7-3/4BO</a>	2/2-way valve, pressure-operated
<a href="#">XGV-1000-000-D20BO-04</a>	P-lock unit
<a href="#">EGV-111-A78-1CG-00</a>	2/2-way solenoid valve
<a href="#">XGV-1000-000-D32CG-04</a>	E-lock unit
<a href="#">PGV-151-A96-1BP</a>	2/2-way valve, pressure-operated
<a href="#">E22-230/50-60-HO / 70242987</a>	magnetic coil
<a href="#">EAV-211-C18-1/8F-00</a>	Part-3/2-way solenoid valve
<a href="#">EGV-112-A78-1PR-00</a>	Part-2/2-way solenoid valve
<a href="#">930M-12-3/8</a>	
<a href="#">E22-024/50-M0</a>	solenoid coil
<a href="#">EAV-213-A18-1/8FK-00</a>	Part-2/2-way solenoid valve
<a href="#">EBV-113-A40-1/4F-00</a>	Part-2/2-way solenoid valve
<a href="#">720212 E22-024/50-M9</a>	solenoid coil
<a href="#">150M-10/8KS-1/4K 301280</a>	Angle Incl. -v.m.ks spiral
<a href="#">130M-10/8KS-1/4</a>	Angled screw-in V., rotatable
<a href="#">E22-024/= -M0</a>	solenoid coil
<a href="#">EGV-111-A78-1/2FN-00</a>	Part-2/2-way solenoid valve
<a href="#">P/N: 613551 Type: EGV-111-A78-1BN-00</a>	Part-2/2-way solenoid valve
<a href="#">EAV-315-C12-FL1B-00</a>	Part-3/2-Way Flange MV
<a href="#">PGV-231-B77-1/2BP / 614051</a>	2/2-way valve
<a href="#">356562</a>	
<a href="#">V61B517A-A219J</a>	5/2-way valve
<a href="#">EGV-713-A79-1/2PN-00</a>	
<a href="#">PGV-131-B76-1FO</a>	2/2 way valve
<a href="#">XGV-1000-000-D32HL-04</a>	membrane
<a href="#">951P3-8FF-1/4</a>	Straight Screw-In V (PPSU)
<a href="#">911P3-8FF-D8</a>	
<a href="#">340017 / 951M-8-1/4</a>	Straight connector male, cylindrical. 8-1/4
<a href="#">951P3-6FF-1/4</a>	straight-screw-in v. (ppsu)
<a href="#">930P3-6FF-1/4</a>	1/4 angle screw -v.DrehB. (PPSU)
<a href="#">930V-6FF-1/4</a>	Male clamp, cylindrical. 6-1/4
<a href="#">951X4-8FF-1/4</a>	Straight connector male, cylindrical. 8-1/4
<a href="#">EAV-213-A30-1/4BK-00</a>	Part-2/2-way solenoid valve
<a href="#">VRN-954-P340-6FF (634938)</a>	Check valve
<a href="#">635004 VNR-133-M60-1/4B</a>	check valve

Product	Description
<a href="#">EAV-211-A12-1/8BK-00</a>	Part 2/2 way solenoid valve
<a href="#">E30-230/50-PO</a>	solenoid coil ip00
<a href="#">P/N: 70305705, Type: EAV-213-C12-1/8B-00</a>	directional valve
<a href="#">P/N: 613051, Type: EGV-211-A79-1/2BN-00</a>	2/2 way solenoid valve
<a href="#">381066</a>	930X4-8FF-1/8 wi-restriction -V., spin. (AISI316L)
<a href="#">616832 / EGV-311/V2-AH9-1/2PN-00</a>	2/2 way part solenoid valve NC
<a href="#">604616</a>	EAM-203-A00-000PK-00 part-2/2-way magnetic system
<a href="#">PKV-137-C61-3/4B</a>	VALVE
<a href="#">TSV-321-C80-1/4</a>	
<a href="#">702853</a>	cable 1,5m
<a href="#">EGV-111-B96-1/2HL-00</a>	part 2/2 way solenoid valve
<a href="#">EAV-213-C18-1/8B-00</a>	Partial 3/2-way solenoid valve
<a href="#">P/N: 654051 Type: EGR-351-1A78-1/2BN-00</a>	
<a href="#">P/N: 654201 Type: EGR-151-1C78-1/2BN-00</a>	
<a href="#">p/n: 720016 type: E22-024/= -M0</a>	magnetic coil IP00
<a href="#">P/N: 616705 Type: EGV-311-AH9-1/2PN-00</a>	
<a href="#">P/N: 720106 Type: E22-024/</a>	solenoid
<a href="#">652663 / EGV-151-Y58-3/4BO-00</a>	Part-2/2-way solenoid valve
<a href="#">P/N: 684081 Type: EDV-113-A10-1/2B-00</a>	solenoid valve
<a href="#">P/N: 613455 Type: EGV-S13-A78-6/4PN-00</a>	Part 2/2 way solenoid valve
<a href="#">654451, EGR-151-1A78-1BN-00</a>	solenoid valve
<a href="#">EAV-211-C18-1/8B-00</a>	solenoid valve
<a href="#">P/N:70335056, Type:E22-024/= -H7</a>	solenoid
<a href="#">70254491 (EGV-111-AH9-1/2BN-00)</a>	2/2-way flange venti
<a href="#">P/N: 342044 Type: 930P-22-3/4-FE</a>	
<a href="#">EGV-111-A78-6/4BN-00</a>	Part 2/2-way solenoid valve
<a href="#">EGV-111-Z76-1BO-00</a>	
<a href="#">P/N: 606901 Type: EAV-213-C30-1/8F-00</a>	partial 3/2-way solenoid valve
<a href="#">P/N: 720215 Type: E22-012/= -M9</a>	solenoid
<a href="#">P/N: 611882 Type: XGV-1000-000-D32HL-04</a>	p-lock unit
<a href="#">385028 / 951X44-8FF-1/4</a>	straight screw-in v. (aisi316l)
<a href="#">951P3-6FF-1/8</a>	1/8 straight-screw-in v. (ppsu)
<a href="#">951P3-4FF-1/4</a>	1/4 straight-screw-in v. (ppsu)
<a href="#">946X44-6FF-1/8</a>	straight screw-on v. (aisi316l)
<a href="#">930P3-8FF-1/4</a>	angle inset -v.spin. (ppsu)
<a href="#">930P3-6FF-1/8</a>	1/8 angle screw -v.DrehB. (PPSU)
<a href="#">954P3-6FF</a>	t-plug connection (PPSU)
<a href="#">982V-4FF</a>	Y-plug connection (PVDF)
<a href="#">958V-4FF</a>	straight plug connection (PVDF)
<a href="#">VNR-958-P340-6FF</a>	check valve
<a href="#">VNR-958-P360-8FF</a>	check valve
<a href="#">930P3-4FF-1/8</a>	1/8 angle screw -v.DrehB. (PPSU)
<a href="#">626010</a>	Drive unit
<a href="#">501338</a>	membrane
<a href="#">650686 // EGV-112-A78-1/2PR-00</a>	

Product	Description
<a href="#">XGV-S11-000-D50HL-04 P</a>	Closure unit
<a href="#">P/N: 605010 Type: EAV-211-A15-1/8FK-00</a>	partial 2/2-way solenoid valve
<a href="#">P/N: 606035 Type: EAV-213-C15-1/8F-00</a>	partial 3/2-way solenoid valve
<a href="#">613051 / EGV-211-A79-1/2BN-00</a>	solenoid valve
<a href="#">EAV-S72-A30-1/4BK-00 /608967</a>	partial 2/2 way solenoid valve
<a href="#">PN: 340521 / 951M-10-D1/4K</a>	Straight screw-in V
<a href="#">P/N: 614422 Type: PGV-131-B76-1FO</a>	2/2-way valve
<a href="#">P/N: 720014 Type: E22-110/50-M0</a>	magnetic coil IP00
<a href="#">p/n: 613421 type: EGV-321-C69-1/2BN-00</a>	partial 2/2 way solenoid valve
<a href="#">p/n: 605082 type: EAV-213-A30-1/8FK-00</a>	partial 2/2 way solenoid valve
<a href="#">618822</a>	solenoid valve
<a href="#">613041 / EGV-211-A79-3/8BN-00</a>	
<a href="#">p/n: 606082 type: EAV-217-C15-M05B-00</a>	partial 3/2-way solenoid valve
<a href="#">p/n: 720066 type: E22-024/= -L0</a>	magnetic coil IP00
<a href="#">IPS-V36-958P3-6FF-V04-51</a>	pressure sensor
<a href="#">p/n: 610446 type: XGV-3000-000-D13BP-04</a>	p lock unit
<a href="#">VNR-951-P325-4FF-1/4</a>	check valve
<a href="#">EGV-112-A78-1CG-00 (650673)</a>	solenoid valve
<a href="#">EGV-311-A78-1/2BR-00 / 613497</a>	solenoid valve
<a href="#">EGV-311-A78-1/2FN-00 / 613405</a>	solenoid valve
<a href="#">VGR-S101-1HA / 614356 OEM</a>	check valve block
<a href="#">EGR-151-1A78-1BN-00</a>	valve
<a href="#">XGV-1000-000-D20HL-04 / 610840</a>	
<a href="#">XGV-1000-000-D32HL-04 / 611882</a>	
<a href="#">p/n: 634902 type: VNR-951-P325-4FF-1/4</a>	check valve
<a href="#">p/n: 634910 type: VRN-951-P325-4FF-1/4</a>	check valve
<a href="#">695524</a>	valve
<a href="#">p/n: 341218 type: 930M-8-3/8</a>	angle-screw-v
<a href="#">p/n: 385109 type: 930X44M-8FF-3/8</a>	angle-screw-v
<a href="#">720016 // E22-024/= -M0</a>	solenoid coil IP00
<a href="#">720034 // E22-110/50-60-H0</a>	solenoid coil IP00
<a href="#">610938 / XGV-1000-000-D50BO-04 P</a>	lock unit
<a href="#">PN: 347314 / 955P-10-8</a>	angle-plug connection
<a href="#">614211 // PGV-131-B76-3/4BP</a>	2/2-way valve
<a href="#">UDV-982P3-6-4PF-060</a>	relief valve
<a href="#">IPS-V36-958P3-4FF-016-51 / 390901</a>	pressure sensor
<a href="#">650695 // EGV-111Q-A78-2PR-00</a>	part 2/2 way solenoid valve
<a href="#">720111 // E22-230/50-M7</a>	solenoid coil IP65
<a href="#">606034 // EAV-213-C15-1/8B-00</a>	solenoid valve
<a href="#">ICS-2-958P3-4FF-200-020-U05-51 / 390660</a>	conductivity sensor
<a href="#">613553 // EGV-111-A78-1PN-00</a>	Part 2/2 way solenoid valve
<a href="#">954V-10FF</a>	T-plug connection
<a href="#">70352446</a>	Part 2/2 way solenoid valve
<a href="#">955V-10-6FF</a>	Angle plug connection
<a href="#">958V-8-6FF</a>	Straight plug connection

Product	Description
<a href="#">70233193</a>	
<a href="#">EGV-111-Z76-1/2FP-00</a>	Part-2/2-way MV, pressbet
<a href="#">ESG-542-09T-C4-024VDC-G13</a>	Outlet
<a href="#">EGV-111-AH9-1BN-00</a>	directional valve
<a href="#">EAV-311-A15-FL9BK-00</a>	Partial 2/2-way
<a href="#">EAV-213-D18-1/8B-00 ( package 25 pcs )</a>	Solenoids
<a href="#">EAV-215-C30-1/8F-00</a>	solenoid valve
<a href="#">306879 / 150M-10/8-D1/8K</a>	90 Degree Elbow Adaptor - Male
<a href="#">300543 / 151M-12/10-3/8K</a>	Straight Adaptor - Male
<a href="#">300529 / 151M-10/8-1/8K</a>	Straight Adaptor - Male
<a href="#">301193 / 150M-12/10-3/8K</a>	90° Elbow Adaptor - Male
<a href="#">300521 / 151M-8/6-1/4K</a>	Straight screw-in V
<a href="#">361323 / 150X4M-8/6M-1/8K</a>	Angle screw-in
<a href="#">361171 / 130X4-8/6M-1/4FF</a>	
<a href="#">362390 / 154X4-10/8M</a>	T-screw connection
<a href="#">362190 / 155X4-10/8M</a>	Angle screw connection
<a href="#">301180 / 150M-10/8-1/4K</a>	90 Degree Elbow Adaptor - Male
<a href="#">EGV-111-A78-1/2FN</a>	
<a href="#">EGV-211-A79-1/2 CG / 70359190</a>	directional solenoid valve
<a href="#">EGV-211-A79-1/2CG-00 / 613052</a>	Partial 2/2-way solenoid valve
<a href="#">617112 / EGV-1027/V2-AH9-1/2CG-024</a>	2/2 solenoid valve
<a href="#">EGV-111-A78-6/4PN-00</a>	Part-2/2-way solenoid valve
<a href="#">502024</a>	O-Ring
<a href="#">L1432 EAV-213-C18-1/8F</a>	Solenoid valve
<a href="#">EGV-111-AH9-1/2BN-00</a>	Valve
<a href="#">EGV-151-Y58-3/4B0-00 24 V-DC</a>	Part-2/2-way solenoid valve
<a href="#">EGV-111-A78-1BN-00</a>	2/2 way solenoid valve
<a href="#">70001143</a>	
<a href="#">PN18/8 DN25 EGV-111Q-A78-1BN-00</a>	2/2-way solenoid valve
<a href="#">606078 EAV-217-c12-1/8B</a>	valve
<a href="#">293U-M5</a>	suppressor
<a href="#">SUC-219M-1/8-4P</a>	swing throttle check valve
<a href="#">EAV-321/05-C15-M05B-00</a>	3/2-way solenoid valve
<a href="#">EAV-321/06-C15-M05B-00</a>	3/2-way solenoid valve
<a href="#">E22-024/- -M0 720016</a>	magnetic coil
<a href="#">SUC-219M-1/8N-4P</a>	
<a href="#">EAV-221-A30-1/4BK-00</a>	solenoid valve
<a href="#">EGV-111-AH9-6/4BN-00</a>	Part-2/2-way flange-MV
<a href="#">XGV-1000-000-D50BN-04</a>	E-lock unit
<a href="#">EGV-111-A78-1 BN</a>	Valve for water
<a href="#">EGR-151-6A78-1/2BN-00</a>	Part-2/2-way solenoid valve
<a href="#">KLD20S-BD3-3/4"-SS-230V AISI316</a>	Stainless steel ball valve
<a href="#">EGV-111-A78-1/2BR-00</a>	partial 2/2 way solenoid valve
<a href="#">613693</a>	2/2-way solenoid valve
<a href="#">347616 982P-12-10</a>	

Product	Description
<a href="#">342025 930P-12-3/8</a>	
<a href="#">342022 930P-10-3/8</a>	
<a href="#">347317 955P-12</a>	
<a href="#">605052 EAV-213-A12-M05 FK</a>	
<a href="#">258210 535M-1/4</a>	
<a href="#">342018 930P-8-3/8</a>	Screw-in angle V, rotatable
<a href="#">340030 951M-16-1/2</a>	
<a href="#">EGV-111-AH9-5/4 PN-00</a>	valve
<a href="#">EGV-311Q-A78-1/2FR-00</a>	Part-2/2-way solenoid valve
<a href="#">EDV-213-A60-3/8T-00</a>	solenoid valve
<a href="#">VNR-133-M40-1/8B / PN: 635001</a>	check valve
<a href="#">E45-024/=-DZ0</a>	magnetic coil
<a href="#">337523</a>	Straight screw-in socket
<a href="#">347315</a>	Angle plug connection
<a href="#">684216 / EDV-213-A60-3/8B-00</a>	Solenoid valve
<a href="#">KFR-135-M-1/2</a>	integral filter-regulator with metal bowl
<a href="#">7024298Z</a>	Magnetic coil
<a href="#">EGV-111-A78-2BN-00</a>	2/2-way solenoid valve
<a href="#">PGV-131-B76-1 F0</a>	valve
<a href="#">ETV-S17-F30-XFF-024/=-RO</a>	3/2-way solenoid valve
<a href="#">911P3-4FF-D6</a>	Angle plug connector (PPSU)
<a href="#">911P3-6FF-D6</a>	Angle plug connector (PPSU)
<a href="#">958V-6-4FF</a>	Straight plug connection (PVDF)
<a href="#">VNR-958-P325-4FF</a>	check valve
<a href="#">951P3-6PF-1/8</a>	1/8 straight screw-in V (PPSU)
<a href="#">954P3-6-4FF</a>	T-plug connection (PPSU)
<a href="#">955V-4FF</a>	Angle plug connection (PVDF)
<a href="#">955P3-6-4FF</a>	Angle plug connection (PPSU)
<a href="#">947M-4-D6</a>	Straight connector, reduced
<a href="#">908M-8-1/4</a>	Straight screw-in socket
<a href="#">954P3-8-6FF</a>	T-plug connection (PPSU)
<a href="#">EGV-211-A79-1/2 BN</a>	2/2 way solenoid valve
<a href="#">946X4-8FF-1/4NPT-S8 / PN: 380641</a>	
<a href="#">EGV-111-B96-1/2HL 24VDC</a>	2/2-way solenoid valve
<a href="#">EGV151-Y56-6/4 B0</a>	2/2-way solenoid valve
<a href="#">EGV-111-A78-1/2PR-00 2/2</a>	2/2-way solenoid valve
<a href="#">EGV-111-A78-5/4PR-00 2/2</a>	2/2 way solenoid valve
<a href="#">626206 / PKV-131-A11-3/4B</a>	2/2-way coax valve
<a href="#">ETV-211-B25-6FF-024/=-U0</a>	2/2-way solenoid valve
<a href="#">PGV-131-B76-1BP</a>	Hard water barrier
<a href="#">70009445</a>	
<a href="#">654294 / EGR-151-1A78-1/2BR-00</a>	2/2-way solenoid valve
<a href="#">ESG-162-N-050-06h-G13 / 70365317</a>	
<a href="#">ESG-162-N-150-06h-G13 / 70365318</a>	
<a href="#">654815 - EGR-151-3CHX-3/4 CG</a>	valve

Product	Description
<a href="#">614358 / VGR-S101-2 HA</a>	check valve block
<a href="#">617771 / EGV-S103-W50-2HL-00</a>	magnetic valve
<a href="#">E30-024 / 70001143</a>	
<a href="#">384109</a>	fitting
<a href="#">PKH-214-A15-1/2T-I2-S1</a>	
<a href="#">695524 / USV-321-H50-1/8 5/2</a>	5/2-way valve
<a href="#">70395107 - EGV-311/M1-A7L-1/2BN-00</a>	Partial 2/2-way MV, 1-battery
<a href="#">618821 / EGV-121-C78-3/4BN-00</a>	Partial 2/2-way solenoid valve
<a href="#">250017 / 170M-64/0-M10x1</a>	Throw mother
<a href="#">EGV-111-Z76-1BO-00 / 70352336</a>	Partial 2/2-way MV, printed
<a href="#">613555 / EGV-111-A78-1 FN-00</a>	Partial 2/2-way solenoid valve
<a href="#">VRN-951-X440-6FF-1/4-S1</a>	check valve
<a href="#">684259 (EDV-213X5-A60-3/8P-00)</a>	Partial 2/2-way solenoid valve
<a href="#">PKH-214-A25-1T-I2-S1</a>	a pneumatic actuator
<a href="#">EGR-151-6A78-3/4BN</a>	pressure regulator unit
<a href="#">EGV-S103-X50-2HL-00 T</a>	4/4-way solenoid valve
<a href="#">720234</a>	
<a href="#">70363121</a>	Magnetic coil
<a href="#">70415412</a>	Socket
<a href="#">EGV-121-C78-3/4FN-024</a>	
<a href="#">70415956 - EGV-111-B96-3/4FP-024/=-M9</a>	Solenoid valve
<a href="#">614111 // PGV-331-B76-1/2/BO</a>	2/2-way valve, pressure-operated
<a href="#">618826 // EGV-121-C78-3/4FN-024/=-M9</a>	Partial 2/2-way solenoid valve
<a href="#">70415612 - EGV-121-C78-3/4FN-024/=-M9</a>	Partial 2/2-way solenoid valve
<a href="#">610830</a>	membrane
<a href="#">G2.335.404</a>	dosing device
<a href="#">614108</a>	VALVE
<a href="#">613726 // EGV-111-B96-3/4FP-024/=-M9</a>	Partial 2/2-way solenoid valve
<a href="#">EAV-S67-B18-M05BK-00</a>	Partial 2/2-way solenoid valve
<a href="#">MAN-114-1/8K-0/10</a>	GAUGE,PRESSURE
<a href="#">EGV-111Q-A98-1/2PT-00 / 650668</a>	solenoid valve
<a href="#">EGV-111Q-A98-1/2PP-00 / 650694</a>	solenoid valve
<a href="#">EGV-311-A7L-1/2BN-00</a>	Solenoid valve
<a href="#">232M-1/8-1/8</a>	
<a href="#">EGV-S112-X50-2HL-00 T / 617678</a>	solenoid valve
<a href="#">EGV-111-A78-1BN-00 T</a>	Partial 2/2-way solenoid valve
<a href="#">24VC E22-024/=-MO</a>	magnetic coil
<a href="#">626255</a>	valve
<a href="#">EAV-321/05-C15-M05B (609654) _</a>	
<a href="#">EAV-325/04-C15-M05B</a>	
<a href="#">PN: 450115 / FIL-151-M-3/4"</a>	Compressed air filter with metal coating
<a href="#">PN: 450125 / FIL-151-M-1</a>	Compressed air filter with metal coating
<a href="#">XGV-1000-000-D20CL-04-10</a>	P fastener
<a href="#">EFC-20-958P305-4FF</a>	
<a href="#">IPS-V36-958P3-6FF-016-51</a>	pressure sensor



Product	Description
<a href="#">367096</a>	FITTING
<a href="#">635080</a>	NON-RETURN VALVE
<a href="#">367005</a>	FITTING
<a href="#">385022</a>	FITTING
<a href="#">385025</a>	FITTING
<a href="#">EGV-111-B96-1CL-00</a>	solenoid valve
<a href="#">955V-10FF</a>	Angled plug connection (PVDF)
<a href="#">IPS-V36-958P3-6FF-004-51</a>	
<a href="#">ICS-3-958P3-6FF-200-020-U05-51</a>	conductivity sensor
<a href="#">G2.335.403</a>	dosing device
<a href="#">FSV-411-C90-1/4</a>	foot valve
<a href="#">618825</a>	EIL-2/2-way solenoid valve
<a href="#">EGV-111-B96-3/4FP-00 // 613725</a>	Partial 2/2-way solenoid valve
<a href="#">ETV-139-F40-6FF-024/=R0</a>	3/2-way solenoid valve
<a href="#">EFC-20-958P310-6FF</a>	
<a href="#">EFC-20-958P315-6FF</a>	
<a href="#">EFC-20-958P320-6FF</a>	
<a href="#">XFC-21-10-U10-51</a>	
<a href="#">XFC-21-15-U10-51</a>	
<a href="#">EGV-211-A79-1/2PN-00</a>	solenoid valve
<a href="#">EGV-121-C78-6/4BN-00</a>	
<a href="#">PKV-131-A11-1/2B</a>	2/2-way coax valve, pressurized.
<a href="#">p/n/ G 3/8, typ. 930X44M-10FF-3/8, order no. 385111</a>	elbow adaptor
<a href="#">911P-8-D10</a>	
<a href="#">911P-10-D10</a>	
<a href="#">911P-8-D8</a>	
<a href="#">958P-10</a>	
<a href="#">958P-8</a>	
<a href="#">PN: 347315 / 955P-10</a>	
<a href="#">954P-8-10</a>	
<a href="#">954P-10-8</a>	
<a href="#">605015</a>	solenoid valve
<a href="#">PGV-131-B76-5/4BN</a>	valve
<a href="#">610836 / XGV-1000-000-D20HG-04</a>	membrane
<a href="#">745000</a>	solenoid valve
<a href="#">623504/EGV-713-A79-1/2PN-00</a>	
<a href="#">959M-10 / 348715</a>	Straight screw connection
<a href="#">955P-6 / 347310</a>	Angle plug connection
<a href="#">145M-10/8-1/4 / 303130</a>	Straight bulkhead fitting also suitable for pressure gauge
<a href="#">518M-1/4 / 258018</a>	Coupling connector
<a href="#">266N-1/4x1,5 / 252926</a>	Seal ring 1/4x1,5
<a href="#">156M-10/8S-1/4N / 326638</a>	Swing screw fitting, long, 10/8S-1/4N
<a href="#">951M-6-1/8 / 340012</a>	Stright screwgland 6-1/8
<a href="#">951M-10-1/4 / 340021</a>	Straight screw fitting 10-1/4
<a href="#">XGV-1000-000-D32PO-04</a>	P-SEALING UNIT

<b>Product</b>	<b>Description</b>
<a href="#">650687</a>	solenoid valve
<a href="#">EGV-161Q-BLH-D20HL-00 / PN: 652662</a>	electrovalve
<a href="#">EGV-2009-A79-3/8-10-024/= -L0 2 (613156)</a>	
<a href="#">610891</a>	P-SEALING UNIT
<a href="#">VNR-951-P340-6FF-1/8</a>	check valve
<a href="#">AFO-958-P340-6FF</a>	shut-off valve
<a href="#">SVK-959-P340-6FF</a>	Schott Quick Release -Coupling
<a href="#">613963 / EGV-111-Z76-2PP-00</a>	magnetic valve
<a href="#">ECO 77-40FB-A1-C DN50</a>	valve
<a href="#">EAV-211-A22-1/8BK</a>	Partial 2/2-way solenoid valve
<a href="#">EAV-211-A30-1/8PK PN10/2 DN3.0 A</a>	
<a href="#">611957 / XGV-1000-000-D20HL-04-10</a>	
<a href="#">PN: 342021 / 930P-10-1/4</a>	Angle-screw-in V., rotatable
<a href="#">PN: 347114 / 958P-10-8</a>	Straight plug connection
<a href="#">PN: 347120 / 958P-16-12</a>	Straight plug connection
<a href="#">613521</a>	
<a href="#">EGV-111-Z76-1BP-00 / 613921</a>	
<a href="#">627206 / EBV-113-A40-1/4F-00</a>	Partial 2/2-way solenoid valve
<a href="#">618805</a>	solenoid valve with coil
<a href="#">TSV-311-C50-1/8 / 695111</a>	Stylus pen
<a href="#">605231</a>	plastic cap
<a href="#">IPS-V36-958P3-4FF-004-51</a>	pressure sensors
<a href="#">505212</a>	
<a href="#">610806</a>	
<a href="#">505262</a>	
<a href="#">610811</a>	