



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Comatrol

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">M16-27D-27W-DN P/N: 171113519</a>	Coil
<a href="#">27V DC 21W</a>	spule
<a href="#">CE 06-00-B P/N: 805154129</a>	Cartridge valve
<a href="#">EVH 06/D5-00-00-00</a>	Valve
<a href="#">EVH-06-C1-24V-V</a>	Solenoid Valve
<a href="#">3/2 EVH 06/D5-24C-A-00</a>	Solenoid Valve
<a href="#">EVH12/C3</a>	Cartridge Valves+Bobbin
<a href="#">EVK06/C5-F-00-00-00 (P/N: 805341519)</a>	Cartridge valve
<a href="#">VCB12-EN-3-B-00-B-XXX 820151829</a>	valve cartridge
<a href="#">C13 H 27V</a>	solenoid
<a href="#">C13 H 24 22.</a>	Solenoid Coil
<a href="#">EVH06D5 R18 84</a>	Valve
<a href="#">171146019 / M16-24D-26W-DN</a>	Coil
<a href="#">SGD4BR</a>	soft gr sd
<a href="#">171110819</a>	coil
<a href="#">NCS06/2-DG 3/8</a>	Housing
<a href="#">VDB12-EN</a>	Hydraulic Valve
<a href="#">VDB 12 N 3 B</a>	Valve
<a href="#">Model CE06/00-0</a>	Safety valve (solenoid)
<a href="#">SV10-22-01</a>	Valve
<a href="#">EVH 06/C3-220-00</a>	Solenoid Valve
<a href="#">111027158</a>	Formbohrer
<a href="#">111027159</a>	Formbohrer
<a href="#">111027161</a>	Formbohrer
<a href="#">111027160</a>	Formbohrer
<a href="#">SV08-22-01-24D-DE-B-DG2B</a>	SOLENOID VENT VALVE
<a href="#">RDP06/05-G-3 94</a>	valve (solenoid)
<a href="#">2F86-01-B-12S-E-250</a>	Solenoid Coil
<a href="#">VEN-06/EN-1-00</a>	pressure relief valve
<a href="#">171111229</a>	Coil
<a href="#">FPO50 D 3/8 - LB</a>	Solenoid Valve
<a href="#">EVH 06/D5-24D-DE-00</a>	Valve
<a href="#">SV15-23-04-24D-DE-B-00</a>	Valve
<a href="#">HSVP10-ODB-H24D-DE-PN-P-00</a>	Valve
<a href="#">800304419</a>	Pilot-Operated Check Valves
<a href="#">C13 H 24V</a>	Solenoid Coil

Product	Description
<a href="#">CP440-1-B-0-E-A-5000PSI</a>	MAX PRESSURE RATING, 10:1 PILOT RATIO
<a href="#">220-RAC-21W</a>	coil
<a href="#">CP 340-1-B-0-22</a>	Flow Divider/Combiner
<a href="#">CP 520-1-B-0-24D-S</a>	Cartridge Valves Legacy Product
<a href="#">CP440-1-B-0-E-A-150-4.5-005</a>	Counterbalance valve
<a href="#">EVH 04/EC1-W-24C-A</a>	Cartridge Valve
<a href="#">CP443-1-B-10B-E-A-10-015</a>	Cartridge Valve
<a href="#">EVH 065/C5-00-00-00</a>	Solenoid valve
<a href="#">VDP 06 / NC - E - 2</a>	Pressure sorting valve
<a href="#">RV10-POP-3EB</a>	Valve
<a href="#">M16-110A-26W-DN</a>	coil
<a href="#">SV08-22-02-00-00-B-DG2B</a>	solenoid valve
<a href="#">220VAC-RAC-26</a>	COIL
<a href="#">P/N: 805337919 Type: SVP08-NCR-00-00-B-F-00</a>	Cartridge valve
<a href="#">M13-24D-20W-DN</a>	Coil
<a href="#">RPC06-05-00</a>	PILOTED CHECK VALVE
<a href="#">CV10-NP-0.3-B-00</a>	Check Valves
<a href="#">CP100-2-B-0-015</a>	Check Valve
<a href="#">M16-220RA-22W-DN (171184419)</a>	Coils
<a href="#">M13-12D-20W-DN (171139819)</a>	Coil
<a href="#">SV08-23-01-00-00-B-00</a>	SOLENOID VALVE
<a href="#">CP722-1-B-0-080-S1 DCV</a>	CARTRIDGE
<a href="#">CP201-1-B-0-E-C-150</a>	RELIEF VALVE
<a href="#">NCS06/3-SE3-8</a>	a block
<a href="#">EVH 06/D5-12D-AS-Omit-SE3/8-V</a>	Solenoid valve
<a href="#">EDH 06/ 4308 L</a>	SOLENOID OPERATED DIRECTIONAL VALVES SPOOL TYPE
<a href="#">11735192X</a>	coil
<a href="#">SE 3/8 ( Gehäuse AL für EDH 06 )</a>	casing
<a href="#">EVH06C1 (EM22B2)</a>	Solenoid Valve
<a href="#">C70-01/02</a>	valve
<a href="#">EVM22 B1</a>	Valve
<a href="#">EDH 06/4306-00-00-00</a>	Valve
<a href="#">EDH06/4205-00-D</a>	Check Valve
<a href="#">EDH 06/4309-00-00-00</a>	Valve
<a href="#">230000370 NCS 06 4 VIE 90SH</a>	SEAL KIT
<a href="#">805313019 - EV3/4 32 A4</a>	Solenoid Valve
<a href="#">EVM22 43G1 EDH06-4309-00-00-D</a>	Solenoid Valve
<a href="#">CP100-X-B-0-005</a>	Cartridge Valves
<a href="#">CP128-1-B-0</a>	Shuttle Valves
<a href="#">18208 24VDC</a>	Coil
<a href="#">NCS 06/3 SE 1/2 (922500713)</a>	valve
<a href="#">M16-13D-26W-AS</a>	Solenoid coil
<a href="#">EVM22B2</a>	Electrovalve
<a href="#">CCSO Coil Series</a>	coil
<a href="#">M13-12D-20W-FL</a>	Coil

Product	Description
<a href="#">Spule 24VDC</a>	spool
<a href="#">800499519</a>	Solenoid Valve
<a href="#">EVH 06/C5-24C-A-00(M)</a>	Cartridge valve
<a href="#">M13-220RAC-17W-DN</a>	Coil
<a href="#">CE 06-00-V</a>	Cartridge valve
<a href="#">CE 06-00-B</a>	Cartridge valve
<a href="#">M16-12D-26W-DN P/N 17114581</a>	Coil
<a href="#">EVH 06/D5-24D</a>	SOLENOID VALVE
<a href="#">17114131 (E29B1339R012CC1)</a>	coil
<a href="#">CP440-4-B-0-E-B-XXX-5-015</a>	valve
<a href="#">VEN 06/EN-3-00</a>	Cartridge valve
<a href="#">CP211-2B-12S-E-D</a>	Valve pressure relief
<a href="#">EDH06/4205-00-00</a>	Valve
<a href="#">SEAL KIT NCS 06 4 VIE 90SH</a>	seal kit
<a href="#">EVK 06/C5-F-00-00-00</a>	Cartridge valve
<a href="#">EVH 06/C5-00-00-00 (800408519)</a>	Cartridge valve
<a href="#">NCS06/2-DG 1/2</a>	housing
<a href="#">M16-110RA-22W-DN</a>	Coil
<a href="#">M13-24D-20W-DED</a>	COIL
<a href="#">Art-no.1088010060 Typ C DIN43650</a>	AC Plug
<a href="#">171139819 / M13-12D-20W-DN</a>	Coil
<a href="#">CP210-2-B-0-E-D-300</a>	Pressure Relief Valve
<a href="#">VCD 04/EN-2-00</a>	Cartridge valve
<a href="#">171146019</a>	coil
<a href="#">HFCV10-RT-V-E-5.5-00</a>	Flow control valve
<a href="#">M16-220RA-22W-DN P/N: 171184419</a>	coil
<a href="#">SV10-34-05-24D-DN-B-00</a>	solenoid
<a href="#">17116571</a>	Solenoid Valve
<a href="#">PFC12-RC-65-24D-DN-B-00</a>	Valve
<a href="#">M16-27D-27W-ASDF250</a>	Coil
<a href="#">P/N: 171111329, Type: M19-24D-33W-DN</a>	Coil
<a href="#">DCB10-HV-3-B-1-E-100-B-SE4B p/n:11030978</a>	counterbalance valves
<a href="#">XRP 06-70-24D-DN-00-SE-6S-V</a>	proportional valve
<a href="#">XRP 06-50-24D-DN-00-SE-6S-V</a>	proportional valve
<a href="#">M13-12D-20W-DE (P/N 17114131)</a>	Coil
<a href="#">R16-24D-20W-DE-D (171183419)</a>	coil
<a href="#">NCS06/4-L 3/8</a>	Housing
<a href="#">VCB12-EN-2-A-00-B 820203319</a>	valve
<a href="#">EVK 06/A3-24A-C-DG 3/8</a>	valve
<a href="#">EVK 06/C3-24A-C-00</a>	Valve
<a href="#">EVH-04-C5</a>	hydraulic valve
<a href="#">EVH12C3-220A/C3-220A-C-00</a>	electric cartridge distributor
<a href="#">CV10-NB-0.3-B-00</a>	valve
<a href="#">CP340-1-B-0-33</a>	Pressure Relief Valve
<a href="#">VDF06-25-00B</a>	Valve

Product	Description
<a href="#">SV10-23-01-24D-DN-B-00</a>	Solenoid Valve
<a href="#">D10-16W-24D-H P/N: 320523</a>	Coil
<a href="#">CB10 AV-1-C-1-E-XXX-B-00</a>	Solenoid Valve
<a href="#">P/N: 1805159219 Type: EVK 04/A1-00-00-00</a>	2/2 way seat valve pat.
<a href="#">CP230-1-B-8S -? -? -?</a>	Pressure-Relieving Valve
<a href="#">CP460-1-B-8S-2-065-O</a>	Check Valve
<a href="#">R13-24D-16W-S</a>	Solenoid Coil
<a href="#">VEN06-EN-2-V-XXX / 1810191119</a>	Solenoid Valve
<a href="#">VEN 06-EN-2-00-V-XXX</a>	RELIEF VALVE
<a href="#">VEN 06-EN-2-00-XXX</a>	Valve
<a href="#">Type CP210-2-B-0-E-C-270</a>	Control Valve
<a href="#">EVH06/C5-DG</a>	Solenoid Valve
<a href="#">EVK06/C1-00-00-00</a>	comatrol valve
<a href="#">EDH 06/NA-00-A-DG 1/2</a>	Solenoid Valve
<a href="#">M19P-12D-1.8A-DN</a>	coil
<a href="#">M16-12D-26W-AJ</a>	coil
<a href="#">EVH-06/C3-24C-00-00</a>	cartridge valve
<a href="#">PC 06-5-OR-00</a>	CHECK VALVE PILOT R
<a href="#">NCS06/3-SE 3/8 (D)</a>	Housing
<a href="#">CP630-1-B-0-2-D</a>	valve
<a href="#">CP640-1-B-0-5-3-D</a>	Pressure Relief Valve
<a href="#">CP600-2-B-0-10-B</a>	Control Valve
<a href="#">M13-12D-20W-AS</a>	Coil
<a href="#">XMD 04-150-24C-A-00</a>	Solenoid Valve
<a href="#">CB10 HV-3-A-1-E-175-B-00</a>	Counterbalance valve
<a href="#">CB10HV-3-A-1-E-200-B-00</a>	Counterbalance Valve
<a href="#">EDH 06/4309-12C-00-00</a>	Solenoid Valve
<a href="#">CP201-1-V-0-E-C</a>	Pressure Relief Valve
<a href="#">M13-12D-20W-AS P/N: 17114111</a>	Coil
<a href="#">CP701-4-B-0-150</a>	Control Valve
<a href="#">EVH065C1</a>	valve
<a href="#">CP521-A01-B</a>	Control Valve
<a href="#">VCB 06CN-2-B-00</a>	Solenoid Valve
<a href="#">RPC04-0.5-OR-00-V</a>	Pressure Control Valve
<a href="#">VME 08-M-2-DG-3/4-XXX</a>	Solenoid Valve
<a href="#">SVP08-CDB-00-00-B-F-00/ 805335119</a>	Valve
<a href="#">171115719 / C13-27D-21W-DN (E29B1339C027CA1)</a>	COIL
<a href="#">1230000110 / NCS06/3</a>	gasket set
<a href="#">M19-12D-33W-DN</a>	coil
<a href="#">D10-16W-24D-DN</a>	coil
<a href="#">CP210-2-B-0-E-D-XXX</a>	RELIEF VALVE
<a href="#">CP720-1-B-0-080-S1</a>	DIRECTIONAL CTRL VALVE
<a href="#">CP10-4-8S</a>	VALVE BODY
<a href="#">HIC SPR-2FFLW86-D-12S-10/15-V</a>	Spreader Valves
<a href="#">RC04-0.5-00</a>	Pressure Control Valve

<b>Product</b>	<b>Description</b>
<a href="#">RPV 06-5-00</a>	Pressure Relief Valve
<a href="#">CP08-4-6S</a>	Housing
<a href="#">M13-12D-20W-DED</a>	Solenoid Coil
<a href="#">CP712-8-B-0-C-150-S4</a>	Control Valve
<a href="#">CP712-1-B-0-C-150-S2</a>	Control Valve
<a href="#">VR 06-EN-2.00-00</a>	Flow control valve
<a href="#">PSV10-34-02-00-00-??-B-00</a>	Proportional valv
<a href="#">VCB12-EN-2-A-SE??-B-XXX</a>	Valve
<a href="#">VLP 06/R0-E-00-V</a>	Logic Valve
<a href="#">SV15-22-02-24D-DN-B-12S</a>	valve
<a href="#">SV10-22-02-24D-DN-B-8S</a>	valve
<a href="#">M16-24D-26W-DN (171146019)</a>	Coil
<a href="#">M16-24D-26W-FL</a>	Cartridge Valves Coils
<a href="#">M16-110RA-22W-DN P/N 171184319</a>	solenoid
<a href="#">CP448-1-B-0-E-A-XXX-3.0-040</a>	Counterbalance Valve
<a href="#">VCB 06/CN-3-B-00</a>	Cartridge valve
<a href="#">PSVP12-NCR-00-00-B-00</a>	Proportional Valve
<a href="#">CP210-2-B-0-E-D-XXX (132227.000)</a>	valve
<a href="#">EVH 12/C1-24C-00-00</a>	Valve
<a href="#">PPRC 06-M-2-00-XXX</a>	Pressure Reducing Valve
<a href="#">M16-24D-26W-DED (17116551)</a>	coil
<a href="#">VCB12-EN-3-A-00-B-XXX</a>	Valve
<a href="#">VME 06-EN-2-00 (0995)</a>	Relief valve
<a href="#">VME 06-DG-6S</a>	Housing
<a href="#">SV10-23-01-00-00-B-00</a>	Solenoid Valve
<a href="#">DHE-0711-X-L3-00 DC</a>	Valve
<a href="#">SP-COE-12DC</a>	Coil
<a href="#">M16-12D-26W-ASD</a>	Solenoid Coil
<a href="#">SVP 08/NOR-00-00-B-F-00 (P/N 805338319)</a>	Valve
<a href="#">VCB12-CN-1-B-00-B-XX</a>	X COUNTERBALANCE
<a href="#">VCB 06/CN-3-B-00 (820153729)</a>	Valve
<a href="#">EDH 06/4205-00-00-00</a>	Valve
<a href="#">PRV10-IS2-U-C-00-00-E-V-00</a>	pressure limiter
<a href="#">PRV10-IS2-U-C-00-00-E-B-00</a>	pressure limiter
<a href="#">HSV10-22-02-H00-00-XC-P-00</a>	Solenoid valve
<a href="#">SVP10-NOR-00-00-B-F-00 (805338719)</a>	Cartridge valve
<a href="#">SDC10-2-DG3B (3/8") (922516910)</a>	Valve body
<a href="#">EVH 12/A1-24C-A-00-V</a>	SOLENOID COIL
<a href="#">D14E-24D-0-9A-DN</a>	reel
<a href="#">M16-24D-26W-DN</a>	Coil
<a href="#">RV08-DR-3-E-XXX-B-00</a>	Pressure Relief Valve
<a href="#">SVP10-NC-24D-DN-V-00</a>	Valve
<a href="#">VCB12-EN-2-A-00-B-XXX</a>	Valve
<a href="#">EVH 12/A1-24C-00-00</a>	Valve
<a href="#">SV08-22-02-00-00-B-00</a>	Solenoid Valve

Product	Description
<a href="#">SDC08-2-DG-2B</a>	Housing
<a href="#">17116571 / M13-12D-20W-DED</a>	Coil
<a href="#">VCB12-CN-2-B-00-V-XXX</a>	Valve
<a href="#">CP208-4-V-0-K-C-XXX</a>	Control Valve
<a href="#">CP102-1-B-0-005</a>	Control Valve
<a href="#">CP612-1-B-0</a>	Control Valve
<a href="#">CP200-1-B-0-E-A-010</a>	Control Valve
<a href="#">CP200-1-B-0-E-C-185</a>	Control Valve
<a href="#">CP200-1-B-0-E-A-40</a>	Control Valve
<a href="#">NCS06/3-SE-6S</a>	Solenoid Valve
<a href="#">SV08-34-04-00-00-B-00</a>	Solenoid Valve
<a href="#">SDC08-4-L2B</a>	Housing
<a href="#">CP710-1-B-0-C-050-S2</a>	Valve
<a href="#">CP200-3-B-0-A-C</a>	Valve
<a href="#">VS 06-G</a>	Shuttle valve
<a href="#">EVH 06/C3-24C</a>	Solenoid Valve
<a href="#">M16-24D-26W-AJ</a>	Coil
<a href="#">EVH 06/D5-24D-DN-00-V</a>	Valve
<a href="#">EVH 06/D5-00-00-00-V</a>	Valve
<a href="#">Type M16-24D-26W-DN</a>	coil
<a href="#">M16-24D-26W-DE</a>	Coil
<a href="#">CP702-2-B-0-000</a>	Valve
<a href="#">M16-24D-26W-AS / 171150319</a>	coil
<a href="#">SDC10-2-S8S / 11137003</a>	housing
<a href="#">VEN 06-EN-1-00-XXX</a>	Valve
<a href="#">PPRC 06-E-3-SE-1/2-XXX</a>	valve
<a href="#">SV15-22-02-12D-DE-B-00</a>	Solenoid Valve
<a href="#">VLP 12/A5-B-00</a>	Logic valve
<a href="#">CP230-1-B-SE3B-K-A-XXX</a>	Press. reducing valve
<a href="#">CP208-3-V-0-E-A-XXX</a>	Valve
<a href="#">RVE06/ME-00-B</a>	Pressure Relief Valve
<a href="#">SV04-00</a>	shuttle valve
<a href="#">M16-12D-26W-DE</a>	Solenoid Coil
<a href="#">M16-24D-26W-DN P/N 171146019</a>	Coil
<a href="#">RV10-POP-3-E-XXX-B-00</a>	Pressure Relief Valve
<a href="#">1805293819 - EVH06/C5-110A-C-HD-00</a>	Solenoid Valve
<a href="#">17116551</a>	coil
<a href="#">17116591</a>	coil
<a href="#">M13-27D-20W-DN</a>	Coil
<a href="#">SDC08-2-LG2-3B (3/8)</a>	Housing
<a href="#">M13-220RA-17W-DN</a>	Coil
<a href="#">R16-12D-20W-DE</a>	Coil
<a href="#">810219619 - ME 06-EN-3-00-0995</a>	Solenoid Valve
<a href="#">EDH 04/3201-24C-A-00</a>	valve
<a href="#">800295119</a>	Control Valve



Product	Description
<a href="#">SVP08-NCR-00-00-M-B-F-00</a>	valve
<a href="#">SVP 08/NOR-00-00-B-F-00</a>	valve
<a href="#">M13-27D-20W-DN P/N: 11104130</a>	Coil
<a href="#">805338519</a>	Cartridge valve
<a href="#">922517010/ SDC10-2-DG4B</a>	Housing
<a href="#">SDC08-2-DG3B (3/8)</a>	Housings
<a href="#">920000419</a>	Solenoid Valve
<a href="#">CB20-HV-1-A-1-E-XXX-V-00</a>	Counterbalance valve
<a href="#">CP452-2-B-0-065-S</a>	check valve
<a href="#">CP462-1-B-0-65-S</a>	check valve
<a href="#">VDP 06/NC-EN-3-00-XXX</a>	sequence valve
<a href="#">D08-16W-12D-L (321117)</a>	Coil
<a href="#">DCB10-HV-1-C-1-E-100-B-8S</a>	Counterbalance valve
<a href="#">SDC10-2-DG4B</a>	aluminum housing
<a href="#">CP710-8-B-O-080</a>	Control Valve
<a href="#">VME 06-EN-3-LG-3B-250</a>	IN-LINE PRESSURE LIMITER
<a href="#">SV10-34-11-24D-DN-B-00</a>	valve
<a href="#">SV08-23-03-00-00-B-00</a>	Solenoid Valve
<a href="#">VCB 12/EN-1-B-00</a>	Solenoid Valve
<a href="#">VCD 04/EN-1-A-00</a>	COUNTER BALANCE VALVE
<a href="#">VCD 04/EN-2-A-00</a>	Solenoid Valve
<a href="#">VR 06-E-3.00-00</a>	Valve
<a href="#">EVH 06/D5-110A-C-00</a>	Solenoid Valve
<a href="#">CP240-8-B-0-E-C-XXX</a>	Unloading Valves
<a href="#">PRMP 064-EN-1-00-XXX</a>	Pressure Reducing Valve
<a href="#">272603488</a>	PA. override rear 08 PB
<a href="#">VCD04-EN-1-00</a>	overcenter valve
<a href="#">138706</a>	Valve Priority COMATROL
<a href="#">1805154129</a>	Solenoid Valve
<a href="#">17114071</a>	Coil
<a href="#">VS 06-G (P/N: 800297919)</a>	Shuttle Valve
<a href="#">CP441-1-V-0-E-B-150-3.0-015</a>	Control Valve
<a href="#">P/N: 805813119 / SV08-23-02-00-00-B-00</a>	Solenoid Valve
<a href="#">P/N 171140019 / Coil M13-24D-20W-DN</a>	coil
<a href="#">P/N: 922518710 / Housing SDC08-3-SE-3B (3/8") P</a>	housing
<a href="#">1171112819</a>	Solenoid Valve
<a href="#">Mag. 24 Volt/26 Watt/Din connection for NCS06</a>	Solenoid Coil
<a href="#">XF250-630100-500</a>	hydraulic control unit
<a href="#">810189419/ VEN 06-EN-2-00-XXX</a>	Solenoid Valve
<a href="#">810191119/ VEN 06-EN-2-00-V-XXX</a>	Solenoid Valve
<a href="#">805315619</a>	Valve
<a href="#">PRV1-10- - S-3B-6-</a>	15 litre/min reducing valve with aluminium base
<a href="#">PRV12-10- -S-S-8T-50-</a>	45 litre/min reducing valve with steel base
<a href="#">PRV2-16- -S-S-12T-60-</a>	150 litre/min reducing valve with steel base
<a href="#">M13-110RA-18.5W-DN (171183719)</a>	



<b>Product</b>	<b>Description</b>
<a href="#">EDH6/4309</a>	Valve
<a href="#">CP410-1-B-4B-0-065</a>	
<a href="#">VRC 06-M-3.50-00</a>	Flow Control Valves
<a href="#">CP230-1-B-0-K-C-XXX</a>	
<a href="#">171149919</a>	Coil
<a href="#">CP230-1-V-0-E-C-XXX</a>	Reducing Valve