



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Daikin

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

| Product                           | Description                                  |
|-----------------------------------|--|
| <a href="#">RP15A1-22-30-T</a>    | Rotor pump                                   |
| <a href="#">DW 36 H-20</a>        |  |
| <a href="#">DW 38 H-20</a>        | Oil Distributor                              |
| <a href="#">DW-56 H-30</a>        | Oil distributor                              |
| <a href="#">U00531B06</a>         | Hydraulic unit                               |
| <a href="#">FB-4A</a>             | Lube Pump                                    |
| <a href="#">GKL-2-100</a>         |  |
| <a href="#">GKL-2-100</a>         | Daikin Cartridge Grease                      |
| <a href="#">JCAG060420</a>        | One-way valve                                |
| <a href="#">JS-G06-66CA-75</a>    | (SOLENOID VALVE)                             |
| <a href="#">5006319</a>           | compressor                                   |
| <a href="#">KSO-G03-2BB-20</a>    | Solenoid Controlled Valve                    |
| <a href="#">LRV-36A</a>           | REVERSING VALVE                              |
| <a href="#">V15A1RY-95</a>        | Hydraulic pump                               |
| <a href="#">RP15A1-22-30</a>      |  |
| <a href="#">EHU25-L04-A-30</a>    | ECO RICH                                     |
| <a href="#">1YC23HXD</a>          |  |
| <a href="#">DV-42H-20</a>         | DISTRIBUTOR VALVE                            |
| <a href="#">DV-43H-20</a>         | DISTRIBUTOR VALVE                            |
| <a href="#">DV-44</a>             | Coolant pump                                 |
| <a href="#">DW-46H-30</a>         | Valve (replaces obsolete part number DV46-H) |
| <a href="#">DV-54H-20</a>         | DISTRIBUTOR VALVE                            |
| <a href="#">DV-62H-20</a>         | Lubrication distributing valve               |
| <a href="#">MEV20BLFF6B160</a>    | solenoid control                             |
| <a href="#">KSO-G02-2AA-30</a>    | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AA-30-E</a>  | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AA-30-TR</a> | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AA-30-N</a>  | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AB-30</a>    | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AB-30-E</a>  | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AB-30-N</a>  | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AP-30</a>    | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AP-30-TR</a> | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2AP-30-N</a>  | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2BA-30-EN</a> | Solenoid-operated valve                      |
| <a href="#">KSO-G02-2BA-30-E</a>  | Solenoid-operated valve                      |

| <b>Product</b>                    | <b>Description</b>      |
|-----------------------------------|-------------------------|
| <a href="#">KSO-G02-2BA-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2BB-30-EN</a> | solenoid control valve  |
| <a href="#">KSO-G02-2BA-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2BB-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2BB-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2BB-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2BP-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2BP-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2BP-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2BP-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2CA-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2CA-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2CA-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2CB-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2CB-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2CB-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2CB-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2CP-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2cp-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2cp-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2cp-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-DA-30</a>     | Solenoid-operated valve |
| <a href="#">KSO-G02-DA-30-E</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-DA-30-TR</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-DA-30-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-2DB-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2DB-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2DB-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2DB-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2DP-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2DP-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2DP-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2DP-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2NA-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2NA-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2NA-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2NA-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2NB-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2NB-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2NP-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-2NP-30-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-2NP-30-TR</a> | Solenoid-operated valve |
| <a href="#">KSO-G02-2NP-30-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-3CA-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-3CA-30-EN</a> | Solenoid-operated valve |

| <b>Product</b>                     | <b>Description</b>      |
|------------------------------------|-------------------------|
| <a href="#">KSO-G02-3CA-30-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-3CB-30</a>     | Solenoid-operated valve |
| <a href="#">KSO-G02-3CB-30-E</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-3CP-30</a>     | Solenoid-operated valve |
| <a href="#">KSO-G02-3CP-30-E</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-3CP-30-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-3CP-30-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-4CA-30</a>     | Solenoid-operated valve |
| <a href="#">KSO-G02-4CA-30-E</a>   | Solenoid valve          |
| <a href="#">KSO-G02-4CA-30-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-4CB-30</a>     | Solenoid-operated valve |
| <a href="#">KSO-G02-4CB-30-E</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-4CB-30-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G02-4CB-30-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G02-66CA-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-66CB-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G02-66CP-30</a>    | Solenoid-operated valve |
| <a href="#">KSO-G03-20AA-20</a>    | Solenoid-operated valve |
| <a href="#">KSO-G03-20BA-20</a>    | Solenoid-operated valve |
| <a href="#">KSO-G03-20BA-20-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-20BB-20</a>    | Solenoid-operated valve |
| <a href="#">KSO-G03-20BB-20-E</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-20BP-20</a>    | Solenoid-operated valve |
| <a href="#">KSO-G03-20BP-20-EN</a> | Solenoid-operated valve |
| <a href="#">KSO-G03-20BP-20-N</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-2AA-20</a>     | Solenoid-operated valve |
| <a href="#">KSO-G03-2AB-20</a>     | Solenoid-operated valve |
| <a href="#">KSO-G03-2AB-20-E</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2BA-20</a>     | Solenoid-operated valve |
| <a href="#">KSO-G03-2BA-20-E</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2BA-20-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-2BA-20-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2BB-20-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-2BB-20-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2BP-20</a>     | Solenoid-operated valve |
| <a href="#">KSO-G03-2BP-20-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-2BP-20-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2CA-20</a>     | Solenoid-operated valve |
| <a href="#">KSO-G03-2CA-20-E</a>   |                         |
| <a href="#">KSO-G03-2CA-20-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-2CA-20-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2CB-20</a>     | Solenoid-operated valve |
| <a href="#">KSO-G03-2CB-20-EN</a>  | Solenoid-operated valve |
| <a href="#">KSO-G03-2CB-20-N</a>   | Solenoid-operated valve |
| <a href="#">KSO-G03-2CP-20</a>     | Solenoid-operated valve |

| <b>Product</b>                    | <b>Description</b>        |
|-----------------------------------|---------------------------|
| <a href="#">KSO-G03-2CP-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-2CP-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DA-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DA-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DA-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DB-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DB-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DB-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DP-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DP-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-2DP-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-3CA-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-3CB-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-3CB-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-3CP-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-3CP-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CA-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CA-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CA-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CB-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CB-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CB-20-N</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CP-20</a>    | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CP-20-E</a>  | Solenoid-operated valve   |
| <a href="#">KSO-G03-4CP-20-EN</a> | Solenoid-operated valve   |
| <a href="#">KSO-G03-66CA-20</a>   | Solenoid-operated valve   |
| <a href="#">KSO-G03-66CB-20</a>   | Solenoid-operated valve   |
| <a href="#">KSO-G03-66CP-20</a>   | Solenoid-operated valve   |
| <a href="#">KSO-G02-2CA-30-E</a>  | Solenoid-operated valve   |
| <a href="#">JM-G02-2N-20</a>      | Manual operated valve     |
| <a href="#">KSO-G02-20BA-30</a>   |                           |
| <a href="#">KSO-G02-20BA-30-N</a> |                           |
| <a href="#">KSO-G02-20BB-30</a>   |                           |
| <a href="#">KSO-G02-20BP-30</a>   |                           |
| <a href="#">KSO-G02-20BP-30-N</a> |                           |
| <a href="#">KSO-G02-2AA-30-EN</a> |                           |
| <a href="#">KSO-G02-2AP-30-EN</a> |                           |
| <a href="#">KSO-G02-2BP-30-EN</a> | valve                     |
| <a href="#">KSO-G02-2CB-30-EN</a> |                           |
| <a href="#">KSO-G02-2CP-30-EN</a> | directional control valve |
| <a href="#">KSO-G02-2DA-30</a>    |                           |
| <a href="#">KSO-G02-2DA-30-N</a>  |                           |
| <a href="#">KSO-G02-2DB-30-EN</a> |                           |
| <a href="#">KSO-G02-2DP-30-EN</a> |                           |
| <a href="#">KSO-G02-2NP-30-EN</a> |                           |

| Product   | Description                                  |
|---|--|
| <a href="#">KSO-G02-3CB-30-N</a>                            |  |
| <a href="#">KSO-G02-4CP-30</a>                              |  |
| <a href="#">KSO-G02-4CP-30-N</a>                            |  |
| <a href="#">AKZ149</a>                                      | Oil Refrigeration Unit                       |
| <a href="#">AKZ569</a>                                      | Oil Refrigeration Unit                       |
| <a href="#">AKZ909</a>                                      | Oil cooling unit                             |
| <a href="#">GKL-2-50</a>                                    | Lubmax Grease                                |
| <a href="#">LUBMAX GKL-2-100</a>                            | High Performance Grease                      |
| <a href="#">LRV-43A</a>                                     | Reversing Valve                              |
| <a href="#">M-5 (35S-30S-20T-20T)</a>                       | Distributing Valve                           |
| <a href="#">792.7040040026</a>                              | BASE CONTROLLER 1P AND HMI                   |
| <a href="#">DW 32 -H-20</a>                                 | DW 32 -H STAINLESS STEEL 1.4305              |
| <a href="#">KSO-G02-2CA-20</a>                              | knockout solenoid valve                      |
| <a href="#">LV-108C-2C</a>                                  |  |
| <a href="#">J-V23A4RX-30</a>                                |  |
| <a href="#">MT02W55</a>                                     | Valve  |
| <a href="#">SFT-06-150W</a>                                 | ELEMENT                                      |
| <a href="#">EHU25-L04-A-30-V</a>                            |  |
| <a href="#">EHU25-L04-A-V-30</a>                            |  |
| <a href="#">JQG034E12</a>                                   | Overflow valve                               |
| <a href="#">JSG064CD75X</a>                                 | Solenoid valve                               |
| <a href="#">MTC02P55</a>                                    | Throttle valve                               |
| <a href="#">MG02P255</a>                                    | Pressure reducing valve                      |
| <a href="#">KSOG024CD30</a>                                 | Solenoid valve                               |
| <a href="#">JRG02322</a>                                    | Pump   |
| <a href="#">MP-02W-20-60</a>                                | Valve  |
| <a href="#">HDINT1005</a>                                   | Valve  |
| <a href="#">EHU250740N903 - OEM</a>                         | Chiller                                      |
| <a href="#">GKL-2-100 (grease)</a>                          | Cartridge Grease                             |
| <a href="#">ERHQ014AAW1</a>                                 | Compressor                                   |
| <a href="#">GKL-2-100</a>                                   | Lubmax cartridge grease                      |
| <a href="#">LS-G02-40BP-30-EN-713</a>                       | Directional Control Valve                    |
| <a href="#">VZ80A3RX-10</a>                                 | hydraulic pump                               |
| <a href="#">J-V8A1RX-20 (6057301)</a>                       | PISTON PUMP                                  |
| <a href="#">DV48-H</a>                                      | Valve (replaces obsolete part number DV48-H) |
| <a href="#">BA-23-38-H3371</a>                              | Barrel Pump                                  |
| <a href="#">J-V15A3RX-95RC</a>                              | HYDRAULIC PUMP                               |
| <a href="#">J-V23A2RX-30</a>                                | Pump   |
| <a href="#">Oil seals(kit for J-V23A2RX-30 DAIKIN PUMP)</a> |  |
| <a href="#">LS-G02-2BP-30-EN</a>                            | operated valve                               |
| <a href="#">J-V15A3RX-30</a>                                |  |
| <a href="#">J-V15A3RX-95</a>                                | Pump   |
| <a href="#">DV-44H-30</a>                                   |  |
| <a href="#">DV-34H-30</a>                                   |  |

| Product  | Description                           |
|--|---------------------------------------|
| <a href="#">DW-48H-30</a>                            |                                       |
| <a href="#">HDFT-G10</a>                             | VALVE-THROTTLE                        |
| <a href="#">EHU3007-40</a>                           | EcoRich Power Pack                    |
| <a href="#">EHU25-M07-AE-30-V344</a>                 | Parameter settings                    |
| <a href="#">GKL-2-100S</a>                           | SINGLES (GREASE)                      |
| <a href="#">AKZ9-OP-K10</a>                          | THERMISTOR                            |
| <a href="#">332115201</a>                            | FILTER LIQ OIL FR4A/FR3B              |
| <a href="#">128810988</a>                            | Oil Filter Gasket Set                 |
| <a href="#">J-V23A4RX-30RC-X131</a>                  | pump                                  |
| <a href="#">C-KA-2A-30</a>                           |                                       |
| <a href="#">249137</a>                               | LUBRICATION SYSTEM GREASE             |
| <a href="#">KSO-GO2-66CA-30-EN</a>                   | Solenoid control valve                |
| <a href="#">DAFEHM6L0460Z</a>                        | Motor and pump for the hydraulic unit |
| <a href="#">EHU3007-40-N-902R</a>                    | HYDRAULIC UNIT                        |
| <a href="#">DW-44H-30</a>                            | Lubrication distributing valve        |
| <a href="#">AIR-EX-DFTX-50</a>                       | BRAND AIR CONDITIONING PLANT          |
| <a href="#">KSO-G02-2NA-30-EN</a>                    | Hydraulic valve                       |
| <a href="#">EHU2504-40</a>                           | Power pack                            |
| <a href="#">EHU2507-40</a>                           |                                       |
| <a href="#">EHU25-L04-A-30-127E</a>                  | -                                     |
| <a href="#">KSO-G02-2BA-30-N-CLE</a>                 | valve                                 |
| <a href="#">V15A3RX-95RC</a>                         | Pump                                  |
| <a href="#">J- KSO-G02-66CD-10</a>                   | Solenoid Valve                        |
| <a href="#">KSO-G02-2CP-30-EN</a>                    | valve                                 |
| <a href="#">LS-G02-4CP-30-EN</a>                     | Valve                                 |
| <a href="#">P/N:743195, Type: J-V23A3RX-30</a>       | hydraulic pump                        |
| <a href="#">1YC32AXD</a>                             | compressor                            |
| <a href="#">SGB-G03-1-20</a>                         | Low pressure reducing valve           |
| <a href="#">JGBC-G03-1-10</a>                        | Reducing valve with check valve       |
| <a href="#">HDRIR-G02-1</a>                          |                                       |
| <a href="#">GKL-2-040</a>                            | Grease cartridge                      |
| <a href="#">EHU2504-40-C-127</a>                     |                                       |
| <a href="#">EHU25-M07-AE-30-V344</a><br>(Parameters) |                                       |
| <a href="#">KSO-G02-2BA-10-N</a>                     |                                       |
| <a href="#">KSO-G02-2CA-10-N</a>                     |                                       |
| <a href="#">J-VZ80A4RX-20-RC</a>                     | hydraulic pump                        |
| <a href="#">MG-06P-2-11</a>                          |                                       |
| <a href="#">J-V23A3RX-3 0S1</a>                      | pump                                  |
| <a href="#">KSO-G02-2DA-30-CLE</a>                   | valve                                 |
| <a href="#">seal kit V15A1RY-85</a>                  |                                       |
| <a href="#">JT170G-P8Y1</a>                          | compressor                            |
| <a href="#">LB05F-11-N</a>                           | Manually Operated pump (LB) LUBYACE   |
| <a href="#">J-V38A3RX-95</a>                         | PISTON PUMP                           |
| <a href="#">J-V70A3RX-60</a>                         | PISTON PUMP                           |

| Product                                | Description  |
|--|--|
| <a href="#">PMMAEZ1Z2-30-3BA1-Z</a>    | lpm motor  |
| <a href="#">SUG0503-R760</a>           | Gear pump  |
| <a href="#">EHM6-M07-40-027A</a>       |  |
| <a href="#">V15A3R-95RC</a>            | PISTON PUMP  |
| <a href="#">KSO-G02-2AP-30-CLME</a>    | VALVE  |
| <a href="#">KSO-G02-2BP-30-CLME</a>    | VALVE  |
| <a href="#">KSO-G02-2DA-30-EN</a>      | Valve  |
| <a href="#">LS-G02-2DP-30-EN</a>       | Valve  |
| <a href="#">KSO-G02-2CA-30-EN</a>      | complete valve                                       |
| <a href="#">KSO-G02-4CA-30-EN</a>      | DIRECTIONAL CONTROL VALVE                            |
| <a href="#">SB-1YC32AXD</a>            | COMPRESSOR SCROLL                                    |
| <a href="#">E-DLSN-140L-B-10</a>       | Level Switch   |
| <a href="#">JV-VR80-A4R X-20-RC</a>    | pump   |
| <a href="#">KSO-G02-2BB-30-N-2T</a>    | Solenoid Valve                                       |
| <a href="#">V8A1RX-20</a>              |  |
| <a href="#">JSO-G02-2NA-20-D</a>       |  |
| <a href="#">MP-02A-20-55</a>           | PILOT OPERATED CHECK VALVE                           |
| <a href="#">KSO-G02-7CA-30-CLE</a>     |  |
| <a href="#">VD3-15A1R-95</a>           | pump   |
| <a href="#">J-VZ80A4RX-10</a>          | .  |
| <a href="#">5016694</a>                |  |
| <a href="#">RP38A2-55-30-028</a>       | PUMP, ROTOR  |
| <a href="#">FTXM35R</a>                | Daikin wall mounted unit for multisplit outdoor unit |
| <a href="#">LT0707A-10</a>             | Oil cooler   |
| <a href="#">KSO-G02-4CP-30-EN</a>      | solenoid valve                                       |
| <a href="#">V15A3RX-95</a>             | Pump   |
| <a href="#">360157P</a>                |  |
| <a href="#">5007346</a>                |  |
| <a href="#">SB-1731836</a>             | Seal Kit   |
| <a href="#">V15AIRX-95</a>             | piston pump  |
| <a href="#">RP15A1-15Y-30-T</a>        | pump   |
| <a href="#">EHM6-M07-40-028A</a>       |  |
| <a href="#">MG-02P-03-55-T-74</a>      |  |
| <a href="#">FTXG25EV1BW</a>            | Fan motor  |
| <a href="#">V15A2RX-95RC</a>           | Pump   |
| <a href="#">HSA235 400V-R410a-115v</a> | Compressor   |
| <a href="#">JT300DATFYE@N</a>          |  |
| <a href="#">KSO-G02-44CA-30-EN</a>     | Valve  |
| <a href="#">EHU30R0702-40</a>          | Hydraulic Power Pack                                 |
| <a href="#">DV-42H-30</a>              | Lubrication distributing valve                       |
| <a href="#">KSO-G03-20AB-20-E</a>      |  |
| <a href="#">RP23A1-22Y-30</a>          | rotor pump   |
| <a href="#">HDIN-T06-0</a>             | check valve  |
| <a href="#">MG-02P-1-55</a>            | valve  |
| <a href="#">MG-02B-1-55</a>            | valve  |



| Product                                 | Description  |
|---|--|
| <a href="#">MG-02A-1-55</a>             | valve  |
| <a href="#">MG-02P-1-55-T</a>           | valve  |
| <a href="#">MC-02T-05-65</a>            | valve  |
| <a href="#">BT-602-50-WY</a>            | manifold block   |
| <a href="#">BT-402-50-WY</a>            | manifold block   |
| <a href="#">MT-02W-60</a>               | Valve  |
| <a href="#">BG-02PT-55</a>              |  |
| <a href="#">MG-02A-03-55-T-76</a>       |  |
| <a href="#">BG-02AB-55</a>              |  |
| <a href="#">KSO-G02-2DA-30-E</a>        | Solenoid Valve   |
| <a href="#">DTA112B51</a>               | Multi Split Systems  |
| <a href="#">KRP928A2S</a>               | Interface Adaptor  |
| <a href="#">MQC-02A-2-55-G</a>          | RELIEF VALF  |
| <a href="#">SGR-G03-1-10</a>            |  |
| <a href="#">GKL-2-100/DL-2T</a>         | Grease   |
| <a href="#">R04089011957</a>            |  |
| <a href="#">MT-02W-50</a>               |  |
| <a href="#">193599301</a>               | Daikin McQuay 193599301 RELAY PHASE MONITOR 109-500VAC 10A/277V, 7A/30V, 8PIN SPDT |
| <a href="#">FWB15CTV</a>                |  |
| <a href="#">KS0-G02-2CP-30-N</a>        |  |
| <a href="#">JSO-G02-2CA-20</a>          | SOLENOID VALVE   |
| <a href="#">V23A3RX-30</a>              | Daikin Pump  |
| <a href="#">KSO-G03-4CP-20-CLE</a>      |  |
| <a href="#">RXYSQ12TY1</a>              |  |
| <a href="#">FXSQ40A</a>                 |  |
| <a href="#">FXSQ63A</a>                 |  |
| <a href="#">FXSQ140A</a>                |  |
| <a href="#">BRC1H52W</a>                |  |
| <a href="#">KS0-G02-4CA-30-EN</a>       | solenoid valve   |
| <a href="#">KSO-G03-4CK-20</a>          |  |
| <a href="#">10000110</a>                | Base Controller IP   |
| <a href="#">KSO-GO2-4CA-30-E</a>        |  |
| <a href="#">IT.AVV-VRV-N1</a>           |  |
| <a href="#">KHRQ22M64H</a>              |  |
| <a href="#">SOFTWARE N THE BOARD</a>    |  |
| <a href="#">AKZ439</a>                  |  |
| <a href="#">RP15A322Y-30-150</a>        |  |
| <a href="#">RXYSQ8TMY1B</a>             | Air conditioner outdoor unit   |
| <a href="#">KSO-G02-9CA-30-EN</a>       | Valve  |
| <a href="#">EHM6-M07-60-Z / 6071603</a> |  |
| <a href="#">V70A3RX-60</a>              | Pump   |
| <a href="#">AKZ569-C</a>                | Oilcooler  |
| <a href="#">5043889 / FWP05C</a>        |  |
| <a href="#">KFD-325-70-8A2(A)-869</a>   |  |

| Product                                  | Description                                       |
|--|---|
| <a href="#">Seal kit for v15a1r40</a>    |   |
| <a href="#">Seal kit for v15a1r95</a>    |   |
| <a href="#">KS0-G02-9CA-30-EN</a>        |   |
| <a href="#">MPD-04W-20-10</a>            |   |
| <a href="#">BRC4C151</a>                 | remote  |
| <a href="#">KS0-G02-2BB-30-EN</a>        | HYDRAULIC SOLENOID VALVE                          |
| <a href="#">KS0-G02-4CB-30-E</a>         | HYDRAULIC SOLENOID VALVE                          |
| <a href="#">KS0-G02-2CP-30-EN</a>        | HYDRAULIC SOLENOID VALVE                          |
| <a href="#">KS0-G02-4CP-30-E</a>         | HYDRAULIC SOLENOID VALVE                          |
| <a href="#">KS0-G02-2CA-30-E</a>         | HYDRAULIC SOLENOID VALVE                          |
| <a href="#">KSO-G02-2BA-90-N-21</a>      |   |
| <a href="#">MG-02P-1-55-P-33</a>         | Valve   |
| <a href="#">JRSS-G06-3-E2A-50</a>        | Solenoid operated relief valve                    |
| <a href="#">KSO-G03-44CA-20</a>          | Solenoid valve                                    |
| <a href="#">KSH-G04-4CA-20</a>           | Solenoid Pilot Operated Directional Control Valve |
| <a href="#">JSP-G03-2NA-40-DY</a>        | Solenoid valve                                    |
| <a href="#">MP-02W-50-55</a>             | Pilot Check Valve                                 |
| <a href="#">J-V70A2RX-60</a>             | Piston Pump                                       |
| <a href="#">JSO-G02-4CA-20</a>           |   |
| <a href="#">ECORICH EHU2504-40-C-127</a> |   |
| <a href="#">V15A1RY-95S23</a>            | Pump  |
| <a href="#">EHU30R0702-40-901</a>        |   |