



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Dittmer

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
eng-8bdit030	
eng100179	Resistance thermometer with VA
68512915	resistance thermometer
D180608083	RTD temperature probe
1846-MU-50/250 C	resistance thermometer with B head
EngD07/095757	Screw resistance thermometers
PT 100 (Ident-Nr 18802715)	Bearing resistance thermometer
Eng10076626	Clamb-temperatur sensor
1xPT100 EN60751 B (eng60751B/4/150)	Lagerwiderstandsthermometer
1xPT100 EN60751 B (eng60751B/4/250)	Lagerwiderstandsthermometer
1xPT100 EN60751 B (eng60751B/4/1100)	Lagerwiderstandsthermometer
eng3359950	1xPT100-B-2L-3359950
PT100	Temperature sensor
D150201632	Temperature sensor
1xPT100 3	conductor circuit
engD07/04199	
3044673	RESISTANCE THERMOMETER
1 x PT 100 Ohm DIN B 3-Leiter	Einsteck-Widerstandsthermometer
D18BDIT013	
68512015	Tilting pad sensor
D01/117531	
D130302450	
eng110604263	resistance thermometer
D07/074260	Immersion resistance thermometer
PT100 (D170201300)	RESISTANCE TEMPERATURE DETECTOR
PT 100 IEC751 KI.B	Temperature Sensor
eng226585	TEMPERATURE SENSOR
eng50826815	
D140910585 (2 x PT100 B 2L)	
eng101005160	Widerstandsthermometer
2 x PT100 DIN KI.A	
7.01.64.31	Ex d Fühler BVS 04 ATEX E 138 X
8.03.04.40	Einschraubverschraubung
15002	
14007	
4380331 , type 1xPT100 Ohm DIN KI. B 3-Leiter	Kleinst-Einschraub-Wth (230 Grad)

Product	Description
141112635	screw resistance thermometer
10805153	bearing sensor
10805154	bearing sensor
eng10805148	Lager-Temp.-Fühler
10805150	bed temperature. Sensor/bearing sensor
10805152	bearing sensor
10805155	bearing sensor
140404311	
D150201452	
513181900	Special resistance thermometer
eng-98812515 - OEM	Fühler
D160201332	
2 x PT100	
eng170201300	
045510	
D140404318	
10547867	
10547797	
D08/116653	Dual Element RTD
D08/116654	Dual Element RTD
1xPT100 4-Leiter (S/N 161111079)	Einschraub-Widerstandsthermometer
2xPT100DIN A 3-Leiter	
160926150001 (BVS 03 ATEX E292 X)	
D140910585	
140910585 (2 x PT100 B 2L)	
141112707 (2 x PT100 B 2L)	
3359950 (1 x PT 100 Ohm DIN B 2-Leiter)	resistance thermometer, RTD
vbn-4,29,04, 32	Widerstandsthermometer
D0403/4558	Lagerfühler
Article No. 4,36,14,11	Widerstandsthermometer
eng14149-01	Bearing temp.-detector
161111079	Einschraub-Widerstandsthermometer
10805148	bearing sensor
eng4,69-1100-2-8	Resistance thermometer
eng4,69-200-2-sg	Resistance thermometer
eng4,69-150-2-sg	Resistance thermometer
D08/074071	Screw
1xPT100 / D10/104068	Probe
100179	Resistance Thermometers
D09/031337	
68512815 / BVS 03 ATEX E292 X Ex ia	bearing sensor
1721-9	Sheathed thermocouple
68512815 /1XPT100	bearing sensor
120909093	Immersion resistance thermometer
engLV057275- 01	Resistance thermometer

Product	Description
eng101001489	sensor
4.35.04.21	Plug-in With 2 meters with fixed cable
4.95.02.22	Screw-in thermowell
D180202279	SENSOR
51.3612700.2B (eng101001489)	resistance sensor
D170100594	sensor
engD04/105751	resistance thermometer
5.045282	TEMPERATURE SENSOR WITH HEAD
68511315	Temperature Probe
68511415	Temperature Probe
eng68510915	tilting pad bearing sensor
eng 226544	Resistance thermometer
8.30.00.38en g	screw
1xFe-CuNi Typ J (D20191001)	Thermocouple
D121212239	Resistance thermometer
BVS 04 ATEX E 138 X (7.33.06.10)	sensor
Modell 4.69.01. 05	Special resistance thermometer
eng-1846-17	
1846-17 (BVS 03 ATEX E292 X)	resistance thermometer
170504108	Temperature sensor
191015078	Immersion resistance thermometer without screw connection
10805151	bearing sensor
68512115	tilting pad bearing sensor
211040	Resistance thermometer
ENG15896516	Bearing Sensor
D09/083748	Resistance Thermometer
eng9228653	
im0001724	probe
D200509351	
in-4.52.20.1 2 (2xPT100)	Resistance thermometer with VAconnection head
8.30.00.16	Movable screw-in screw connection for temperature sensors
3359950	Temperature Sensor
4.44.25.11	Resistance thermometer
4.44.25.03	Resistance thermometer version
engdi8bdit00 6	Special resistance thermometer
68513015	RESISTANCE THERMOMETER
D04/116108	Screw resistance thermometer
Art.-Nr. 4.18.04.31 Type PT100	feeler
eng68512815	
11313671- k-a	
9020001	Sensor
eng-z1383595	Resistance thermometers
eng150504539	Resistance thermometers
68511715	tilting pad bearing sensor
68511515	RESISTANCE TEMPERATURE SENSOR

Product	Description
79321815	SENSOR TEMPERATURE
68512715	SENSOR TEMPERATURE
4.15.04.11	Screw-in resistance thermometer
4.15.20.11	Screw-in resistance thermometer
eng-1846-8	Resistance thermometer with B head
D500589	Screw resistive thermometer
4.52.01.11	Resistance thermometers
4.53.04.41	Resistance thermometers
5-68450-BB0702A-14	sensor
en68450bb1681a01	Insert-in
eng684509103501	Resistance thermometers
5-68450-BB0702A-14 (as AU169721080005)	
E0700090	Sheath resistance thermometer
werkszeu30	temperature sensor
en68450bb0702a14 AU161234680005	sensor
10122-1	
10122-2	
1xPT100	TEMPERATURE SENSOR
SN 2,64,04,42	Sheath Thermocouple
eng10547866 KZ 4651600-00140-xx	bearing-temp.-sensor
eng10547951 KZ D1211160802	Bearing sensor
eng10547950 KZ D1307405602	Bearing sensor
eng10547951 KZ D1307405603	Bearing sensor
eng10547794 KZ D1308454302	bearing-temp.sensor
eng10547866 KZ D1308454303	bearing-temp.-sensor
eng10547868 KZ D1308454304	Bearing-Temperature-Sensor
eng10547950 KZ D1309484301	Bearing sensor
eng10547794 KZ 4653437-00020-xx	bearing-temp.sensor
eng10547866 KZ 4653437-00030-xx	bearing-temp.-sensor
eng10547868 KZ 4651600-00180-xx	Bearing-Temperature-Sensor
eng10547868 KZ 4653437-00080-xx	Bearing-Temperature-Sensor
eng10547794 KZ 46553437-00020-xx	
eng10547794 KZ 46553437-000100-xx	
eng10547868 KZ 46553437-00080-xx	
98812515	Resistance thermometers
eng-45112	Resistance thermometers
LV57275-01	
eng-10122-2	
eng-10122-1	Special Thermocouple
eng18801315	Special resistance thermometers
eng18802615	Bearing Resistance Thermometer NoEx
eng27521015	Bearing resistance thermometer
im6970453707	
en68450bb0945a00	Plug-in Double Thermocouple
im68450bb0945axx	Plug-in Double Thermocouple

Product	Description
94/1113479	Room temperature sensor
eng101018149	Resistance thermometers
en68450bb070 2a41	Plug-in double thermocouple with measuring insert
D170100511	Plug-in double thermocouple with measuring insert
P/N: eng310108, Type: 310108	Screw WTH
131010068	
190101159	Screw resistive thermometer
eng10547866	Bearing warm. probe
1XPT100-B-3L , P/N: D191013360	Immersion resistant thermometer
D2104052220	resistance thermometer
D131049630001	
1xPT100 3L 1/3 DIN	
Manufacture Certificate	
D200813511	Immersion resistant thermometer
D160807119	resistance thermometer
21003950	temperature sensor
D20210901	resistance thermometer
68511615	
D02/062556	Screw-in wth for gases tip perforated
Factory certificate 3.1B	Manufacture Certificate 3.1B (Test Report)
4.29.04.42 Typ 206 d	resistance thermometer
Manufacture Certificate 3.1B	Certificate
E6A1E1A1776483-EAC	Sensor
eng-p0008860 600	Bayonet screw connection with nipple M14x1 SW17
eng-10122-2 (PM0A67F14A26)	special thermocouple
eng-10122-1 (PM0A67F14A26)	special thermocouple
eng-10122-2 (PM0A67F14A18)	special thermocouple
eng-10122-1 (PM0A67F14A18)	special thermocouple
eng21003950	temperature sensor
eng2021-09-0 1	Resistance thermometer
D150606022	Sensor
BVS 03 ATEX E292 X	Immersion thermocouple head B
D150606698	Resistance thermometer with VA connection head Ø 40 mm
ATEX certificate	ATEX certificate
eng1211098	
4.91.00.72	Resistance thermometer
kali2xPT100/ 3pun	Single test certificate
eng161009092	Screw-in resistance thermometer with neck tube 115 mm
1xPT100 DIN Kl.B 4-wire	Bearing sensor
eng20220202	
D181014298	thermocouple
160302740	resistance thermometer
140302908	resistance thermometer
210100219 / 1xPT100	Bearing temp. -detector
test report 3.1	Manufacture Certificate

Product	Description
au1705489500_01	
en68450bb165_9a50	resistance thermometer
eng101015374	bearing resistance thermometer
eng101015373	sensor
eng24222815	bearing resistance thermometer
1XNiCr-Ni	Probe
1211141-G L	
210405450	resistance thermometer
11000602 Type: 1xPt100/3L DIN-B	
Type: 1xPT100-B-3L-11000602	
OEM 110807269	resistance thermometer
140708117	Tilt segment bearing sensor
68511915	Storage resistance thermometer
eng8bdt031	Immersion resistance thermometer
D120707394	Screw-in sensor with spring function.
D1123534801	Screw-in WTH
8.01.04.40	Compression fitting
101017366	
101015948	
101015069	
101003347	Tilting pad sensor
Manufacture Certificate 3.1	Manufacture Certificate
eng-11473	probes
WTH Exi G/D T3 WZ	
1 x PT100 -B-3L--1268658	screw-in
226704	Tilting pad sensor
002815	Immersion resistance thermometer with adjustable screw connection
156081	Screw-in resistance thermometer
hydro 03-03	
101001426	
150605961	Resistance thermometer with MA
1xPT100 DIN class B, 2-wire	Temperature sensor eng-005
D160605262	resistance thermometer
D160201610	
D130706826	Screw-in resistance thermometer with spring-function
eng101018445 / model: 4.69.20.06	resistance thermometer
2 x PT100 EN60751 B 3-L	Sensor
1 x PT 100 Ohm DIN Kl.B 2 - 3359950	resistance thermometer
68450bb232_7a01	
Model 4.68.00.02	
eng29011.03	
8.11.04.50	
2.35.40.42	
147591	
eng147591	

Product	Description
D221116301	Screw-in resistance thermometer
D201119693	resistance thermometer
en21079686	
D160100327	TEMPERATURE TRANSMITTER
D16102874000 1	resistance thermometer
4.99.04.31	resistance thermometer
38472	Screw-in resistance thermometer
eng-hydro03- 03	
Model 4,69,01,05	Special resistance thermometer
D1704472702	Screw-in WTH
D1115465802	Screw-in WTH by workshop number
1xPT100 4-wire	Screw-in resistance thermometer
en68450bb255 8a22	resistance thermometer
eng1100-4,8- 12	
eng1100-4,8- 12 12060 mm	
226562	
eng230100832	Screw-in resistance thermometer
engEL002815	Immersion resistance thermometer with sliding screw connection
1846-8	temperature sensor
TE 2061A	Resistance thermometer for Siemens tipping shaft bearings
TE 2061B	Resistance thermometer for Siemens tipping shaft bearings
eng-156081	
eng101011660	
eng101008493	
eng101013697	
1xPT100 Ohm DIN Kl.B 2-wire circuit	Screw-in resistance thermometer
eng000769363 34	
PT 100 Ohm DIN Kl.B 3	Screw-in resistance thermometer
eng145082	Screw-in resistance thermometer
eng14149-02	Instrument systems
1 x PT 100 / engD08/042488	
D201072720002	Temperature sensor
101003037	
101003038	
D01/010688	
1XPT100-B-4L-VENTAP6	
1XPT100-B-3L - 045510	resistance thermometer
1 x PT100 DIN B 3-wire circuit	special resistance sensor
eng1211014654	