



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Elektra Tailfingen

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
p/n: 134369 type: S1 011/HS-F3-D-RG	main emergency stop switch
D3 06-NF2-D-SS	Switch Insert
S3N 017-XN-X-XX	Switch insert
304025	Emergency Stop Switch
S1 024/HS-HF3-D-RG	emergency stop switch
S3N017-XN-X-XX OEM!!	400 V / 50 Hz
157916	Cam Switch
138502-01	cam switch
158088	MOTORSCHUTZ-EIN-AUSSCHALTER
FM 014-T7/5-B-GSX	Switch
S1 013/HS-F3-D-RG	MAIN EMERGENCY STOP SWITCH
p/n: 135014 type: S3N 013/HS-F3-D-RG	main emergency stop switch
V2NA2-F25	EIN-AUS-Schalter
V2N-F45-B-SI9	special switch, for front mounting
138502-01	Switch Component
V1D-F25-D-RG9	Custom reversing switch
141929	On-load tap changer, for front mounting
134687 // S1 024/HS-HF3-D-RG	Main emergency stop switch
613701010, type V2N HF25H-BH-SS	Switch Assembly
8.12.013	Product Identifier
184966	Switch
305421	Switch
152010	Switch
135321 (S7N 011/HS-F45-D-RG)	HAUPT-NOT-AUS-SCHALTER
32000220	Switch
D1-F15-B-S9 (OEM)	Cam Switch
FZ 014/2S-F15-B-RG (OEM)	Cam Switch
151533	switch
D2 00/HS-F35-D-RG	EMERGENCY STOP SWITCH
D3 00/HS-F35-D-RG	EMERGENCY STOP SWITCH
101000135721	control switch
142742	switch
S3N 023/HS-F35-D-RG / PN: T304759	main switch
184944	Motor protection switch
6900000040-000	Motor protection switch complete
ELE138371 V1D-F1-B-SI9,V1D 3-5	Cam Switch

Product	Description
D1WR-G2/9-B-XSX	Wendeswitcher mit O-stellung;91x97
MN Y 011-F3-B-SI	Motor protection star delta switch
FDC A2U-GU-P-SGS	Footswitch
36990009	Main switch for floor mounting
138502-01 (V1D-F25-D-RG9)	Special reverse gear switch
9003342	
142836 , 4018325506981	Pole switch insert, for floor mounting
V2N W-F2-B-SI / 142250	Reversible switch
133905	MAIN SWITCH
3504 0261 Type: D5 04/HS-F45-D-SS	switch
V2N/HS-F25-D-RG9	Special main emergency stop switch
V2N-F45-B-SI9 (143263)	Non-standard switch, for front mounting
V2N XF X XX / 143210	Special switch insert for front mounting
V2N V2-F15-B-SI	Cam Switch
V2N MA-F2-B-SI	Cam Switch
125565, Type S1 011-XF-X-XX	Switch Insert
158050	Switch
307125	Main Switch
D1 09/HS-T51/4-D-MSS	Main Switch
008682	Main switch
008683	Main switch
S1 013/HS-T8/2-D-MRG	switch
AELKV2N-LG44/3-2	switch
AELKV2N-LG44/2-1	switch
S1 015-F2-BE-RG	Emergency stop switch
310320	Main Switch
V2N S5-F1-B-SI	Cam Switch
ES1 1 1003	4-pin master switch/low voltage coil
094-000564-00050	replacement switch
06413	Circuit breaker insert
V2N S5-F1-B-SI / 141920	Cam Switch
S4N 011/HS-F3-D-RG	Main Emergency Stop Switch
188630 (S1 024-F3-B-RG)	On-off switch
142250	Reversing Switch
142878 Type: V2N Y-F15-B-SS	Switch
134 281/6.5-10 A	switch
V2N-XF-X-XX / 143077	Switch Component
Type: S1 013/HS-F3-D-RG No.: 134624	Main emergency stop switch
P/N: Type: S3N 013/HS-F3-D-SS	main switch
35008260	Switch Component
FM 014-T7/5-B-GSX / 154962	Motor protection on-off switch
P/N: 31990284, Type:	Switch Component
EM 013/KA-HF35-D-SS / 184996	on/off switch
P/N: 142250 Type: V2N W-F2-B-SI	Reversing switches
FM-XF-X-XX /158050	switch

Product	Description
p/n: 134401 type: S1 013/HS-F3-D-RG	main emergency stop switch
133054 / EMZ 024/KA/HS-F3-D-RG	motor protection main emergency stop switch
CGS1 011 516/6H-CT8/2-S-GRX	Emergency Stop Switch
FM 014-XF-X-XX / 306442	motor protection switch insert
V2N S04-KZF15-B-SI	tap changer
S3N 049A/HS-F35-D-RG (313658)	Main Emergency Stop Switch
S1 017-XF-X-XX, Best-Nr:130364	Switch Component
149523 // EM 017-XKE-X-XX	Motor protection switch off insert
143264	Star triangle insert
P/N: 154575, Type: EM 013/KA/HS-HF3-D-RG	stop switch
ES 1.1.1005	main switch
P/N: 304070, Type: S3N 021/HS-F35-D-RG	Main emergency stop switch
158016	Motor circuit breaker insert
P/N: 150801 , Type: S6N 011/HS-F4-D-RG	Main emergency stop switch
V3N-T27/9-D-MSS9	Special reversible switch
188627	Main switch
33990185	rotary load switch
F 031-F1-BE-RI / 157568	Emergency stop switch
V1D-XF-X-XX, 138354	Special switch insert
158099 / FM 014-T7/5-B-GRX	Emergency Stop Switch
149567	Switch Component
149629	Switch Component
ART00000206	Tool selector
149411	Switch
31990988	Main On-Off Switch
V2N-XF-X-XX	Special switch insert
157519	Switch
V1D-F1-B-SI8 (138331)	Selector switch
000000071220280000	Three-Phase Reversing Switch
Type: EMZ 013-XF-X-XX / 208002	motor protection switch
3.001.270	Start Switch (Star-Delta)
S7N 049A/HS-F4-D-RG	Main emergency stop switch
FM 014-XF-B-RX	Motor protection switch insert
134370	Switch
MN Y 013-LT5/5-B-MSI	switch
3.001.269	Switch Component
157955 / Type: FM 014-G2/9-B-GRX	Motor Protection Switch
55ED04	Complete switch combination
D1WR-G2/9-B-XSX9	reversible switch
V2N S8-F1-B-SI	Step switch
151562	switch
157292 /EMZ 013-XF-X-XX	Motor Protection Switch Insert
FM2-F35-D-RG	Motor Protection Switch
33990198	Main switch for front mounting
149412	Switch Component

Product	Description
Typ. S1 011/HS-HF3-D-RG No.134649	Main Emergency Stop Switch
V2N Y-F25-B-SI	Star triangle switch
008600	Main switch with undervoltage release
31991054 / FD WT-GU	Switch Component
S3N 023/HS-F35-D-RG (304759)	Main Emergency Stop Switch
FM-XF-X-XX / 311762	Motor Protection Switch Insert
31991072	Switch Component
D7 33/HS-T55/6-D-MRG	Main Emergency Stop Switch
D5 33/HS-T14/4-D-MRG	Main Emergency Stop Switch
1TZ9003-1BB23-4JB4	three-phase motor
HF 10 131760	auxiliary switch
HC 10 131765	auxiliary switch
208016	main switch
V3N A-F3-B-SI / 146258	Switch Component
159002 / MN WY 013-F4-B-SI	Motor Protection Switch
D3 00/HS-NOF35-D-SS	Main Switch for Floor Mounting
N/P: 143422 / MODEL: V2N-XF-B-SX	Special switch insert
VN 32-HF4-B-SI9 / SN 1104-3	Special switch
149523 / EM 017-XEF-X-XX	motor protection switch
V2NS33-FX-X-XX / 142005	Switch Component
V1D S38-FX-X-XX / 138332	Special Switch Insert
142790 V2N-XKE-X-XX	Special turning switch
V2N-XF-B-SX Art. Nr. 142283	Special switch insert for front mounting
1135158	Pole Switch for RASAMAX DUO (USA Version)
V3N 01/HS-HF3-D-RG	switchboard
S3N 011/HS-F3-D-RG 135 012	Main emergency stop switch
S5N 013/HS-F4-D-RG	Main emergency stop switch
T2 Schalter	switch
35000261	Switch Component
FM-T7/5-B-GSX	Motor Protection Switch
158650 / MN Y 013-F4-B-SI	Motor Protection Star-Delta Switch
S4N 023/HS-F35-D-RG Nr: 304761	Main Emergency Stop Switch
008604	switch
FM 014-F15-BE-SS / 307610	Motor protection on/off switch
115149, V2N-A2XHF-X-XX for MPR220	cam switch
158178	Switch Component
149371	Switch Component
D3 00/HS-F35-D-SS, 3300 0221	Main switch for front mounting
1234205	
138371/4018325436097 V1D-F1-B-SI9	
150143	switch
149007	
S1 013/HS-T8/2-BE-MRG/188627	coupling
Typ. S1 013/HS-F3-BE-RG	
22443 / D3 06-NF2-D-SS	

Product	Description
152503	