



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Halstrup Walcher

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
9003.00.71	PS 10 pressure sensor
9031.0064	Pressure transducer PIZ sensor
9302.0239	Helical gears
9400.0087	Special transmissions
0775150004E	Differential Pressure Transmitter
9007.0001	Digital pressure gauges
9001.0044/EMA84-10-5-1-0	portable digital pressure gauge
P26 9612.0030	Differential pressure transmitter
P 26 9612.0164	differential pressure transmitter
P29 Erdgas (Art.nr. 9614.0002)	Differential pressure transducer
PS10, 9276/347 (9003.0777) (9003.0778)	pressure sensor
PSE312-8-DP-T-0-0-54	positioning system
PSE312-8-DP-0-0	Positioniersystem
PSE 3125-VG 14 DP-0 9435.0025	Positioniersystem
P-14-0...5kPa-05-24D-5-0	Differential pressure transmitter
PUC24 (100 Pa)	Prozessüberwachungsgerät
PUC24 (250 Pa)	Prozessüberwachungsgerät
PK 11	Differenzdruckmeßumformer
9071.0818	Pressure converter
9071.3153	Druckaufnehmer P92
9276/659	Pressure Transducer
9613.0173	Differential pressure transmitter
PSE212-8-CAA-W-1 / 9421.0014	Positioniersystem
9003.0323	Drucksensor PS 10
9071.3029	differential pressure transmitter
9030	Druckaufnehmer PI-Sensor
9030.2510	Druckaufnehmer PI-Sensor
9031.0016	PIZ sensor pressure transducer
9031.0226	Druckaufnehmer PIZ-Sensor
9002	Druckaufnehmer PU-Sensor
P 92 (9071.0711)	Differential Pressure Transmitter
P 92	Druckaufnehmer
9031.	Druckaufnehmer PIZ-Sensor
9029.	Elektronisches Barometer BA1000
9003.0688	PS 10 pressure sensor
9071.1535	Druckaufnehmer P 92

Product	Description
PSE3125VG-14-CA-0 (9435.0046)	Positioning system
PS18	Differenzdruckmeßumformer
9612.0007	Differenzdruck-Messumformer P26
9071.0764 / P 92	Druckaufnehmer
9071.1281	Druckaufnehmer P 92
PS11	Differenzdruckmeßumformer
9506.0006 EC12	HIPERDRIVE HUB EC12
9030.1938	Sensor
PSE423DP (9442.0079)	Positioning system
9421.0014	Positioniersystem PSE212-8-CA-A-W-1
P/N: 9612.0752, Type: P26-4-24ACDC--10...50Pa-2-0-0-0-0	Differential pressure transmitter
9030.0784	Differential Pressure Transmitter
9604.0035	Differenzdruckmeßumformer
PSE4210-DP-DO / 9442.0073	Positioniersystem
9442.0091	Positioniersystem
9440.0105	Positioning system PSE40
9442.0082	Positioniersystem
9440.0106/PSE405DP	Positioniersystem
9442.0073/PSE4210DP	Positioniersystem
PSE328-14-EC-0-0-0-54 (9432.0389)	positioning system
PSE325-14-EI-0-0-0	positioning system
PSW305-14-PN-0-0-0	Differential Pressure Switch
HDA70-EI-L-S-S	Hiperdrive
PSE325-14-DP-T-M-O	Positioniersystem
9071.2826	Pressure transducer
9095.0059	Mobile calibration device
9071.0994	Differential Pressure Transmitter
Typ: PSE231-8-CAO-W-0	
9612.P26 (0,2%, +0,3Pa)	Differential pressure
9612.P26 (0,5%, +0,3Pa)	Differential pressure
9612.0338.P26 +/-0,2%(+0,3Pa) + LCD	Differential pressure
9612.0338 P26 (0.5%; LCD display)	Differential pressure transmitter
PS27-4-AC/DC-0...500Pa-0-0-1-S-0 (9613.0561)	differential pressure transmitter
HDA70-PN-L-S-S	engine
PSE3210-14-EL-0-0	Integrated Positioning System
9613.0117 / PS 27	Differential Pressure Transmitter
PS 10 / 9003.0114	Pressure sensor Delta_P
9071.3062 (P 92)	Differential Pressure Transducer
Differenzdruck-Messumformer P26 (9612.0042)	Differential Pressure Transmitter
9601.0002	Factory calibration certificate
PSE232-8/So-CA-O-W-0 14924 (9423.0012) OEM	Positioning system
9421.0014 Type: PSE212-8-C-A-W-1	Positioner System
9030.3069	
9373.0123	Getriebe N100/So
PSE3410-14- CA-0-M-0	engine

Product	Description
PSE3418-14-EI-0-0-0	positioning system
PS11.9079.0048	Differential Pressure
PSE 4210DP-DM	Positioning System
9440.0106 (Type: PSE405DP)	Positioning system
9003.0727	Pressure sensor
9003.0758	Pressure sensor
9030.2350	Pressure sensor
KAL200-1-2A- 1 (9609.0037)	generator
9601.0003	Calibration certificate
9079.0038	Differential pressure transducers
9003.0338 PS 10	pressure transmitter
9071.2736 KH21.012	
9431.0119	
PS 10	Differential pressure transmitter
9327.0013	reducer
9431.0224	Positioning system
9003.0338	PS 10 pressure sensor
9030.0635	Pressure transducer PI sensor
PSE335-14-IO-0-0-0	Positioning system
PSE305-14-IO-0-0-0	Positioning system
PSE423DP-R-M (9442.0092)	Positioning system
PSE4325S (9443.0114) OEM	Positioning System
9003.0765	Pressure sensor
PK15.9011.0499	Differential Pressure Transducer
PS10 / 9003.0771	Pressure sensor
PSE332 14-DP-0-M-0	Positioning system
Type P 92 LT (9071.3185)	pressure transducer
PSE232-8-CA-O-W-0	Positioning system
PSE332-14-PN-0-M-0-54	positioning system
HDA70-DP-L-B-S	Hiperdrive
9613.0421	Differential pressure transmitter PS27
9003.0720 Type PS 10	Pressure sensor
9612.0012 (P26)	differential pressure transmitter
9462.0058 / PSD428-14H-S-IO-0-65-1-0	Positioning system
9030.2350 (9030.2350)	pressure reader
9616.0007 (P34)	Differential pressure transmitter
P26 (9612.0108)	differential pressure transmitter
PSE335-14 (9433.0122) OEM	Positioning system PSE335-14-DP- 0-0-0
9030.1960	pressure transducer
PSE302-14-PN-0-0-0-54	Positioning system
9505.0007 / HDA70-I-L-H-S	Intelligent Positioning Drive
PSE4210-DP-DO	POSITIONER
PSE325-14-EI-0-0-0-54	positioning system
PSE3310-14-EI- 0-0-0-54	positioning system
PSE335-14-EI-0-0-0-54	positioning system

Product	Description
PSE3218-14-EI-0-0-0-54	positioning system
9434.0132	positioning system
9612.0303	Differential pressure transmitter P26
9434.0133	positioning system
9434.0101	positioning system
PSE405C	Positioning System
PSE335-14-DP-0-0-0-54	Positioning system
9003.0070	Pressure sensor PS 10
9031.0092	Pressure transducer PIZ sensor
Model: P92	Pressure transducer
9071.0675	Pressure transducer P 92
9614.0067 Type P29	Differential pressure transmitter
9030.3116	Pressure transducer PI-sensor
9071.1431	pressure transducer P 92
9071.3134	pressure transducer P 92
9612.0164	Differential pressure transmitter P26
P/N: 9613.0482 Type: PS27	differential pressure transmitter
P26 / 9612.0469	Differential pressure transmitter
9612.0469	Differential pressure transmitter P26
9435.0043	Positioning system
9435.0051	Positioning system
9505.0063	Intelligent Positioning System
P/N: 9003.0702, Type: PS 10	pressure sensor
P/N: 9505.0037, Type: HDA70-EC-L-S-S	Hiperdrive
P/N: 9431.0326 Type: PSE312-8-EI-0-0-0-54	positioning system
P/N: 9616.0020 Type: P34	differential pressure transmitter
9007.0003 / EMA 200-10-0	Digital pressure gauges
P/N: 9613.0522, Type: PS27-4-ZWL-0...100Pa-0-0-0	Differential Pressure Transmitter
9623.0021 / PS17-4-AC/DC-1-0-0-1-16	Differential pressure transmitter
PS 10 / 9003.0323	pressure sensor
9276/721	general purposes transmitters
HDA70-EI-L-S-S-HF / 9505.0033	Intelligent Positioning System
PSE305-8-EC-0-0-0-54 / 9430.0608	positioning system
9030.3148	differential pressure transmitter
9612.0815 / P26-4-24ACDC-0...5kPa-S-0-0-0-0	differential pressure transmitter
9612.0816 / P26-4-24ACDC-0...2.5kPa-S-0-0-0-0	differential pressure transmitter
PSE312-14-DP-0-0-0-54 / 9431.0214	positioning system
9433.0119	Positioniersystem
PS27-4-AC/DC-0-5kPa-0-1-1	differential pressure transmitter
PSE312-8-EC-0-0-N-54	positioning system
PSE322-14-SE-0-0-0-54 / 9432.0432	positioning system
9612.0164 (+/- 50 Pa)	differential pressure transmitter
9623.0260 / PS17-4-VDC-4-0-0-025-16-0	Pressure transducer
PSE312-8-PN-0-0-0-54	positioning system
9612.0709	differential pressure transmitter

Product	Description
9031.0612	Differential pressure transmitter
9613.0588	differential pressure transmitter
9612.0995	differential pressure transmitter
9002.2631	differential pressure transmitter
PSE3210-14-EI-0-M-0-54	positioning system
9030.3190	differential pressure transmitter
9612.0126	P26 differential pressure transmitter
9002.0310	pressure transducer
9002.2045	PU sensor pressure sensor
9002.0458	PU sensor pressure sensor
9030.3204	Differential pressure transmitter
9030.3017	pressure sensor
PI-4-+/-250Pa-02-24D-0-0-I (9030.2010)	pressure sensor
9613.0521	Differential pressure transmitter
9030.1752	PI-Sensor pressure sensor
9612.1078 / P26-1-24ACDC-0...250Pa-S-LC-0-0-S-I	Differential pressure transmitter
9613.0526	Differential pressure transmitter
9030.3216	Differential pressure transmitter
9612.1126 (+/- 250 Pa)	Differential pressure transmitter
9625.0014	pressure calibrator
PSE302-14-PN-0-0-N-54 (9430.0659)	positioning system
PS27 (9613.0135)	Differential pressure transmitter
9003.0781	Differential pressure transmitter
PSE312-8/So-DP-0-0-0-54	positioning system
PSE312-8-DP-0-0-0-54	positioning system
KE43093	Differential Pressure Transmitter
9623.0057	Differential pressure transmitter
9613.0222	Differential pressure transmitter
9002.2595	Differential pressure transmitter
PSE328-14-DP-0-M-0-54	positioning system
9623.0250 / PS17-4-AC/DC-+/-1mbar-0-0-1-16-0	Differential pressure transmitters
9612.1252 / P26-1-230/115-0...10Pa-2-LC-0-0-S-0	Differential pressure transmitter
PSE305-14-DP-0-0-0-54	positioning system
LA 125 / 9390.0001	linear actuator
9030.2926	pressure transducer
PSW335-14-DP-0-0-0-68	Positioning System
9612.1288	differential pressure transmitter
9616.0389	Differential pressure transmitter
9030.0043	differential pressure transmitter
9002.2678	Differential Pressure Transmitter
9612.0612	Differential Pressure Transmitter
9031.0336	PIZ sensor pressure transducer
PSE302-8-CA-0-0-0-54	positioning system
9614.0068	Natural gas differential pressure transmitter
9030.3246	differential pressure transmitter

Product	Description
9030.3212	differential pressure transmitter
9030.3174	differential pressure transmitter
PSE305-14-PN-0-0-N-54	positioning system
9462.0061	Positioning System
9460.0043	Positioning System
9430.0545	positioning system
9433.0305	positioning system
9434.0122/PSE3418-14-EI-0-0-0-65	positioning system
9030.0035	differential pressure transmitter
9433.0129 - PSE335-14-DP-0-M-0-54	positioning system
9612.1381	differential pressure transmitter
9002.2389	PU sensor pressure transducer
9461.0033 / PSD411-5V-S-IO-0-50-1-0	positioning system
9002.1998	PU sensor pressure transducer
PSD422-8V-S-PN-0-50-1-0	positioning system
9612.1106	differential pressure transmitter
9433.0109 / PSE332-14-DP-0-M-0-54	positioning system
PSE335-14-PN-0-0-0-54 / 9433.0291	positioning system
9612.1439	Differential Pressure Transmitter
9612.0003	P26 differential pressure transmitter
9505.0042	positioning system
PI-4-+/-1mbar-1-230-10-0-0 / 9030.3204	differential pressure transmitter
old code PSE3410-14- CA-0-M-0/ new code PSE3410-14- CA-0-M-0-65	Integrated Positioning System
PSD422-8V-S-PN-0-65-1-0 // 9462.0094	positioning system
9432.0357 / PSE328-14-PN-0-M-0-54	positioning system
9420.0036	PSE200/5-C-4U positioning system
KAL 84-1-1-230-D / 9095.0339	Netzun. Pressure calibrator
9030.2010 23080001	pressure transducers
9030.2010 AK091093	pressure transducers
9613.0477	differential pressure transmitter
KAL200-0A-A-1-D	Pressure calibrator
9612.0915	differential pressure transmitter
PSE3210-14-DP-0-0-0-54	Integrated positioning system for automatic format changeover in machines
9030.3143	Differential pressure transmitter
PSD401-5V-S-IO-0-50-P-0	Positioniersystem
9030.2950	PI sensor pressure transducer
PSE325-14-DP-0-M-0-54	positioning system
PSD401-5V-S-CA-0-65-1-0	Servo Drive
P34-4-10...50mbar-5-0-A-W3-l	differential pressure transmitter
9030.2878	PI sensor pressure transducer
9002.0087	Pressure transducer
PU-0-100Pa-1-24A-0-0-0 / PN: 9002.2721	Pressure transducer
9508.0045	Bus cable

Product	Description
9508.0050	Connector set
9508.0043	Power supply cable
9612.0632	Pressure Transmitter
factory calibration certificate	factory calibration certificate
9613.0376	differential pressure transmitter
9612.0585	differential pressure transducer
9432.0203 / Type: PSE3210-14-DP-0-0-0-54	positioning system
PSE305-14-PN-0-0-0-54	
9002.263 / PU-0...10mbar-1-230-0-0-0	differential pressure transmitter
PN: 9462.0100 / Type: PSD428-14H-S-PN-0-50-1-0	positioning system
KAL84-1-2-1	Pressure Calibrator