



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

# Hemomatik

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## BRAND'S PRODUCTS

Product	Description
<a href="#">HFNI-930119</a>	LIQUID LEVEL SWITCH
<a href="#">BO-10-1/2MS-160</a>	Flow Control Valve
<a href="#">BO-6-1/2MS</a>	Flow Control Valve
<a href="#">HFNI-040818</a>	Liquid Level Switch
<a href="#">HM-1000</a>	levels more then 500mm
<a href="#">LG130NO AISI 316 Rev.1</a>	Level sensor
<a href="#">HMC-OT</a>	liquid level and temperature switch
<a href="#">HMDHI-OO, O=310mm, O=410</a>	Level Switch
<a href="#">HMDHI-OT, O=300 +2, F-PA, PAC-A1</a>	Level Switch
<a href="#">HMF3-3 S=75 O=175 O=275</a>	OIL COMPARTMENT LEVEL SWITCH HIGH
<a href="#">HMF3-OO O=150 O=220mm</a>	level indikator
<a href="#">HMF3-OOTT, O=190, O=280, T60+T70</a>	level guard
<a href="#">HMF3-SOT</a>	LEVEL INDICATOR
<a href="#">HMF3-ST S=200mm</a>	level sensor
<a href="#">HMF3-V +T60</a>	temperature level switch
<a href="#">HMF3-V, V=365MM</a>	switch
<a href="#">HMF3-V, V=70MM</a>	Level Switch
<a href="#">HMF3-VT, V=200</a>	Liquid Level and Temperature Switch
<a href="#">HMF3-VV, V=145mm, V=195mm</a>	liquid level switch
<a href="#">HMF3-DHI-OO, O=200mm, O=265</a>	LEVEL SWITCH
<a href="#">HSC3/8-28-SO-K501, S=239, O=348</a>	Liquid level switch
<a href="#">HSCB-OO</a>	Level meter
<a href="#">KM18NOP8JA</a>	Capacitive sensor
<a href="#">RFS12P-2</a>	SWITCH, LEVEL
<a href="#">WDS-2500-P96-SR-U</a>	metal-bodied yarn sensor 0-10V, 2500n
<a href="#">ACP4-D1/2B-I-400</a>	sensor
<a href="#">HMF3-OO O=55 O=155mm</a>	Liquid Level Indicator
<a href="#">HMDHI-OO, O=440, O=520mm</a>	Temperature switch
<a href="#">BO-6-1/2MS-160</a>	Flow Control Valve
<a href="#">U10001)LG130NO</a>	Level sensor
<a href="#">U10002)D12x80-NO/NC-A</a>	Magnet sensor
<a href="#">U10001</a>	Level sensor
<a href="#">U10002</a>	Magnet sensor
<a href="#">HMF3-V +TS80, V=350mm</a>	Liquid Level Switch with Temperature Sensor
<a href="#">HMG3-040312 (C012796)</a>	Aqua Clean spare part
<a href="#">HMCB-VV, V=430 V=500</a>	Liquid Level Switch

Product	Description
<a href="#">HMFB-VV V=800 V=950</a>	switch liquid level.
<a href="#">HMC-OT1</a>	Liquid Level and Temperature Switch
<a href="#">R1/4" TA-A-P-5PUR</a>	Sensor Magnet
<a href="#">HM25P-A-5M</a>	Sensor Magnet
<a href="#">MFS9-N2-2</a>	Sensor Magnet
<a href="#">LAY-600-200-351-11</a>	SENSOR
<a href="#">LAY-600-002-311-11</a>	Pressure Switch
<a href="#">HMCK-O850O1000T60T70</a>	Oil level switch with temperature switch
<a href="#">MM12-S130</a>	Magnetic Switch
<a href="#">HMFB-VV V=190 mm</a>	Liquid Level Switch
<a href="#">HMFB-VV V=420 mm</a>	Level / temperature sensor
<a href="#">HMFB-VV V=520 mm</a>	Liquid Level Switch
<a href="#">HMFB-VV V=800 mm</a>	Liquid Level Switch
<a href="#">HMFB-S+1</a>	Liquid Level Switch
<a href="#">HA-15354</a>	Magnetic Switch
<a href="#">MPG9-A130</a>	Magnetic switch NO
<a href="#">M02</a>	Magnet
<a href="#">HMFB00T-O1=270/O2=335/T=80</a>	Level and Temperature Switch
<a href="#">HMCK-VVTA90</a>	Liquid level Switch
<a href="#">HMFB-S</a>	S=300mm
<a href="#">HMDHI-V</a>	Level Switch
<a href="#">HMFB-VV, V=190mm, V=280mm</a>	Liquid Level Switch
<a href="#">HMFB-VV, V=800mm, V=950mm</a>	Liquid Level Switch
<a href="#">HMFDHI-OO, O=200mm, O=265mm</a>	Liquid Level Switch
<a href="#">HMFB-VV, V=520mm, V=600mm</a>	Liquid Level Switch
<a href="#">HMFB-VV, V=420mm, V=500mm</a>	Liquid Level Switch
<a href="#">HMFB-O, O=450mm</a>	Liquid Level Switch
<a href="#">K191417</a>	Liquid Level Switch
<a href="#">HSC3/8-O-K500</a>	Float Level Switch
<a href="#">HM18P-A-5M</a>	Sensor Magnet
<a href="#">HMFB-VT, V=200mm</a>	Hydraulic Oil Level and temperature switch
<a href="#">HMFB-SOT120-100</a>	Liquid Level Switch
<a href="#">HFNI-960213</a>	Liquid Level Switch
<a href="#">HMFB-VT, V=175 mm</a>	Liquid Level and Temperature Switch
<a href="#">HMFB-OQT</a>	Liquid Level Switch
<a href="#">HFNI-100623</a>	Liquid level switch
<a href="#">HSFB-VV</a>	Liquid Level Switch
<a href="#">HMFB-3S=75 O=175 O=275</a>	Oil Compartment Level Switch (High)
<a href="#">HMFB-3 O=75 S=175 S=275</a>	OIL COMPARTMENT LEVEL SWITCH LOW
<a href="#">HMDHI-T</a>	Temperature Switch
<a href="#">HMFB-VT V=70</a>	Sensor
<a href="#">LAY-600-010-321-14 ( brass )</a>	Pressure switch
<a href="#">HMFB-OT, O=315mm</a>	Liquid Level Switch
<a href="#">LAY-600-010-321-24</a>	Pressure Switch
<a href="#">HMFB-SO</a>	Level guard

Product	Description
<a href="#">BO-2-1/4MS</a>	Flow Indicator
<a href="#">HM-EG</a>	power supply
<a href="#">HMCK-OO O=100mm O=360mm</a>	Liquid Level Switch
<a href="#">HMCK-TA90 +1, T70 L=550mm</a>	Liquid Level and Temperature Switch
<a href="#">HMCK-OO-O1 100-O2 360</a>	Liquid Level Switch
<a href="#">HMCK-TA90, L=550</a>	Liquid Level and Temperature Switch
<a href="#">HMFV-VV, V=200, V=265mm</a>	Sensor
<a href="#">HMFV-SOT S=135 O=200</a>	Level Switch
<a href="#">Level switch (999990)</a>	Level switch
<a href="#">LAY-600-010-311-11</a>	Pressure Switch
<a href="#">LAY-600-070-351-11</a>	Pressure Switch
<a href="#">HMFV-VV V= 230 V= 330</a>	Liquid Level Switch
<a href="#">HMFDHI-OO O1=150 O2=215mm</a>	LEVEL TRANSMITTER
<a href="#">HFNI-970123 (C003160)</a>	Level Sensor
<a href="#">HMFV-3 S=130 O=195 O=260</a>	Level sensor
<a href="#">HMFV-SOT, S=115, O=180mm</a>	Level and Temperature Display
<a href="#">3719000337</a>	Level+temperature display
<a href="#">HMFV-VT, V=250mm</a>	Liquid Level and Temperature Switch
<a href="#">BM-6-1/2MS</a>	flow control mechanism
<a href="#">BM-16-1/2MS</a>	flow control mechanism
<a href="#">12000497 (C013523)</a>	Level Sensor
<a href="#">HMDHI-OO, O=440, O=520</a>	Magnetic float switch
<a href="#">HMDHI-OT, O=300</a>	Liquid and temperature switch
<a href="#">HMCHI-OT</a>	LEVEL SWITCH
<a href="#">BO-16-1/2MS</a>	Flow Control Mechanism
<a href="#">HMFV-VV V210, V300mm</a>	Level switch
<a href="#">HMFV-SO +1, S=190 O=255 T=60C</a>	Liquid Level/Temperature switch
<a href="#">HMFV-SOT +1, S=190 O=255 T=60C</a>	Liquid Level/Temperature switch
<a href="#">HMDHI-OO,500mm,625mm</a>	Sensor
<a href="#">1236169, HMCK-TA90-T70 L550</a>	Temp Switch
<a href="#">1272690, HMCK-OO-O1 150-O2 550</a>	Level switch
<a href="#">HMFV-OT, O=230</a>	Level & Temperature Sensor
<a href="#">HMFV-VV, V=365, V500mm</a>	Liquid Level Switch
<a href="#">MM12-S110</a>	Magnetic sensor
<a href="#">HFNI-960126</a>	Level switch
<a href="#">HMFV-3 S=65 S=130 O=380</a>	Level indicator
<a href="#">HMFV-V, V=400, T60</a>	Liquid Level and Temperature Switch
<a href="#">HMFV-OTI20-100, O=200</a>	Level and Temperature Switch
<a href="#">HMFV-VT, V=350mm</a>	Sensor
<a href="#">HMFV-OOT-O200-O100</a>	Level and temperature switch
<a href="#">HMFV-SOT S=190 O=255</a>	Temperature/Level Probe
<a href="#">HMFV-OO +1 O=270 O=335 + T80</a>	Level/temp switch
<a href="#">HMFV-OO O=235O=300</a>	Liquid Level Switch
<a href="#">KT-50R-03-ES</a>	SENSOR
<a href="#">HMCB VV V=300 V=400</a>	Level sensor

Product	Description
<a href="#">HMFB-O, O=115mm</a>	Switch
<a href="#">HMDHI O=300 T70C+2 F-PA PAC-A1</a>	Level / temperature transmitter
<a href="#">HMFB-V, V=900mm</a>	Level Switch
<a href="#">HMDHI-OT, O=350</a>	Liquid Level and Temperature Switch
<a href="#">HM-1/8MS</a>	Float switch
<a href="#">HMFB-VT, V=150mm</a>	Liquid level and temperature switch
<a href="#">HMFB-VT</a>	Liquid level and temperature switch
<a href="#">HMFB-VV V130 V195</a>	Float switch
<a href="#">HMCHI-V, V=350mm</a>	Liquid Level Switch
<a href="#">HSFB-S, S=185</a>	Level switch
<a href="#">HSFB-S, S=120</a>	Level switch
<a href="#">HMFB-SOT S=800mm O=940mm</a>	Liquid Level and Temperature Switch
<a href="#">10 2542</a>	Tank sensor
<a href="#">HMFB-OT, O=200mm</a>	Level switch
<a href="#">HFNI-970213 oem</a>	temperature controlled liquid level sensor
<a href="#">HMFB-SOT, S=240, S=500</a>	Level Indicator
<a href="#">HSC3/8-0-K500</a>	Float level switch
<a href="#">901541</a>	Level sensor
<a href="#">HFNI-931219</a>	Liquid Level Switch
<a href="#">MM12-S210-K501</a>	MAGNETIC SWITCH
<a href="#">HM-500S</a>	LEVEL SENSOR
<a href="#">12000183</a>	Sensor for lower water distributor
<a href="#">PA-U-250-B-1-HS</a>	Level Sensor
<a href="#">HMCK-OOTTA90</a>	Level/Temperature Switch
<a href="#">HMFB-VT, V=350</a>	level relay
<a href="#">HMFDHI-OO, O=200, O=265</a>	LEVEL SWITCH
<a href="#">M5000-2</a>	Flow Meter
<a href="#">HMDHI-OO, O =270MM =O=410MM</a>	LEVEL SWITCH
<a href="#">HMDHI-V, V=300</a>	Level switch,
<a href="#">HFNI 011219/105694</a>	level switch
<a href="#">TA-EN</a>	Temperature Sensor
<a href="#">HSFB-S 150mm</a>	Level Switch
<a href="#">HMDHI-O440-O520</a>	Level Switch
<a href="#">HMFB-OS, O=75, S=275</a>	Level Indicator
<a href="#">HM5000</a>	Level Sensor
<a href="#">HMFB-SOT S=350, O=450</a>	Electrical Level Indicator
<a href="#">HSFB-S, S=150</a>	LEVEL SWITCH
<a href="#">HSFB-S, S=90</a>	LEVEL SWITCH
<a href="#">HMDHI-O385-O450</a>	Level Switch
<a href="#">HMDHI-OO</a>	Level Switch
<a href="#">HMDHI-O</a>	Level Switch
<a href="#">HMFB-SOT, S=200, O=300</a>	Electrical Level Indicator
<a href="#">HMDHI-O=350+F-MS80-G1</a>	Level Switch
<a href="#">HMDHI-O=450+ F-MS80-G1</a>	Level Switch
<a href="#">HMDHI-O=400+ F-MS80-G1</a>	Level Switch

Product	Description
<a href="#">HMDHI-O=200+ F-MS80-G1</a>	Level Switch
<a href="#">HMDHI-O=150+ F-MS80-G1</a>	Level Switch
<a href="#">HMFB-O, O=200mm</a>	Level and temp sensor
<a href="#">HMFB VV, V=60 V=300</a>	level switch
<a href="#">HMFDDHI-OO</a>	level sensor
<a href="#">HMFB-VV</a>	Level / temperature sensor
<a href="#">HMFB-V</a>	LEVEL SWITCH
<a href="#">HSC3/8-28-SO-K501, S=239, O=348mm</a>	level switch
<a href="#">CERTIFICATE OF CONFORMITY</a>	Certification Document
<a href="#">CERTIFICATE OF ORIGIN</a>	Certification Document
<a href="#">HM57-BFJ-A-5M</a>	Liquid level switch
<a href="#">HMFB-O,O=400 + T75</a>	Level and Temperature Switch
<a href="#">HSC3/8-O-K500, O=300</a>	Oil float
<a href="#">1BS/W/220</a>	Sensor Interface
<a href="#">HMFB-3T</a>	Liquid Level Switch
<a href="#">RX6/0T-3B</a>	Liquid Level Switch
<a href="#">HMFB-VV V=150 V=21</a>	Liquid Level Switch
<a href="#">HMFB-VV, V=55mm, V=100mm</a>	Liquid Level Switch
<a href="#">HSFB-SS</a>	liquid level switch
<a href="#">HMDHI-SO</a>	float level switch
<a href="#">HMFB-VT, V=300mm</a>	Liquid level and temperature switch
<a href="#">HMFB-VT, V=500mm</a>	Liquid Level and Temperature Switch
<a href="#">HM-RFS12P-2</a>	Level switch
<a href="#">HMFB-S0Ti20-100</a>	Level Indicator
<a href="#">HMDHI-V, V=179mm</a>	Level Switch
<a href="#">HFNI-980228</a>	Level Sensor
<a href="#">D10-PNPNO-5M</a>	Proximity Sensor
<a href="#">HMCHI-OT ; O=150 ; T=70C</a>	Level and Temperature Switch
<a href="#">HMDHI-V + F-MS80-G1</a>	Level Switch
<a href="#">HMFB-OQ, O=275</a>	OIL COMPARTMENT LEVEL SWITCH HIGH
<a href="#">HMFB-3</a>	Multi-Point Level Switch
<a href="#">HMCHI-OT ; O=150 ; T=70C (170 mm)</a>	Level and Temperature Switch
<a href="#">HMDHI-V, V=80</a>	Level Switch
<a href="#">HMFB-OOTT</a>	level switch
<a href="#">HSCB-O</a>	Float Level Switch
<a href="#">HMFB-VT, V=260mm</a>	Liquid Level and Temperature Switch
<a href="#">HM-IEG-TCMM</a>	Temperature Sensor
<a href="#">HFNI-090205</a>	Level Switch
<a href="#">HMFB-V, V=170mm</a>	oil level sensor
<a href="#">HMFB-OOT, O=80mm, O=160mm</a>	Liquid Level and Temperature Switch
<a href="#">HMFB-V, V=600mm</a>	Oil level switch
<a href="#">HMFB-V, V=350mm</a>	Oil level switch
<a href="#">LG130NO</a>	Level sensor (liquid)
<a href="#">HMFB-VV V=140 V=225</a>	level switch
<a href="#">HMFDDHI-OO O1=200 O2=265</a>	Dual-Point Level Switch



Product	Description
<a href="#">220314//HSCB-OO, O=204, O=313mm</a>	Float Level Switch
<a href="#">HM-1/8MS-V</a>	Float Level Switch
<a href="#">HMFB-VT (V= 300, T= 70 deg C)</a>	Liquid Level and Temperature Switch
<a href="#">HMFB-#T</a>	Liquid Level and Temperature Switch
<a href="#">HMFB V+1 T80 V=300</a>	temperature sensor
<a href="#">TKON-500-SVART</a>	Temperature Sensor
<a href="#">TSO65 // HMFB-O</a>	Level Switch
<a href="#">HMFB-T, L=900mm</a>	Level Sensor
<a href="#">HMDHI-V, V=115mm</a>	Level Switch
<a href="#">HMFB-VT, V=900mm</a>	Liquid Level and Temperature Switch
<a href="#">HMFB-SSPT100</a>	Liquid level switch and temperature sensor
<a href="#">HMFB-OO, O=200, O=260</a>	Liquid level switch
<a href="#">HMFB-OO</a>	Dual-Point Level Switch
<a href="#">HMDHI-OO, O=310mm, O=410 (3-9 pcs)</a>	Dual-Point Level Switch
<a href="#">HMDHI-OO, O=310mm, O=410 (10-24 pcs)</a>	Dual-Point Level Switch
<a href="#">HMDHI-OO, O=310mm, O=410 (25 pcs)</a>	Dual-Point Level Switch
<a href="#">HMFB-3, S=55, S=120, O=791</a>	Multi-Point Level Switch
<a href="#">HMFB-O, O=550mm</a>	Single-Point Level Switch
<a href="#">HMFB-O +2, O=550mm, T80, TSO65</a>	Level Switch with Temperature Monitoring
<a href="#">HMFB-OT, V=250mm</a>	Oil level sensor
<a href="#">HMDHI-SO S=120 O=190</a>	Dual-Point Level Switch
<a href="#">HMFB-OO, O=200mm, O=260mm</a>	Dual-Point Level Switch
<a href="#">BO3VE6/O</a>	Flow Switch
<a href="#">HMDHI-OO, O=400, O=550mm</a>	Level Switch
<a href="#">HMDHI-OO, O=270, O=410mm</a>	Level Switch
<a href="#">HM-AA020230</a>	Speed And RPM Hall Effect Sensor
<a href="#">KR-EB2P</a>	Latching Magnetic Switch
<a href="#">MPG9-A170-K360</a>	Latching magnetic switch
<a href="#">HMFB-SOTI20-100, S=300mm, O=400mm</a>	liquid level switch
<a href="#">47208</a>	magnetic switch
<a href="#">FALW/BP-1E</a>	Photoelectric Sensor
<a href="#">BO4VE16/OV</a>	Adjustable Flow Switch
<a href="#">HMFB-OO+1, O=330, O=410 + T80</a>	Dual-Point Level and Temperature Switch
<a href="#">LH11X20/OP03JF4</a>	Optical Sensor
<a href="#">HMFB-V-255</a>	FLOAT TYPE LEVEL SWITCH
<a href="#">HMFB-V=275mm</a>	FLOAT TYPE LEVEL SWITCH
<a href="#">HMFB-V=225mm</a>	FLOAT TYPE LEVEL SWITCH
<a href="#">HMDHI OO, 01=270, 02=410</a>	level switch
<a href="#">HFNI-961009</a>	LEVEL AND TEMP GAUGE
<a href="#">HMCB-VV, V=55, V=300</a>	Dual-Point Level Switch
<a href="#">HMDHI-O O=470</a>	Single-Point Level Switch
<a href="#">HMDHI-O O=150</a>	level switch
<a href="#">HMFB-O O=230</a>	level switch
<a href="#">DGE/01-0C</a>	PHOTOCELL TRANSMITTER
<a href="#">HMFB-O, O=730mm</a>	Level sensor

Product	Description
<a href="#">HM-IEG-TC1+T, (L=300 T=60°C)</a>	Level and Temperature Sensor
<a href="#">HM-IEG-TC1+T, (L=350 T=70°C)</a>	Level and Temperature Sensor
<a href="#">HMFBSST</a>	oil level sensor
<a href="#">HMC-OT1 O=280mm</a>	sensor
<a href="#">BO4VE16/A</a>	Switch
<a href="#">HMFBSOT, O=100</a>	Sensor
<a href="#">HMFBS3T, S=120, S=240, S=370</a>	Multi-Point Level Switch
<a href="#">K3/8NOP15J-HT125</a>	High-Temperature Pressure Switch
<a href="#">HMFBSOT, O=350</a>	TEMPERATURE AND LEVEL PROBE
<a href="#">HFNI-211019</a>	Level switch
<a href="#">HMF4Z0/70U</a>	Sensor
<a href="#">F-MS80-G1</a>	flange for levelswitches
<a href="#">HMFBS O+1 O=225, HM-500S</a>	Single-Point Level Switch
<a href="#">HMF4Zo/70U</a>	sensor
<a href="#">HMFBS00 = 350</a>	Single-Point Level Switch
<a href="#">HMFBS00 = 450</a>	Single-Point Level Switch
<a href="#">HMFBSVT V=140</a>	Level and Temperature Switch
<a href="#">HMFBSST, S=300mm</a>	Thermometer
<a href="#">HM-IEG-TC1, A=550</a>	Level and Temperature Sensor
<a href="#">DW-AS-703-M30-002</a>	Transducer
<a href="#">HMFBS3 S=145 ,O=245, O=345mm</a>	SWITCH,LEVEL,LOW
<a href="#">HMDHI-O=300+F-MS80-G1</a>	Single-Point Level Switch with Flange
<a href="#">HMCK-TA90 +1 T70</a>	Level and Temperature Switch
<a href="#">HMFBSOPT100</a>	Level Sensor O=450 PT100
<a href="#">HMFBSOT O-200 T-70</a>	level switch
<a href="#">HMFBSOOT, O=355 O=420</a>	Liquid and Temperature Switch
<a href="#">300-025-366-1</a>	Level Switch
<a href="#">H5FA-P100-K</a>	Float Level Switch
<a href="#">3719002956</a>	Float Level Switches
<a href="#">HMFBSVPT100</a>	Level Sensor with PT100
<a href="#">HMFBSVT, V=730mm</a>	Level and Temperature Switch
<a href="#">DW-AC-E4F-VPG9</a>	Connector
<a href="#">HMFBSOT O=175mm</a>	oil and level sensor
<a href="#">HMFSDHI-OO O=585 O=650</a>	Level switch
<a href="#">HMFBSOTO300</a>	level switch
<a href="#">HMFBSV, V=150mm</a>	
<a href="#">HMFBSVT, V=170mm</a>	Level/temperature switch
<a href="#">HMFBSOTIMINUS20-100 O=400mm</a>	Electrical level
<a href="#">HMFBSOT, O=450mm, 230VAC</a>	electrical level
<a href="#">HMFBSOTIMINUS20-100 O=450mm</a>	electrical level
<a href="#">HFNI-010529</a>	LEVEL SWITCH
<a href="#">H3FC-P-V020</a>	proximity sensor
<a href="#">AC2-D1B-I-250-CF0,43</a>	Level sensor
<a href="#">HFNI-980225</a>	Level switch