



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Italweber Elettra

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">93TRMI600-49</a>	Transformer
<a href="#">OCM032050N003</a>	TRANSFORMER
<a href="#">OCM050080N004</a>	TRANSFORMER
<a href="#">OCM064100F347</a>	Single phase transformer
<a href="#">CTCFM005000805</a>	.
<a href="#">1465012</a>	Fus
<a href="#">CFM00200CC04-I</a>	Transformer
<a href="#">CTCB16001290000</a>	BIPOLAR SWITCH
<a href="#">IPB00040EE23</a>	Transformer
<a href="#">OCM032060P272</a>	Single phase transformer approved
<a href="#">CTOCM0250307516</a>	
<a href="#">92-TRMS250-20</a>	SAFETY MONOPHASE TRANSFORMER 250VA
<a href="#">CFM000631638</a>	Single phase transformer
<a href="#">CTOCM0400709032</a>	Transformer
<a href="#">OCM025030P342</a>	Transformer
<a href="#">CTCTT0300602633</a>	3 Phase transformer
<a href="#">OTT0601204286</a>	Transformator
<a href="#">OAM0501000375</a>	Single phase auto-transformer
<a href="#">OCM0280403198</a>	
<a href="#">CTOCM032050P462</a>	Transformer
<a href="#">CFM00050CC10</a>	Single-phase transformer
<a href="#">OATC1001001131</a>	
<a href="#">CF00P152600411</a>	
<a href="#">CTOCM0400804032</a>	transformer
<a href="#">OCM0400804035</a>	
<a href="#">OCM0400804466</a>	
<a href="#">CTOCM0500803850</a>	
<a href="#">OCM0501003851</a>	
<a href="#">OCM0501003852</a>	
<a href="#">OCM050100L270</a>	
<a href="#">OCM050100R096</a>	
<a href="#">OCM0641004030</a>	
<a href="#">OCM064100M617</a>	
<a href="#">OCMC500804029</a>	
<a href="#">OCMC60060M487</a>	
<a href="#">CMS0400406689</a>	Single-phase safety transformer

Product	Description
<a href="#">OTTC1001000849</a>	
<a href="#">CCM040060M291</a>	
<a href="#">OCMC60070F348</a>	Trasf. OCM
<a href="#">OTT0400600252</a>	transformer
<a href="#">CTCFM00160CC09</a>	Transformer
<a href="#">OCM0500806890</a>	
<a href="#">CTOMX3206001226</a>	
<a href="#">2923310275L</a>	transformer
<a href="#">CTOCM0250300488</a>	single-phase transformer
<a href="#">OCM0320507652</a>	Transformer
<a href="#">OM X02202502052</a>	
<a href="#">OAM028300899</a>	Transformer
<a href="#">CFM001004048</a>	Transformer
<a href="#">CFM001K05708</a>	Transformer
<a href="#">CFM003K0L977</a>	Transformer
<a href="#">OCM0220309965</a>	
<a href="#">OTTC1001501042</a>	Three phase Control Transformers in box approved
<a href="#">OTTC1001721100</a>	Three phase Control Transformers in box approved
<a href="#">CTOCM040050N638</a>	electrical transformer
<a href="#">CTOCM050100M593</a>	transformer
<a href="#">CTCFM000302178</a>	
<a href="#">OMX02204001366</a>	
<a href="#">CFM001K29671</a>	
<a href="#">OCM040080P776</a>	Voltage transformer
<a href="#">CT OCM0250301024</a>	Transformer
<a href="#">CFM005201828</a>	
<a href="#">CTCFM001K0CC07</a>	Single phase Isolating Transformer
<a href="#">OMX03205002073</a>	
<a href="#">OMX05008002074</a>	
<a href="#">CFM006006516</a>	
<a href="#">OCM025030L536</a>	
<a href="#">CTOMT0320601988</a>	Transformer
<a href="#">OMX0220250AA07</a>	Isolation Transformer
<a href="#">CTABM005000015</a>	TRANSFORMER
<a href="#">Z90774002738</a>	transformer
<a href="#">CFM00500L892</a>	
<a href="#">CTOCM064150F582</a>	TRANSFORMER
<a href="#">OCMC60120P526</a>	TRANSFORMER
<a href="#">OCM064080F581</a>	TRANSFORMER
<a href="#">CFM00050L525</a>	Transformer
<a href="#">CFM00250CC08- I</a>	
<a href="#">FRIEND80-1T</a>	
<a href="#">CTOCM0500603048</a>	transformer
<a href="#">AFT005K02095</a>	Three phase Autotransformer
<a href="#">AFT001K52096</a>	Three phase Autotransformer

Product	Description
<a href="#">AFT002K32097</a>	Three phase Autotransformer
<a href="#">AFT003K02098</a>	Three phase Autotransformer
<a href="#">AFT005K02100</a>	Three phase Autotransformer
<a href="#">AFT010K02101</a>	Three phase Autotransformer
<a href="#">CFM006309626</a>	Single Phase Safety and insulating Transformer
<a href="#">OMT032040EE02</a>	
<a href="#">OCM040080N569</a>	
<a href="#">CFM001K6CC15</a>	TRANSFORMER
<a href="#">CFM00080M194</a>	TRANSFORMER
<a href="#">CFM00100H462</a>	
<a href="#">OMT0320602026</a>	
<a href="#">OCM0220306419</a>	transformer
<a href="#">OCM0500808178</a>	
<a href="#">OCM025030P415</a>	TRASFORMER
<a href="#">CFM00250N480</a>	Transformer
<a href="#">CTCSB20-00540</a>	Bipolar line switch
<a href="#">CFM00030H970</a>	transformer
<a href="#">CFM000458639</a>	
<a href="#">353/528027</a>	
<a href="#">IESFM00100CC04</a>	transformer
<a href="#">OMX03206001780</a>	Transformer
<a href="#">CCM040040F693</a>	Transformer
<a href="#">CCM050080F691</a>	Transformer
<a href="#">CTOCM032040F344</a>	TRANSFORMER
<a href="#">CTOCM064100F773</a>	APPROVED SINGLE-PHASE ISOLATION TRANSFORMER
<a href="#">OCM032060P660</a>	Transformer
<a href="#">OAT0601203038</a>	
<a href="#">CTCFM00150H732</a>	
<a href="#">OCM025030BB02</a>	
<a href="#">CTCFM002004902</a>	
<a href="#">777/ATT30K/027</a>	
<a href="#">OCM028030S269CTOCM028030S269</a>	
<a href="#">CFM001006790</a>	
<a href="#">OCM032060BB02</a>	
<a href="#">91ATRM2K5-2</a>	
<a href="#">AFT012K51260</a>	
<a href="#">OCM064100S325</a>	
<a href="#">CFM00400CC15-I</a>	transformer
<a href="#">CFM001600610</a>	Trasforme
<a href="#">CFM00630L909</a>	
<a href="#">CFT002K05610</a>	
<a href="#">OCM0320605141</a>	
<a href="#">CTCFM001009418</a>	trasformatore
<a href="#">OCM032060R506</a>	
<a href="#">OAT0400751090</a>	AUTOTRANSFORMER

Product	Description
<a href="#">OCM0641003950</a>	TRANSFORMER
<a href="#">OTT0500801787</a>	THREE PHASE TRANSFORMER
<a href="#">91ATRM500-8</a>	
<a href="#">OCM040080L606</a>	
<a href="#">CBM001K6CC08</a>	
<a href="#">OCM0320508176</a>	
<a href="#">CFM003K78599</a>	Transformer
<a href="#">OCM040080N006</a>	SINGLE PHASE CONTROL TRASFORMER
<a href="#">SFM00063CC04</a>	
<a href="#">CFM00050BB02</a>	
<a href="#">OMX0500800CC07</a>	TV1 component
<a href="#">OMT0640642117</a>	transformer
<a href="#">OMX0500800CC02</a>	TV2 component
<a href="#">CTOCM0641002238</a>	
<a href="#">OIM000090050138</a>	
<a href="#">CMA001000010</a>	
<a href="#">CTOCM032050M266</a>	
<a href="#">CTCBM000250238</a>	
<a href="#">CFM000151340</a>	
<a href="#">CTOAT0230401630</a>	3 phase transformer
<a href="#">0TA0230401630</a>	
<a href="#">CTOCM0501003030</a>	transformer
<a href="#">CTAFT003K0CC</a>	three-phase auto transformer
<a href="#">CTOMX2503501178</a>	
<a href="#">CTOCM032040S674</a>	
<a href="#">CTOMT0250302039</a>	
<a href="#">CTOMX0400500226</a>	SINGLE-PHASE SAFETY CONTROL TRANSFORMER
<a href="#">CTCIMAV1</a>	
<a href="#">CTOF000P1003018</a>	
<a href="#">CTOATC07K901190</a>	
<a href="#">CT371/TT6K/043</a>	
<a href="#">OCM064080F346</a>	TRANSFORMER
<a href="#">CT93TRMI2K5-4</a>	
<a href="#">CTOCM050080F345</a>	TRANSFORMER
<a href="#">CTOAM0250400978</a>	TRANSFORMER
<a href="#">CTCF3P150750959</a>	
<a href="#">CTIPB00100CC12</a>	Single-phase transformer
<a href="#">CTOCM032050N637</a>	
<a href="#">CTOCM028030S511</a>	
<a href="#">CTCFM001K0H733</a>	
<a href="#">CTOTT0600803273</a>	
<a href="#">CTSTCYBED190339</a>	
<a href="#">CT92TRMS063-39</a>	
<a href="#">CTCFM001808992</a>	TRANSFORMER
<a href="#">CTOATC500901849</a>	TRANSFORMER

Product	Description
<a href="#">CTOCMC70120R608</a>	
<a href="#">IW1421000</a>	FUSE
<a href="#">CTCFM001007148</a>	transformer
<a href="#">CTOCM050100M566</a>	transformer
<a href="#">CTCMS022030F166</a>	Transformer
<a href="#">CTOCMC60060M351</a>	
<a href="#">CTCFM003K07786</a>	
<a href="#">CTCF5P150600957</a>	
<a href="#">CTCF6P310370958</a>	
<a href="#">CTCF8P450400955</a>	
<a href="#">CTCF10P30300956</a>	
<a href="#">CTCCM0280408146</a>	transformer
<a href="#">CT353/528027 (CFM 50VA)</a>	transformer
<a href="#">CT353/528027 / CFM 50VA P=230/400V S=24V MAMMUT</a>	SINGLE PHASE SAFETY TRANSFORMER
<a href="#">CTAFT0115K0295</a>	
<a href="#">CT777/ATT30K003</a>	autotransformer
<a href="#">CTOAM0501000911</a>	
<a href="#">CTIM00260120114</a>	
<a href="#">CTOCMC60060P011</a>	
<a href="#">OCM040050N611</a>	
<a href="#">OMX04007001947</a>	
<a href="#">OCM0320400206</a>	
<a href="#">OIM000140050139</a>	electrical ballast
<a href="#">CTCCM005000341</a>	transformer
<a href="#">CTOCM032050R901</a>	transformer
<a href="#">CTOCM0400500434</a>	
<a href="#">CTOTT0701004121</a>	Three-phase transformer
<a href="#">OCM0320404893</a>	
<a href="#">OTT0400506252</a>	
<a href="#">CTOCMC50080M128</a>	transformer
<a href="#">CTCFM00060T242</a>	TRANSFORMER
<a href="#">CTCFM00100CC02-</a>	SINGLE-PHASE TRANSFORMER
<a href="#">CB16001290000</a>	
<a href="#">CTCFM00100CC04</a>	SINGLE-PHASE TRANSFORMER
<a href="#">CTOMX0220400108</a>	
<a href="#">OCM0500803850</a>	
<a href="#">CTCFM00400CC15</a>	
<a href="#">CBM00400CC09</a>	
<a href="#">92TRMS030-18</a>	
<a href="#">CTOCM0320606003</a>	
<a href="#">CTOCMC600601794</a>	
<a href="#">CTOMX0250403451</a>	Transformer
<a href="#">CFM006305279</a>	
<a href="#">CFM002004638</a>	
<a href="#">CTCFM001K06503</a>	

Product	Description
<a href="#">CTCFM001K0BB01</a>	transformer
<a href="#">CTCFM00450BB07</a>	transformer
<a href="#">CFM001K0CC15</a>	
<a href="#">OCM064150S562</a>	
<a href="#">CTOTT800801584</a>	
<a href="#">CTOTT0800803503</a>	
<a href="#">CTSTCTBED180313</a>	
<a href="#">CTKIT-STAB</a>	
<a href="#">CTAFM003000508</a>	
<a href="#">CTCBM000360755</a>	
<a href="#">CTOMX2804001469</a>	Single-phase transformer
<a href="#">CTOCM022030T979</a>	Primary Transformer
<a href="#">CTCFM00500CC07 -R</a>	TRANSFORMER 500VA
<a href="#">CTCFM00100CC04-I</a>	Transformer
<a href="#">CTOTT0300503990</a>	
<a href="#">CT353/528048</a>	
<a href="#">CTOCM0400601674</a>	Transformer
<a href="#">CTOCM050080M409</a>	
<a href="#">CTCFM002K03589</a>	Voltage Transformer
<a href="#">CTOCM040070S309</a>	mono phase transformer
<a href="#">CTCFM00100L340</a>	control transformer
<a href="#">CTCFM004001742</a>	
<a href="#">CTCFM000631754</a>	
<a href="#">CTOCM064130CC11</a>	
<a href="#">CTAFT006K32719</a>	transformer
<a href="#">CTCFM001008004</a>	Power Supply Transformer
<a href="#">IP44 610X460X720 R</a>	HOMOLOG CASE. HOME
<a href="#">IP44 450X360X620 R</a>	HOMOLOG CASE.
<a href="#">CTOCM050060F718</a>	
<a href="#">OCM0500809553</a>	
<a href="#">CTCFM00100CC12</a>	
<a href="#">CTCFM001504039</a>	
<a href="#">CTOTT0601202717</a>	
<a href="#">CTCFM00500CC15-</a>	
<a href="#">CTOTT0700805762</a>	
<a href="#">CFM00050CC04-I</a>	
<a href="#">CTOCM032050M723</a>	
<a href="#">CTOIM0000900501138</a>	Single-Phase Inductor
<a href="#">CTOIM0090050138</a>	Single Phase Inductor