



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Laumas

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">ALL3</a>	SINGLE-POINT LOAD CELL
<a href="#">AM150</a>	AM 150Kg SINGLE-POINT LOAD CELL 400x400mm ALLUMINIUM IP65 OIML R60 C3
<a href="#">AZL50 C3</a>	SINGLE-POINT LOAD CELL
<a href="#">FCAX 500Kg</a>	
<a href="#">FUN6141T1T</a>	load cell
<a href="#">MODEL W100</a>	WEIGHT INDICATOR
<a href="#">2E1262CC00, FTL1000 (FTL 1.000Kg SHEAR BEAM LOAD CELL STAINLESS STEEL 17-4 PH IP68 OIML R60 C3)</a>	LOAD CELL
<a href="#">JOLLYTLB485</a>	
<a href="#">JOLLYW100</a>	WEIGHT INDICATOR
<a href="#">MODEL TLB RS485 ±</a>	WEIGHT TRANSMITTER
<a href="#">AM60</a>	SINGLE-POINT LOAD CELL
<a href="#">FTK1000</a>	FTK 1.000Kg SHEAR BEAM LOAD CELL
<a href="#">WT60BASE</a>	WEIGHT INDICATOR MODEL WT60000 BASE
<a href="#">CX10000L</a>	CELLA CX 10.000 KG
<a href="#">EXCX</a>	
<a href="#">FTL300</a>	SHEAR BEAM LOAD CELL
<a href="#">FTL500</a>	SHEAR BEAM LOAD CELL
<a href="#">FTL2000</a>	SHEAR BEAM LOAD CELL
<a href="#">FCOL20</a>	
<a href="#">CTOL5000</a>	Standardaufnehmer
<a href="#">CTOL2500</a>	Standardaufnehmer
<a href="#">CTOL1000</a>	Standardaufnehmer
<a href="#">CTOL500</a>	load cell
<a href="#">CTOL50</a>	Standardaufnehmer
<a href="#">P1250INOXN</a>	PLATFORM
<a href="#">WL60.000 3 Products</a>	WEIGHING AND BATCHING SYSTEMS
<a href="#">CBLS-750t (CBLS 750000)</a>	Load Cell
<a href="#">WT60/4-20MA</a>	WEIGHT INDICATOR
<a href="#">CBLxxx</a>	Load cell
<a href="#">AZL10</a>	SINGLE-POINT LOAD CELL
<a href="#">EM6DADO</a>	ALLOY STEEL JOINT
<a href="#">CBL5000</a>	COMPRESSION LOAD CELL
<a href="#">TLB PROF1</a>	DIGITAL WEIGHT TRANSMITTER
<a href="#">PWS6CC24</a>	WEIGHT INDICATOR

Product	Description
<a href="#">CTL5000</a>	
<a href="#">CX 30000 kg</a>	
<a href="#">PRC-6kg</a>	LOAD CELL
<a href="#">CBL7500</a>	Compression Load Cell
<a href="#">SW100/ANA</a>	Weight indicator
<a href="#">V10000</a>	MOUNTING ACCESSORY
<a href="#">V10275</a>	
<a href="#">JOLLYTLBSERCOS</a>	
<a href="#">AM200</a>	load cell
<a href="#">CE41ATEX</a>	
<a href="#">TLBPROFINETIO</a>	
<a href="#">W200BOXBP</a>	
<a href="#">CTOL100</a>	
<a href="#">CTOL200</a>	Tension/compression load cell
<a href="#">SA15</a>	LOAD CELL
<a href="#">SA60</a>	Load Cell
<a href="#">AZL15</a>	
<a href="#">ALL10</a>	
<a href="#">AZS200</a>	
<a href="#">PRC6</a>	
<a href="#">Mod. TLB</a>	TRANSMITTER
<a href="#">Mod. CBL 10.000</a>	LOADCELL
<a href="#">FCAX1000</a>	Load cell
<a href="#">CE41-INOXP</a>	Junction Box
<a href="#">JOLLYW100ANA</a>	Load cell indicator
<a href="#">FCOL350</a>	
<a href="#">FTP500</a>	load cell
<a href="#">CBL2500</a>	Compression Load Cell
<a href="#">FTP1000</a>	LOADCELL
<a href="#">CBL1000</a>	Compression load cell
<a href="#">APL200</a>	LOADCELL
<a href="#">SA30</a>	Tensioner Type LOADCELL 30Kg
<a href="#">WINOXRBP</a>	INDICATOR
<a href="#">SL300</a>	CELL
<a href="#">OPZW1ANALOGICA</a>	ANALOG OUTPUT
<a href="#">JOLLYTPS</a>	TRANSPONDER
<a href="#">WL60 14 PRODUCTS</a>	Weight indicator
<a href="#">FTL1000</a>	Load cell
<a href="#">TLB RS485</a>	Transmitter
<a href="#">CX</a>	Load cell
<a href="#">CX15000L</a>	Cell
<a href="#">W200</a>	weight indicator
<a href="#">TLB4RS485</a>	
<a href="#">CBL500</a>	Load cell
<a href="#">OPZW1PNETIOW200</a>	

Product	Description
<a href="#">TLB4PROFINETIO</a>	
<a href="#">AZL100</a>	Load Cell
<a href="#">AZL50</a>	Load Cell
<a href="#">W100/ANA</a>	Weight indicator
<a href="#">WT60000</a>	Weight indicator WT60000 0-10 V
<a href="#">AIN30</a>	
<a href="#">FCAX300</a>	BENDING BEAM AND SHEAR LOAD CELLS
<a href="#">C41N</a>	Junction box
<a href="#">AZLI50</a>	LOAD CELL
<a href="#">AZLI100</a>	LOAD CELL
<a href="#">CTL100</a>	LOAD CELL
<a href="#">102470</a>	LOAD CELL
<a href="#">102420</a>	Load cell
<a href="#">102240</a>	
<a href="#">APL500</a>	Load Cell
<a href="#">100302</a>	
<a href="#">CL10000KG</a>	load cells
<a href="#">CL60000KG</a>	load cells
<a href="#">CL5000KG</a>	load cells
<a href="#">JOLLYTLBPROFINETION</a>	WEIGHT TRANSMITTER
<a href="#">W100</a>	Weight Indicator
<a href="#">TLB485</a>	RS485 serial port
<a href="#">TLBCANOPEN</a>	digital weight transmitter
<a href="#">1002112 / TLB</a>	DMS evaluation electronics
<a href="#">PRC-30</a>	SINGLE-POINT LOAD CELL
<a href="#">1012351 / AZL10</a>	platform load cell