



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Luyang Gear Motor

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">J220-200-18-A54</a>	
<a href="#">J220-200-18-A-G2 (UL certified)</a>	Gear Motor
<a href="#">J220-200-18-AT54-G1</a>	GEAR MOTOR
<a href="#">J220V18-300-21.4-A old model number</a>	
<a href="#">J220-200-17-S7-G2</a>	MOTOR 3 PHASE
<a href="#">EA-016-004-00</a>	capacitor
<a href="#">5GU60KB</a>	GEARBOX
<a href="#">D12GU90-1800</a>	DCMOTOR
<a href="#">J220-200-20-A-G3</a>	gear motor
<a href="#">J220-200-18-A-G3 (A000)</a>	gear motor
<a href="#">4IK25RGN-C(BX1)</a>	Speed control Motor
<a href="#">SS22</a>	Separated Speed Controller 1 Phase
<a href="#">2IK6GN-A</a>	AC Motor
<a href="#">J220-200-18-A-G1</a>	Gear motor
<a href="#">J220-200-15-U1T54-G3</a>	GEAR MOTOR
<a href="#">J220V18-300-21.4-A</a>	GEAR MOTOR
<a href="#">J220-200-15-U1T54(B1)-G3</a>	Gear Motor
<a href="#">UJ230-200-15-A(A007)</a>	Gear Motor
<a href="#">J220-200-15-CE2-G3</a>	Gear motor
<a href="#">J220-200-18-A-G3</a>	GEAR MOTOR
<a href="#">J220V18-300-21.4-A(P1)</a>	gear motor
<a href="#">2IK6GN-A(D1)</a>	motor
<a href="#">GN5KG(D1)</a>	
<a href="#">EA-018-003-00</a>	Capacitor
<a href="#">J220-200-17-CE1-G2</a>	Gear Motor
<a href="#">J220V18-300-21.4-A(G1)</a>	GEAR MOTOR
<a href="#">J220V18-300-21.4-AT54-G3</a>	gear motor
<a href="#">UJ230L16-200-15-A(A002)</a>	Gear Motor
<a href="#">J220-200-18-AT(A088)-G3</a>	GEAR MOTOR
<a href="#">5IK40GN-U4(A000)</a>	AC motor
<a href="#">4GN180K</a>	Gear Box
<a href="#">UJ230V18-200-21.4-A-G3</a>	motor
<a href="#">J220V18-100-15-A(A150)-G</a>	gear motor
<a href="#">UJ230L16-200-15-A(A002)(UL certified)</a>	gearmotor
<a href="#">UK04IK25GN-PTA</a>	MOTOR
<a href="#">J220-200-15-CE2T54-G3</a>	Gearmotor

Product	Description
<a href="#">J220L16-200-18-A-G2</a>	Gear motor
<a href="#">UJ230L16-200-15-A(A002)-G4</a>	
<a href="#">5IK60GN-AF</a>	AC MOTOR
<a href="#">J220V18-200-20-C(A125)-G1</a>	gear motor
<a href="#">4IK25GN-U</a>	AC MOTOR
<a href="#">J220V18-300-21.4-A(P1)-G3 (G3TL)</a>	
<a href="#">J220V18-300-21.4-A(P1)-G3 (G3TR)</a>	
<a href="#">J230V18-200-15-A</a>	GEAR MOTOR
<a href="#">ULH22-200-20-HP</a>	
<a href="#">J230V18-200-20-A(A005)</a>	GEAR MOTOR
<a href="#">J220-200-15-U1T54(B1)-G1</a>	
<a href="#">5GN30K</a>	GEAR BOX
<a href="#">51K150GU-STF(A146)</a>	Motor
<a href="#">5GU10K(BDS1)</a>	Gear Box
<a href="#">5IK40A-S</a>	
<a href="#">J220-200-17-CE1(B1)-G2</a>	
<a href="#">J220-200-10-U3</a>	
<a href="#">J220-200-18-A-G2</a>	Gear Motor
<a href="#">J220-200-18-C-G2</a>	gear motor
<a href="#">J220-200-18-U2T-G2</a>	GEAR MOTOR
<a href="#">J230V18-100-15-A(A000)</a>	Gear motor
<a href="#">J230V18-200-20-C(A046)</a>	Gear Motor
<a href="#">J220-200-10-CE1</a>	Gear Motor
<a href="#">4IK25RGN-CT(BTX1)</a>	Gear Motor
<a href="#">4GN30K</a>	Gear box
<a href="#">4IK25GN-ST(B1)</a>	motor
<a href="#">J220-200-15-CE1T(A043)-G3</a>	Gear Motor
<a href="#">LV18-200-18-ACM</a>	gear motor
<a href="#">J220V18-300-21.4-A(P1)-G1</a>	Gear motor
<a href="#">J220V18-200-20-S4(A000)</a>	gear motor
<a href="#">J220-200-18-CE2T-G1</a>	gear motor
<a href="#">41K25RGN-C</a>	motor
<a href="#">4GN18K</a>	Gearbox
<a href="#">D12GU90-1800(A003)</a>	DC motor
<a href="#">4GN180</a>	gear box
<a href="#">4IK25GN-U3 (A042)</a>	Motor
<a href="#">J220-200-15-UT-G3</a>	gear motor
<a href="#">5IK60GN-UF</a>	AC MOTOR
<a href="#">LH18-200-3-S3</a>	Gear Motor
<a href="#">J220-200-25-A CE</a>	
<a href="#">J220-200-25-A UL</a>	
<a href="#">5IK60GU-UF</a>	AC motor
<a href="#">5GU200KB(P1)</a>	gear motor
<a href="#">LH18-200-7.5-S3</a>	
<a href="#">4GN90K</a>	GEAR BOX

Product	Description
<a href="#">4IK25GN-S3</a>	AC MOTOR
<a href="#">SB32-IN</a>	Electronic Instantaneous Barke , for single pahse 220V
<a href="#">SB31-IN</a>	Electronic Instantaneous Barke
<a href="#">ULH28-750-20-H</a>	GEAR MOTOR
<a href="#">J220-200-18-AT-G3</a>	Gear Motor
<a href="#">J220-200-10-U3-G2</a>	GEAR MOTOR
<a href="#">J220-200-10-A-G3</a>	GEAR MOTOR
<a href="#">5GN30(A357)</a>	
<a href="#">5GN20</a>	GEAR BOX
<a href="#">5GN20(A**)</a>	
<a href="#">4IK25GN-S</a>	AC motor
<a href="#">5IK90GU-UF</a>	MOTOR
<a href="#">5GU3KB</a>	REDUCER
<a href="#">4IK25GN-S6(A068)</a>	AC MOTOR
<a href="#">J220-200-18-S0</a>	Gear Motor
<a href="#">J220V18-300-21.4-A(PS1)-G 3</a>	GEAR MOTOR
<a href="#">5IK60GU-U3E</a>	Motor
<a href="#">LV18-200-20-AC(A260)</a>	gear motor
<a href="#">J230V18-200-20-S3(A**)</a>	Motor
<a href="#">J220V18-100-15-A(A150)-G</a>	GEAR MOTOR
<a href="#">J230V15-200-10-A(A059)</a>	
<a href="#">J230V18-200-15-C(A000)</a>	GEAR MOTOR
<a href="#">J230V18-200-15-S3M(A**)</a>	
<a href="#">4GN15K</a>	Gear Box
<a href="#">LH28-400-30-S3+</a>	gear motor
<a href="#">J220-200-15-C-G3</a>	Gear Motor
<a href="#">J220-200-18-CE2</a>	
<a href="#">UJ230-200-15-A(A007)-G3</a>	
<a href="#">J220V15-100-15-C(A135)-G1</a>	
<a href="#">4IK25GN-UT(A041)</a>	AC Motor
<a href="#">LV18-400-5-S3</a>	Gear motor
<a href="#">5IK90GU-CETF</a>	INDUCTION MOTOR
<a href="#">5GU36KB</a>	Gear Box
<a href="#">UK05RK120GU-CE6E</a>	Ac Motor
<a href="#">M590-002E</a>	
<a href="#">J220-200-15-U1T54 (B1)</a>	GEAR MOTOR
<a href="#">BJ-A00-003-00</a>	Terminal Box-Front Cover
<a href="#">5GU30KB(A372)</a>	GEAR BOX.
<a href="#">5GU100KB</a>	Gear Box
<a href="#">5IK90GU-S3MF</a>	AC Motor
<a href="#">J220V18-200-15-C(A**)</a>	gear motor
<a href="#">LV22-750-10-S3(A079)</a>	GEAR MOTOR
<a href="#">4IK25GN-S(F2)</a>	AC Motor
<a href="#">LV40-2200-10-S2</a>	Gear motor
<a href="#">J220V18-200-20-S3(A152)</a>	Gear Motor

Product	Description
<a href="#">5IK60GN-S3F</a>	AC motor
<a href="#">J220L16-200-15-A-G1</a>	
<a href="#">UJ230L16-200-15-A(A002) - G1</a>	Gear Motor
<a href="#">J220V18-200-21.4-A(A067) -G1</a>	
<a href="#">J220V18-300-21.4-A (A012) G3</a>	GEAR MOTOR
<a href="#">J220V18-300-21.4-A(P1)-G3</a>	gear motor
<a href="#">LH28-750-5-S5</a>	gear motor
<a href="#">J220-200-25-A-G3</a>	
<a href="#">J220-200-18-C-G3</a>	gearmotor
<a href="#">UJ230V16-200-18-A-G2</a>	Gear motor
<a href="#">LV28-750-10-S3(A1)</a>	Gear motor
<a href="#">LH18-200-15-S3</a>	gear motor
<a href="#">J220-200-15-U3T54(A010)-G1</a>	Gea motor
<a href="#">LH32-200-3600-S3</a>	Gear motor
<a href="#">UJ230V18-200-21.4-AT54-G3</a>	200W , $\psi$ 18-V type , 1 Phase
<a href="#">J220-200-18-S5-G3</a>	
<a href="#">J230V15-100-15-C(A***)</a>	Gear Motor
<a href="#">LH18-200-10-S3</a>	Gear Motor
<a href="#">UJ230V18-200-21.4-A-G4</a>	
<a href="#">J220-200-15-CE2-G2</a>	Gear Motor
<a href="#">LH22-200-200-S3</a>	GEAR MOTOR
<a href="#">31K15GN-C</a>	AC motor
<a href="#">LV32-1500-10-S3</a>	
<a href="#">3GN75K</a>	Gear Box
<a href="#">M590-702TF</a>	AC Motor
<a href="#">5GA10KR</a>	Gear box
<a href="#">J220-200-15-CE1T-G3</a>	Gear motor
<a href="#">UJ230L16-200-15-A(A002)(G2)</a>	
<a href="#">UJ230V16-200-15-A-G3</a>	
<a href="#">J220-200-15-CT (A080)</a>	Gear motor
<a href="#">J230V18-200-15-C(A247)</a>	
<a href="#">5RK150GU-SMT(BFT1)</a>	AC Motor
<a href="#">4IK25GN-C(A085)</a>	AC Motor
<a href="#">5GN9K</a>	GEAR BOX
<a href="#">J220V18-200-20-S3M(A000)</a>	Gear Motor
<a href="#">J220-200-18-S-G3</a>	Gear motor
<a href="#">5IK150GU-STF</a>	
<a href="#">J220-200-18-CE2T-G3</a>	Gear motor
<a href="#">J220-200-18-A-G4</a>	
<a href="#">UJ230L16-200-15-A(A002) G3</a>	
<a href="#">51K40GN-58</a>	
<a href="#">LH28-200-200-S3(A162)</a>	
<a href="#">LV18-200-15-S3(S3)</a>	gear motor
<a href="#">4IK25GN</a>	
<a href="#">J230L16-200-10-C(A049)-G1</a>	Gear motor

Product	Description
<a href="#">CP10-410</a>	
<a href="#">LV18-200-25-ACM (A025)</a>	motor w/ brake
<a href="#">UX206-01</a>	Digital Speed Controller
<a href="#">Bearing for CP10-410</a>	
<a href="#">SHAFT SEAL for CP10-410</a>	
<a href="#">O-RING for CP10-410</a>	
<a href="#">MOTOR ROTOR for CP10-410</a>	
<a href="#">SHEEVE for CP10-410</a>	
<a href="#">VANE for CP10-410</a>	
<a href="#">SEPARATOR GASKET for CP10-410</a>	
<a href="#">EXHAUST FILTER for CP10-410</a>	
<a href="#">SORING for CP10-410</a>	
<a href="#">SEAL for CP10-410</a>	
<a href="#">RUBBER GASKET for CP10-410</a>	
<a href="#">SORING SCREW for CP10-410</a>	
<a href="#">J230V16-200-18-A(G1)</a>	
<a href="#">J230V16-200-18-A(G2)</a>	
<a href="#">5GN25K</a>	
<a href="#">5IK40RGN-CEFF</a>	
<a href="#">3GN6K</a>	GEAR BOX
<a href="#">M315-401(A039) 15W</a>	AC MOTOR
<a href="#">LV22B-400-10-S3</a>	gear motor
<a href="#">S001 / UK05IK90GU-HFMTAF</a>	
<a href="#">S001 / UK05IK90GU-PFMTAF</a>	
<a href="#">LV22-400-30-AV(T1)</a>	
<a href="#">J230V18-200-20-A(A006)</a>	
<a href="#">LH32-1500-5-S6</a>	
<a href="#">5IK60RGN-AF(BRX1)</a>	Induction Motor
<a href="#">Capacitor for J230V16-200-18-A(G1)</a>	
<a href="#">S001 (4GN Type)</a>	GEAR BOX
<a href="#">5GN60K</a>	Gear Reducer
<a href="#">J220-200-12.5-U1MT54(A114 )-G1</a>	Motor
<a href="#">J220V18-100-15-A(A150)-G2</a>	
<a href="#">3IK15GN-U2TI(A010)</a>	
<a href="#">J230V18-300-21.4-A(P1)</a>	
<a href="#">LH22-400-30-S3</a>	Motor
<a href="#">M590-501F</a>	AC MOTOR
<a href="#">LV18-200-10-S3(A255)</a>	geared motor
<a href="#">ULV32-750-90-ACAV</a>	GEAR MOTOR
<a href="#">LH28-750-20-HP(A008)</a>	Motor
<a href="#">Type J220-200-18-CE2T-G2</a>	gear motor
<a href="#">Type J220-200-18-CE2T-G1</a>	gear motor
<a href="#">J220V18-300-21.4-A(G2)</a>	GEAR MOTOR
<a href="#">capacitor for J220V18-300-21.4-A (A012) G3</a>	
<a href="#">J220-200-15-UT54(A076)-G</a>	gear motor

Product	Description
<a href="#">5IK90GU-S4E</a>	
<a href="#">J220-200-10-A-G1</a>	GEAR MOTOR
<a href="#">J220-200-10-A-G2</a>	
<a href="#">LH22-200-90-S6</a>	gearmotor
<a href="#">LV18-200-15-S3 (A199)</a>	
<a href="#">4IK25RGN-CET(BFT1)</a>	AC MOTOR