



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Marzoc

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### hiBRAND'MiSA POD

McUCTdz	AordcauzaUt
<a href="#">1P- D92 DG DDM9 G 0LDMG 34</a>	Valve
<a href="#">GRGOGDNOMGN T 1P- 4DT8 DN DD99 G 1ofA 8flach</a>	-ydraulic Valve
<a href="#">6P- 49TR N8</a>	Urged steel ball valve
<a href="#">1P- 4DT8 DN DRM9 D</a>	
<a href="#">GRGOGGMOGD9 TT 1P- 4DTR GM DDDN D</a>	
<a href="#">1P- 4DT8 DN DDDN 8 0L9GG</a>	
<a href="#">1P- 4D 89 DDDN D</a>	
<a href="#">7P- 5L89 6AE MGGGpsi 5T5 RR8N</a>	
<a href="#">1P- DT8L03 DN DDR9 D</a>	1lock ball valves
<a href="#">G/8.GB 55OAL 8RF 5SL</a>	
<a href="#">6PN 4NTR 8G 8D8N D 2</a>	
<a href="#">7P- 5LRG 6AE MGGGpsi 5T5 RR8N</a>	
<a href="#">UP- 5LDGG 0LDMG NR8N D UD</a>	
<a href="#">1PN DG2 GB DD8N D 2 1rD99</a>	
<a href="#">UKP- 5L8GG II/N</a>	
<a href="#">1P- 4DT8 DN DDDDN D 435</a>	AK3HA3(7, 0LEH)A3SK
<a href="#">1PN 4DTR GM RR8N 2</a>	
<a href="#">1P- 4DTR GM DDDN D T GRGOGGMOGD9</a>	1all valves blockOtype
<a href="#">UP- 5LBG 0LDM 9/RR UR#MNOGBGOGG9Z</a>	1all valve
<a href="#">1PN</a>	NOWay 5iverter 1all valve
<a href="#">3P- 4DTR GM NR// G 5f4</a>	Valve
<a href="#">RP- 4D 89 8D8N D IOGM</a>	ROway valve
<a href="#">7P- 4DTR GM RR8N</a>	
<a href="#">D/GOGBGOG++, UKP- 5LBG 6AE MGGGpsi N/8N D</a>	Ulange ball valve
<a href="#">1PN B2 GM DD8N D 2 10 6o</a>	NT8 Way valve
<a href="#">7P- 9TRL03 N8 RR89</a>	Valve
<a href="#">U1P- 5LRG6AE MGGGpsi DD8N D #9RGOGRGOGG8Z</a>	valve
<a href="#">1P- D86 GB DDDN G 10R 8E6</a>	FA2FE
<a href="#">1P- 8BO2 89 DDDN</a>	1A22 FA2FE
<a href="#">1P- 882 8G DDDN</a>	1A22 FA2FE
<a href="#">1P- D82 DG DDDN D 1o63E 6FD8</a>	1A22 FA2FE
<a href="#">1P- DB2 DM DD8N D T GRGOGDMOOND</a>	
<a href="#">1P- NTRL03 8G DD89</a>	FA2FEO0S63E7
<a href="#">1P- DB2 DM DD8N #GRGOGDMOONDZ</a>	1A22 FA2FE
<a href="#">1P- D92 DM DD8N</a>	1A22 FA2FE
<a href="#">1P-H 5L8G DD89 D AF</a>	









Product	Description
<a href="#">K1PS6.7G</a>	Tang Drive Pump
<a href="#">1P-D-1,6-GAS</a>	GEAR PUMP
<a href="#">ALP3-D-40</a>	GEAR PUMP
<a href="#">ALP2A-D-16</a>	GEAR PUMP
<a href="#">968-01-160</a>	Adjustable low-speed compression and rebound damping
<a href="#">ELI2-D-28,0-T0-D-N</a>	ELIKA GEAR PUMP
<a href="#">GHPA2-D-30-D</a>	FRONT PUMP
<a href="#">GHPI2-9-D</a>	INTERMEDIATE PUMP
<a href="#">GHPP2-D-9-D</a>	REAR PUMP
<a href="#">KIT MOD.2 + 2 (650168)</a>	pump coupling kit
<a href="#">GHPA3-D-50</a>	pump
<a href="#">K1P-S-1,6-G</a>	gear pump
<a href="#">1P-D-5</a>	GEAR PUMP
<a href="#">650231/R</a>	GASKET KIT NBR ALP/GHP 3 D/S
<a href="#">1P-D-3,3-GAS</a>	pump
<a href="#">GHP1-D-4</a>	GEAR PUMP
<a href="#">GHP2A-D-20-S1</a>	Gear pump
<a href="#">ALPP2-D-10</a>	rear pump
<a href="#">GHP2-D-40</a>	GEAR PUMP
<a href="#">ALPP3-D-94</a>	ALPP3-D-94 REAR PUMP
<a href="#">ALP3A-D-120</a>	Pump
<a href="#">ALP2BK7-S-6</a>	GEAR PUMP
<a href="#">ALP3-D-94</a>	GEAR PUMP
<a href="#">GHP3-D-94</a>	GEAR PUMP
<a href="#">ALPA2-D-25+GHPP1-D-7</a>	DOUBLE PUMP
<a href="#">ALPP1-D-6</a>	REAR PUMP
<a href="#">GHPP1-D-6</a>	REAR PUMP
<a href="#">GHP2-D-22</a>	GEAR PUMP
<a href="#">GHP2-D-25</a>	Gear pump
<a href="#">GHP1-D-7-FG</a>	GEAR PUMP
<a href="#">K1P-S-5-G</a>	GEAR PUMP
<a href="#">GHPA3A-D-110-S1</a>	
<a href="#">GHPA1-D-4</a>	
<a href="#">ALPA1-D-6</a>	FRONT PUMP
<a href="#">EL12-D-11,4-T0-D-N</a>	ELIKA GEAR PUMP
<a href="#">KL1P-S-5,8-G-GAS</a>	GEAR PUMP
<a href="#">GHP3-S-40-MU</a>	GEAR PUMP
<a href="#">ALP2-D-16-T3</a>	GEAR PUMP
<a href="#">ALP3-D-66-FG</a>	GEAR PUMP
<a href="#">GHPA1-D-4 + ALPP1-D-4</a>	DOUBLE PUMP
<a href="#">ALPP2-D-16</a>	REAR PUMP
<a href="#">ALPA3-D-60</a>	FRONT PUMP
<a href="#">GHPA3S110+GHPP3S110</a>	DOUBLE ASSEMBLED PUMP
<a href="#">ALM2-R-13C0-E1</a>	
<a href="#">0.25-D-18-TR</a>	pump

Product	Description
<a href="#">1 PD4.2</a>	PUMP
<a href="#">GHM3C-R-50</a>	
<a href="#">GHPA3-D-80-EP + ALPP2-D-25-EP</a>	
<a href="#">ALPA3-D-80-FG</a>	FRONT PUMP
<a href="#">ALP 4-D-160</a>	
<a href="#">ALP2-S-16</a>	
<a href="#">650313/R</a>	GASKET KIT
<a href="#">650312/R</a>	NBR GASKET KIT
<a href="#">LTH-524139</a>	SEAL RING
<a href="#">524162/R</a>	separate NBR sealing rings for ALP2
<a href="#">GHM2A-R-40-E2</a>	engine
<a href="#">0.25-D-48</a>	
<a href="#">GHP2-D-13</a>	gear pump
<a href="#">ALP2A-D-30</a>	POMP
<a href="#">K1P-D-6,7-AS-P199</a>	GEAR PUMP
<a href="#">ALP2-S-22</a>	pump
<a href="#">ALP2-D-9-T3</a>	
<a href="#">GHP2A-D-16-FG</a>	
<a href="#">EL 12-D-35.0-T0-D-N</a>	
<a href="#">EL 12-D-17,8 TO-D-N</a>	
<a href="#">650169</a>	
<a href="#">ALP2-D-16-FG</a>	GEAR PUMP
<a href="#">GHPA3-D-110 + GHPP2-D-20</a>	ASSEMBLED DOUBLE PUMP
<a href="#">UK 0,25 S 18 G</a>	gear pump
<a href="#">ALPA3-D-66 + ALPP2-D-12</a>	
<a href="#">ALPA3-80-FG</a>	INTERMEDIATE PUMP
<a href="#">ALP2-25-FG</a>	INTERMEDIATE PUMP
<a href="#">ALPP2-D-25</a>	REAR PUMP
<a href="#">GHPA3-D-50 + ALPP1-D-5</a>	DOUBLE PUMP
<a href="#">ALPA3-D-30</a>	FRONT PUMP
<a href="#">ELI3-D-52,0-T0-A-N</a>	PUMP
<a href="#">KIP- S- 1.6 G</a>	GEAR PUMP
<a href="#">ALP4-D-190</a>	pump
<a href="#">GHP3-D-120</a>	GEAR PUMP
<a href="#">NBR ALP/GHP 2BK7 D/S</a>	GASKET KIT
<a href="#">GHPP1-D-3</a>	pump
<a href="#">ALPP1-D-3-FG</a>	pump
<a href="#">ALPA1-D-4-FG</a>	pump
<a href="#">K1P-S-1,6-G-1/4x1/4</a>	Pump
<a href="#">K1P-S-1,6-G (standard version)</a>	Pump
<a href="#">K1P-D-11,5-AS-P199</a>	GEAR PUMP
<a href="#">ALP1A-D-4-FG</a>	GEAR PUMP
<a href="#">ALP2-S-9-P561</a>	GEAR PUMP
<a href="#">ALP2-S-6-P561</a>	GEAR PUMP
<a href="#">ALP3-S-66</a>	GEAR PUMP



Product	Description
<a href="#">GHP3-S-66</a>	GEAR PUMP
<a href="#">ALPI2-16</a>	INTERMEDIATE PUMP
<a href="#">GHPI2-16</a>	INTERMEDIATE PUMP
<a href="#">GHP2A-D-10-FG</a>	Pump
<a href="#">K1P-S-11.5-C</a>	GEAR PUMP
<a href="#">601506/R</a>	Standar gasket kit for K1P models
<a href="#">TRIPLE PUMP</a>	PUMP
<a href="#">99141759 - CRN95-2-2 A-F-A-E-HQQE 400D/690Y 50 HZ</a>	
<a href="#">ALP2-D-20-D</a>	
<a href="#">LTH-N20800872</a>	
<a href="#">ALPA3-D-60+ALPP3-D-60</a>	DOUBLE PUMP
<a href="#">ALPA2-D-16</a>	.
<a href="#">ALPA2-D-12</a>	FRONT PUMP
<a href="#">LTH-N20800872 GHPA2-D-40 + GHPP2-D-40</a>	DOUBLE ASSEMBLED PUMP
<a href="#">ALP2-D-40-T3</a>	GEAR PUMP
<a href="#">0.25-R-30-KX</a>	GEAR PUMP
<a href="#">ALPA2-D-20+ALPP2-D-25</a>	DOUBLE ASSEMBLED PUMP
<a href="#">ALPA2-D-20 + GHPP2-D-25</a>	DOUBLE ASSEMBLED PUMP
<a href="#">ALPA2-D-40</a>	
<a href="#">ALP3-D-50-C0</a>	hydraulic pump
<a href="#">ALP3 A D110 FG</a>	
<a href="#">ALM3A R80 FG</a>	
<a href="#">ALP1A-D-5</a>	GEAR PUMP
<a href="#">K1P S 5 G 101739803</a>	GEAR PUMP
<a href="#">0.5-D-1.30</a>	GEAR PUMP
<a href="#">ALPP2-D-30</a>	REAR PUMP
<a href="#">GHPC2A3-S-22/22-S5</a>	GEAR PUMP
<a href="#">ALP2-D-6-T3</a>	GEAR PUMP
<a href="#">ALPP2-D6</a>	REAR PUMP
<a href="#">GHPP2-D-6</a>	REAR PUMP
<a href="#">ALPA4-D-130+GHPP3-S-66-FG</a>	
<a href="#">ALP2-D-25-T3</a>	
<a href="#">0.5-D-1.60</a>	GEAR PUMP
<a href="#">K0.25-D-24-TR</a>	GEAR PUMP
<a href="#">GHP1-D-2</a>	PUMP
<a href="#">ALP1A-D-2</a>	Pump
<a href="#">GHPA3-D-40</a>	
<a href="#">ALPI2-20</a>	
<a href="#">ALPP2-D-20</a>	PUMP
<a href="#">650174</a>	
<a href="#">GHP2BK1-D-34</a>	
<a href="#">ALP2-D-30-T3-EP ZB</a>	gear pump
<a href="#">ALP2-D-30-T3-EP</a>	
<a href="#">GHP 1 A D5</a>	
<a href="#">ALPA2-D-20</a>	Pump

Product	Description
<a href="#">ALPA2-D-30</a>	pump
<a href="#">ALP2-D-12</a>	GEAR PUMP
<a href="#">K0.5-S-1.00-G</a>	pump
<a href="#">GHPP1-D-5-FA</a>	
<a href="#">K1P-D-4.2-G</a>	HYDRAULIC PUMP
<a href="#">ALP2-D-9-FG</a>	GEAR PUMP
<a href="#">ALP2-D-10-T3</a>	GEAR PUMP
<a href="#">ALP3A-D-94-S1</a>	GEAR PUMP
<a href="#">GHPA3A-D-60-S1-FG</a>	GEAR PUMP
<a href="#">GHP2A-D-25-C2</a>	GEAR PUMP
<a href="#">GHP2-D-34-FG</a>	Pump
<a href="#">1BK7-9,2D</a>	
<a href="#">0.25-D-36</a>	
<a href="#">ALM2-R-16-E1</a>	HYD. FAN MOTOR
<a href="#">GHP1A-D-4</a>	pump
<a href="#">650150/R</a>	
<a href="#">ALP3-D-135</a>	
<a href="#">GHP3-D-135</a>	
<a href="#">GHPA3-D-60</a>	
<a href="#">GHPP2D-25</a>	
<a href="#">KIT 3+2 ALP</a>	
<a href="#">KIT 2+2 ALP</a>	
<a href="#">U0.25-R-36</a>	
<a href="#">U0.25-R-24-VN-KX</a>	pump
<a href="#">ALP3A-D-66-FA</a>	
<a href="#">ALP3-D-110</a>	GEAR PUMP
<a href="#">GHP3-D-110</a>	
<a href="#">GHP2-D-30-T3-FG</a>	Pump
<a href="#">GHPC2A-D-40/6-C2-KA</a>	Pump
<a href="#">ALP1AQ-S-6-G1-P636</a>	
<a href="#">GHP2-D-20-FG</a>	Hydraulic Gear Pump
<a href="#">ALPA4 -D-160</a>	
<a href="#">ALPA1-D-4+ALPI1-4+ALPP1-D-3</a>	pump
<a href="#">GHPA3-D-94</a>	
<a href="#">GHPP2-D-40</a>	
<a href="#">GHPP1-D-2-AS</a>	Gear Pump
<a href="#">ALP3A-S60-S1-E</a>	
<a href="#">A0.5-D-1.30+P0.25-D-24</a>	DOUBLE PUMP
<a href="#">GHP3A-S-60-S1-E</a>	
<a href="#">E20800042 / PDELI2-D-9,6/9,6-T0-D-D-N</a>	Pump
<a href="#">ALP2BK7-S-9</a>	
<a href="#">ALP2-D-34-FG</a>	pump
<a href="#">GHPA3A-D-80-S1-D</a>	Pump
<a href="#">MA00000000</a>	BOMB
<a href="#">ELI4AC-D-127,4-C0-A-N</a>	Pump

Product	Description
<a href="#">ALPA1-D-4-P524A + ALPI1-4-P524A + ALPP1-D-3-P524A</a>	TRIPLE PUMP
<a href="#">GHP3-D-50</a>	PUMP
<a href="#">ALM3A-R-80-S1-E-E3</a>	pump
<a href="#">GHM2A-R-34-E2</a>	
<a href="#">1PHL-D-2.5/10-8/35-30-P606</a>	HIGH-LOW DOUBLE PUMP
<a href="#">ALP3S-50</a>	PUMP
<a href="#">ALPA3D-110+ALPP2D-20</a>	
<a href="#">1P-D-1,6-KA</a>	
<a href="#">GHPA2-D-40+ALPP2-D-10</a>	pump
<a href="#">ALPP1-D-9-FG</a>	PUMP
<a href="#">ALPP2-S-30</a>	REAR PUMP
<a href="#">ALM1-R4-E1</a>	ENGINE
<a href="#">ALPA4-S-190</a>	FRONT pump
<a href="#">GHM3C-R-50-EP-MU-E1</a>	Engine
<a href="#">K1PS1.2G</a>	Gear pump
<a href="#">MA90000124</a>	GEAR PUMP
<a href="#">K1P-D-2,5-AS-P199</a>	pump
<a href="#">K1P-D-6,7-G</a>	GEAR PUMP
<a href="#">ALP/GHP 3+1 (650169)</a>	
<a href="#">ALP-P1D5</a>	
<a href="#">GHP35-D-135</a>	PUMP
<a href="#">G1.3B40X ALP1A-D-4</a>	Bomba
<a href="#">ALP1A-D-4</a>	ALP1A-D-4 GEAR PUMP
<a href="#">GHPP2-D-9-FA-AC12</a>	External gear pump
<a href="#">ALP2-D-13-C0-FG</a>	
<a href="#">MZ.650226/R</a>	
<a href="#">650351/R</a>	sEAL KIT
<a href="#">ALPA1-D-6-FG-TR</a>	FRONT PUMP
<a href="#">K1PS9.2G</a>	.
<a href="#">ALP2A-D-34</a>	GEAR PUMP
<a href="#">ELI-1PD4.3-T0-D-N</a>	ELIKA GEAR PUMP
<a href="#">1BK7-S-6.7</a>	PUMP
<a href="#">ALM3-D-50</a>	MOTOR
<a href="#">GHPA3-D-66-V</a>	Doppelpumpe
<a href="#">GHPP2-D-16-EP-V</a>	double pump
<a href="#">FT1006-363</a>	ASSEMBLY KIT
<a href="#">K1P D 15 G P199</a>	GEAR PUMP
<a href="#">UK0.25-D-60-G</a>	GEAR PUMP
<a href="#">ALM2A-R-25</a>	
<a href="#">K1P R 1,6XG</a>	GEAR PUMP
<a href="#">P1.33210</a>	.
<a href="#">P1.62080</a>	
<a href="#">P1.41220</a>	
<a href="#">MA90000024</a>	
<a href="#">ALPA1D-5+ALPP1D-5</a>	DOUBLE PUMP

Product	Description
<a href="#">ALP-2S30</a>	
<a href="#">GHPA3-D-80 + GHPP3-D-80</a>	DOUBLE PUMP
<a href="#">ALP3A-D-60-S1-E</a>	GEAR PUMP
<a href="#">ALPA3-D-66+ALPI1-9+ALPP1-D-3</a>	
<a href="#">GHPA3-D-66+GHPI1-9+GHPP1-D-3</a>	
<a href="#">LTH-ND108C</a>	
<a href="#">LTH-R103</a>	
<a href="#">LTH-ND108P2</a>	
<a href="#">MA00000000 - 1P S 11.5</a>	PUMP
<a href="#">601505/R</a>	GASKET KIT
<a href="#">ALPA3-D-135</a>	FRONT PUMP
<a href="#">GASKET KIT FOR 1PD-2</a>	
<a href="#">ALPP1-D-3</a>	
<a href="#">ALPP1-D-13</a>	REAR PUMP