



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Max-Air

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">BE41-210003</a>	Limit Switch Box
<a href="#">MT45-5EAE13</a>	Max-Air Aluminum Pneumatic Actuator
<a href="#">UT15-0DAC13</a>	Max Air Pneumatic Actuator
<a href="#">MT35-5EAE13</a>	Max-Air Aluminum Pneumatic Actuator
<a href="#">EV62-521MB1</a>	NAMUR Max-Air IP65 1/4" GAS 5-way bistable aluminum solenoid valve complete with No. 2 24 V DC coils and No. 2 Pg09 connectors with LED
<a href="#">EV61-521MJ1</a>	solenoid
<a href="#">BE45-220M03</a>	Limit switch box
<a href="#">PEY01</a>	ELECTROPNEUMATIC POSITIONER WITH GAUGE
<a href="#">UT10-2BAB31</a>	PNEUMATIC ACTUATOR
<a href="#">UT20-5BAD31</a>	Aluminum Pneumatic Actuator
<a href="#">AE04H-120VAC-YY</a>	Electric Quarter-Turn Actuator
<a href="#">AE02.120VAC</a>	Electric Quarter-Turn Actuator
<a href="#">AE01A-24VAC/VDC</a>	Electric Quarter-Turn Actuator
<a href="#">AE03-1CA00S</a>	
<a href="#">SV61-120A</a>	
<a href="#">SV61-521M-220VAC1</a>	Solenoid Valve
<a href="#">SV61-531MB1</a>	Max Air Solenoid Valve
<a href="#">SV61-12VDC</a>	Solenoid Valve
<a href="#">SV71-541M24VDC1</a>	Solenoid Valve
<a href="#">MT31_DA</a>	
<a href="#">MT16.S5.F05-F07</a>	Rack & Pinion Actuator
<a href="#">MT31S4F07</a>	
<a href="#">MT31.S4.F05-F07.CH17</a>	
<a href="#">MS41-2</a>	Limit Switches
<a href="#">UT10-0BAB13</a>	PNEUMATIC ACTUATOR
<a href="#">KIT/SV91-HT</a>	Kit
<a href="#">Typ: EV61-521MB1</a>	Valve
<a href="#">MAX-AIR Endschalter-Box, Typ BE41</a>	Box
<a href="#">Typ: UT50-5GAF31</a>	Actuator, Pneumatic
<a href="#">MT20-0DAD31S100</a>	Pneumatic Actuator
<a href="#">UT18S4-VK64GF20A (2")</a>	Pneumatic actuator
<a href="#">UT18S3-VK64GE15A (1 1/2")</a>	Pneumatic actuator
<a href="#">UT10DE-VK64GM14A (1/4")</a>	Pneumatic actuator
<a href="#">UT13S3-VK64GC10A (1")</a>	Pneumatic actuator

Product	Description
<a href="#">AE01-0CB00S</a>	ELECTRIC ACTUATOR
<a href="#">EV61</a>	SOLENOID VALVES
<a href="#">MT35-3EAE31</a>	Pneumatic actuator
<a href="#">MT40-3EAE31</a>	Pneumatic actuator
<a href="#">UT25-0DBD31</a>	Pneumatic actuator
<a href="#">EV61-521MB1</a>	Solenoid valve
<a href="#">AE01-A (230 or 110 vac)</a>	Electric actuator
<a href="#">UT/MT17- RK</a>	Skates and compasses kit
<a href="#">UT/MT17-OR</a>	Kit oring in buna
<a href="#">UT18S4-VK64GF20A + UT18 SR4</a>	VALVE 2" + ACTUATOR
<a href="#">UT18S3-VK64E15 + UT18 SR3</a>	VALVE 1 1/2" +ACTUATOR
<a href="#">UT20-0DAD31</a>	max air pneumatic actuator
<a href="#">AE02-A 230VAC</a>	Electric actuator
<a href="#">UT/MT20-0DAD31</a>	PNEUMATIC ACTUATOR ALL. DOUBLE EFFECT
<a href="#">IF36 9000 CFM</a>	
<a href="#">MT16-0DAC314</a>	
<a href="#">AE03-1HA00S</a>	Electric actuator
<a href="#">MEE23-24VDFB</a>	Electric actuator
<a href="#">MT35 - RK</a>	SKATES AND BEARINGS SPARE PART KIT
<a href="#">MT35-OR</a>	BUNA O-Ring KIT
<a href="#">MT16.S4.F04-F07.CH14 LT</a>	
<a href="#">UT/MT35-3EAE31</a>	PNEUMATIC ACTUATOR
<a href="#">AE03-0HA00S</a>	Electric actuator
<a href="#">UT 35 5EAE13</a>	MAX-AIR UT SERIES PNEUMATIC ACTUATOR
<a href="#">UT26 S4 90° F05 CH17 1/4"NPT</a>	
<a href="#">BE45-220M033</a>	Limit switch box
<a href="#">UT26 S4 90° F07 CH17 1/4"NPT</a>	
<a href="#">MT26 S4 90° F05/F07 CH.17 1/4" NPT</a>	
<a href="#">UT11-2AAB31</a>	
<a href="#">UT25-0DAD13</a>	Pneumatic Actuator Double Acting
<a href="#">UT10DE-VK64M14</a>	Ball valve with actuator
<a href="#">UT13S3-VK64C10</a>	Ball valve with actuator
<a href="#">EV61-521M01</a>	
<a href="#">UT25-0CAD31</a>	pneumatic actuator
<a href="#">UT/MT40-4EAE31</a>	ACTUATOR
<a href="#">UT18-3CAD31</a>	pneumatic actuator
<a href="#">UT13-3CAD31</a>	PNOMATIC
<a href="#">MT07-4AAB31</a>	Pneumatic actuator
<a href="#">MT07-4BAB31</a>	Pneumatic actuator
<a href="#">UT20-0CAD31</a>	Double acting pneumatic drive
<a href="#">SKATES AND BEARINGS SPARE PART KIT for UT/MT20</a>	
<a href="#">BUNA O-Ring KIT for UT/MT20</a>	
<a href="#">UT20-21 KIT O-RING IN NBR</a>	

Product	Description
<a href="#">EV81-501MB1</a>	Max-Air Solenoid Valve
<a href="#">UT20-21 KIT PARTI IN PLASTICA</a>	
<a href="#">UT11 S2 90° F04 CH11 1/4" NPT</a>	
<a href="#">EV63-521MF1</a>	solenoid valve
<a href="#">MT30-5DAD13</a>	pneumatic actuator
<a href="#">AE03120VAC</a>	
<a href="#">UT17U0TAV31</a>	Pneumatic Actuator
<a href="#">UT17 DA 3.25 DD</a>	Max Air Pneumatic Actuator Double Acting
<a href="#">MT40-5EAE31</a>	Pneumatic Actuator
<a href="#">22x14 H27</a>	
<a href="#">EV61-521MH1 -EV61-501M01</a>	solenoid
<a href="#">BS48- 220MD3</a>	Limit Switch Box
<a href="#">MT41.S5.F07-F10.CH22.C</a>	
<a href="#">MT51.S5.F10-F12.CH27.C</a>	
<a href="#">MT31.S5.F05-F07.CH17.C</a>	
<a href="#">MT21.S5.F05/F07.CH17.C</a>	
<a href="#">UT10-OAAB31</a>	Pneumatic Actuator
<a href="#">15050B1HL</a>	PANEL FAN
<a href="#">MT15-5DAC31S100 F05/F07</a>	Acromatic Pneumatic Actuator
<a href="#">EV61-521MB1 3/2 &amp; 5/2</a>	Solenoid Valve
<a href="#">MT21.DA.F05-F07.CH17</a>	ACTUATOR
<a href="#">MT12.DA.F03-F05.CH11</a>	
<a href="#">EV61-521MH1 (110 V AC)</a>	solenoid valve
<a href="#">MT15-4DAC31</a>	Pneumatic actuator
<a href="#">MT20-4DAD34</a>	Max Air pneumatic actuator spring retroactive
<a href="#">SV61-120VAC-5-CSA</a>	
<a href="#">MT08.S4.F03-F05.CH11</a>	Pneumatic actuator
<a href="#">MT61.S4.F10-F14.CH36</a>	MAX-AIR TECHNOLOGY PNEUMATIC ACTUATOR
<a href="#">MT35-5EAE31S100</a>	
<a href="#">MT30-5DAD31S100</a>	Pneumatic Actuator
<a href="#">BE45-220M03X</a>	Limit switch
<a href="#">SV71-24D-TT-SA1</a>	
<a href="#">MT04.DA.F03.CH9</a>	Pneumatic Actuator Double Acting
<a href="#">UT10-3AAB31E</a>	actuator
<a href="#">MT 45-0EAE11</a>	Pneumatic Actuator
<a href="#">MT40-5EAE31S100</a>	
<a href="#">AC23-R1EC4S</a>	Adapter
<a href="#">MT35-DA-090-F07/F10-CH22-A</a>	
<a href="#">MT25-5DAD13</a>	Max Air Pneumatic Actuator Spring Return
<a href="#">UT16.S4.F04.CH14</a>	
<a href="#">SV61-120VAC-5HT</a>	
<a href="#">MT41.DA.F07-F10.CH22</a>	Actuator
<a href="#">BE45220MS3</a>	
<a href="#">MT17-0DAC31</a>	DOUBLE ACTING PNEUMATIC ACTUATOR
<a href="#">UT50-0GAF34</a>	

Product	Description
<a href="#">MS35-140M00</a>	
<a href="#">MT75-09AH34S100</a>	
<a href="#">SVH61-220A-AA-SA1</a>	
<a href="#">UT17-0DAC13</a>	pneumatic drive
<a href="#">EV61-521MJ1 (230Vac)</a>	SOLENOID VALVE
<a href="#">Spare coil EV61 110/120 VAC 5VA</a>	coil for 3/2 solenoid valve
<a href="#">EV61-521MJ1 (220 VDC)</a>	Solenoid Valve
<a href="#">NV61-120A-3-STD</a>	
<a href="#">MT21.S4.F05-F07.CH17</a>	
<a href="#">SV61-531MJ1</a>	Solenoid Valve
<a href="#">UT14.S3.F05.CH14</a>	Actuator
<a href="#">MT31.DA.F05-F07.CH17</a>	PNEUMATIC ACTUATOR
<a href="#">SV61-24VCD-5 STD</a>	
<a href="#">15050B2HL</a>	
<a href="#">MS35-120M03</a>	LIMIT SWITCH
<a href="#">UT20-0DAD13</a>	pneumatic drive
<a href="#">MT36.S5.F07-F10.CH22</a>	
<a href="#">UT35-5EAE33</a>	Pneumatic actuator
<a href="#">SKATES AND BEARINGS SPARE PART KIT+ BUNA OR KIT (</a>	
<a href="#">UT36.S5.3.25/5.00.CH22</a>	MAX-AIR UT SERIES PNEUMATIC ACTUATOR
<a href="#">Type UT35-5EAE13</a>	pneumatic drive
<a href="#">ENP.MT21.DA.F05-F07.CH17</a>	ACTUATOR
<a href="#">UT21-NBR-RK</a>	BUNA SEALS REPAIR KIT
<a href="#">UT21-S-B</a>	SKATES & WEAR BEARING KIT
<a href="#">PES90-RC4NS1001E</a>	electro-pneumatic positioner
<a href="#">MT46.S5.F07-F10.CH22</a>	SPRING RETURN ACTUATOR
<a href="#">MT46.S4.F07-F10.CH22</a>	
<a href="#">PES70-RN45NS1001-DFE</a>	electro-pneumatic positioner
<a href="#">MT05-0AAB11</a>	Double acting pneumatic drive
<a href="#">BE48-220M03</a>	Limit switch box
<a href="#">MT15-0DAC13</a>	MT15 repair kit
<a href="#">MT17-0DAC13</a>	MT17 repair kit
<a href="#">MT05-OBAB11</a>	MT05 repair kit
<a href="#">MT25-0DAD13</a>	MT25 repair kit
<a href="#">MT35-OEAE31</a>	MT35 repair kit
<a href="#">MT40-5EAE13</a>	MT40 repair kit
<a href="#">MT45-5EAE12</a>	MT45 repair kit
<a href="#">MT15-0DAC31</a>	pneumatic drive
<a href="#">MT30-0DAD31</a>	pneumatic drive
<a href="#">MT35-OEAE13</a>	actuator
<a href="#">MS45-120M03</a>	LIMIT SWITCH
<a href="#">MT46.DA.F07-F10.CH22</a>	ACTUATOR
<a href="#">MT45.DA.F07-F10.CH22</a>	ACTUATOR
<a href="#">PET60-RN4NS0000</a>	

Product	Description
<a href="#">MT46-NBR-RK</a>	MT46 SEAL REPAIR KIT
<a href="#">Spare coil for EV61-521MJ1 220 VAC 5VA</a>	
<a href="#">MT46-S-B</a>	
<a href="#">SV61-120A-5-STD</a>	SOLENOID VALVE
<a href="#">EV62-521MB1X</a>	Electrovalves
<a href="#">MF58</a>	Spare Coil for EV61 220 VAC 5VA
<a href="#">MT070BAB31</a>	DA PNEUMATIC ACTUATOR
<a href="#">MT250DAD31</a>	DA PNEUMATIC ACTUATOR
<a href="#">UT13-AC000V</a>	
<a href="#">AC23-R3DC07</a>	
<a href="#">MT17-5DAC31S100</a>	PNEUMATIC ACTUATOR
<a href="#">GO-W02 S0S000</a>	DETACHABLE REDUCER
<a href="#">MT16.S4.F04-F07.CH14</a>	
<a href="#">Old P/N: UT46-SR4-F07/10 New P/N: MT46.S4.F07-F10.CH22</a>	ACTUATOR
<a href="#">SV61-24DC-5-STD</a>	SOLENOID VALVE
<a href="#">SV61-220A-5-STD</a>	
<a href="#">UT30-0DAD31</a>	Pneumatic actuator
<a href="#">BUNA O-Ring KIT</a>	
<a href="#">UT11-2BAB31</a>	actuator
<a href="#">EV61-521MB1 (E2202887)</a>	Pneumatic actuator
<a href="#">MT35-5EAE31S100 F07/F10</a>	
<a href="#">MT30-4DAD31S100</a>	
<a href="#">MT12.S2.F04.CH11</a>	
<a href="#">MT35-9EAE31</a>	
<a href="#">MT20-0DAD31</a>	
<a href="#">EV71-541MB1</a>	
<a href="#">MT51.DA. F10-F12.CH27</a>	
<a href="#">SV61-24D-5-STD</a>	
<a href="#">24VDC-61-COI</a>	
<a href="#">612-201-0051</a>	
<a href="#">MT70-AA000V/A</a>	
<a href="#">MT70-AC000V/AMT70</a>	
<a href="#">SV61-24V DC</a>	
<a href="#">Spare coil EV61 501M01</a>	
<a href="#">MT70</a>	
<a href="#">MT71-NBR-RK</a>	
<a href="#">MT71-S-B</a>	
<a href="#">MT DA ---MT15-0DAC31S100</a>	
<a href="#">MT15.S3.F05-F07.CH14</a>	SPRING RETURN ACTUATOR
<a href="#">MT60.S5.F10-F-12.CH36</a>	MAX-AIR SPRING RETURN ACTUATOR
<a href="#">UT17-0DAC31</a>	Double acting pneumatic drive
<a href="#">MT17.DA.F05-F07.CH14</a>	TECHNOLOGY DA PNEUMATIC ACTUATOR
<a href="#">EV61-501M01</a>	valve

Product	Description
<a href="#">EV61-521MH1</a>	valve
<a href="#">UT 40 3EAE31</a>	pneumatic drive
<a href="#">MT40.S3.F07-F10.CH22</a>	MT40 ALUMINUM ACTUATOR
<a href="#">EV71-24VDC</a>	
<a href="#">BS45-220MF3</a>	Limit switch box
<a href="#">BE45-220MF3</a>	Box Limit switch
<a href="#">MT25-0DAD31S100</a>	Actuator
<a href="#">MT41.S4.F07-F10.CH22</a>	PNEUMATIC ACTUATOR
<a href="#">UT10-0AAB31</a>	Actuator
<a href="#">MT20-4DAD31S100</a>	Actuator
<a href="#">UT15-0CE533</a>	Max Air Pneumatic Actuator
<a href="#">Type MT41.S4.F07-F10.CH22</a>	
<a href="#">UT15 0 CE533</a>	Max Air Pneumatic Actuator
<a href="#">MT15-4CAC3AS100</a>	
<a href="#">MT50-5GAF31S100</a>	servomotor
<a href="#">Certificate of origin</a>	
<a href="#">MS45-120M03</a>	
<a href="#">MT16.DA.F04-F07.CH14</a>	
<a href="#">MT55</a>	Actuator
<a href="#">UT11-NBR-RK UT11</a>	
<a href="#">UT10-2KAA31</a>	
<a href="#">UT10-2KAA34</a>	
<a href="#">UT11.S2.F04.CH11</a>	
<a href="#">UT11.S2.F04.CH11.D - UT11</a>	
<a href="#">MT07-4AAB31S100</a>	
<a href="#">Supplier declarations</a>	
<a href="#">MT31-NBR-RK</a>	sealing kit
<a href="#">ENP.MT31 S4 F05/F07</a>	
<a href="#">Sealing Kit for ENP.MT31 S4</a>	
<a href="#">EV61-521MB1X</a>	Solenoid valve
<a href="#">SV61-24VDC-5-STD</a>	Solenoid Valve
<a href="#">GO-W33</a>	DETACHABLE TORQUE CAST IRON REDUCER
<a href="#">IS41-22STGT</a>	
<a href="#">GO-W33S0S000</a>	
<a href="#">EV61-521MJ1- MAX-AIR 1/4" GAS</a>	pneumatic solenoid valve
<a href="#">Cod. UT10-0BAB31</a>	TECHNOPOLYMER ACTUATOR
<a href="#">MT07-4AAB34</a>	PNEUMATIC ACTUATOR
<a href="#">EV62-501M01</a>	valve
<a href="#">EV71-541MB1 E1305911</a>	control valve
<a href="#">Type BE41-210003</a>	Limit switch box
<a href="#">UT11.DA.F03-CH11</a>	
<a href="#">UT35-0EDE31</a>	
<a href="#">UT36.180.DA.F07/F10.CH22</a>	
<a href="#">EV61-521 MB 1S</a>	Valve
<a href="#">UT20-3CAD31A</a>	

Product	Description
<a href="#">EPOXY.MT21.S3.F05-F07.CH17</a>	
<a href="#">EV61-521MB4</a>	solenoid
<a href="#">UT20-3CAD31S200</a>	R&P Max-Air pneumatic actuator
<a href="#">MT08-4AAB31S100</a>	
<a href="#">MT16-S-B</a>	
<a href="#">MT40-4EAE31</a>	propulsion
<a href="#">Seal kit for MT DA ---MT15-0DAC31S100</a>	