







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Micro Detectors / Diell

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
AE1/AP-1F	Standard d.c. 3 wires inductive proximity sensor
<u>AE1/AP-2A</u>	Inductive sensor
AE1/CP-3A	
AES/AP-1F	
AK1/AP-2H	Inductive sensor
AM1/AP-1H	Inductive Sensor
<u>BV4/00-0E</u>	Cubic photoelectric sensor
<u>BV6/00-0E</u>	Photoelectric sensor
BX10SR/0A-HB6A	
BX10SR/0A-HB6A79	
<u>BX80A/1P-1A</u>	Sensor
<u>BX80S/10-1A</u>	Area sensor
FAI7/BP-0E	sensor
FALD/BP-1E	Photoelectric sensor
FALH/X0-1E	Photoelectric sensor
<u>H8E/1</u>	
<u>H8R/1</u>	Photoelectric sensor
<u>MS2/00-0A</u>	Diffuse sensor
<u>MS6/00-0A</u>	Lichttaster M.D.
<u>MSC/00-0E</u>	Photoelectric sensor Retroreflective
PD1/AN-1A	Inductive Proximity Sensor
<u>SB300</u>	module
SBCR03/S-AM	Control Unit
SSG/AP-0E	Photoelectric sensor
<u>SSU/00-0E</u>	Photoelectric sensor
<u>SP2/0P-0E</u>	
FARL/BP-0E	Sensor
AES/AN-1F	
SSG/AP-1H	Receiver
PMS/OP-1H	Induktiver Sensor
QMRG/0P-0F OEM	
<u>MP0/00-0E</u>	Photoelectric sensor
FAIC/BP-1EDA	Photoelectric sensor
<u>RX8/0T-3B37</u>	Photoelectric sensor
SSC/DP-1E	
FARS/BP-1E	Photoelectric sensor





Product	Description
A413BX80A1P1	Detector
SS0/LP-1E	
<u>390000011410</u>	Sensor
A413BX80100H	
<u>SH2/E-1K</u>	Emitt.
<u>SH2/R-1K</u>	Receiver
<u>TH2/R-K</u>	Receiver
<u>TH2/E-K</u>	Emitt.
<u>SH2/R-1H</u>	sensor receiver
<u>SH2/E-1H</u>	sensor
CD12M/0B-050A1	Cable and Plug
<u>BX80S/10-0H</u>	
BX80S/10-1H6X	Area sensor
<u>BX80B/1P-1H6X</u>	Area sensor
<u>320000000111 (SH2/E-0E)</u>	
<u>MS2/00-0E</u>	Photoelectric sensor
SSC/LN-0A	
<u>BX80A/1P-1H</u>	Light curtain receiver
<u>BX80A/1P-0H</u>	area sensor
<u>CF/CB1-20</u>	FIBRE TAGL.SCANNER
<u>Q50ID/0T-0A</u>	Photoelectric sensor
<u>Q50IH/0T-0A</u>	Photoelectric sensor
<u>RX8/0T-1B37</u>	Photoelectric sensor
<u>SSP/LP-1E</u>	Retro-Reflective photoelectric sensor
<u>PK3/00-1H</u>	
FQI7/BP-0E	
LS2ER/30-090	
<u>CD12M/0H-050A3</u>	
<u>AM1/AP-2H3W</u>	
AM1/AP-1H4W	Inductive sensor
FAIC/BP-0E	Photoelectric sensor
<u>SS2/LP-0E</u>	
<u>AE6/AN-1A</u>	
<u>AE1/CN-1A</u>	
<u>AE6/CN-1A</u>	Inductive sensor
	Inductive sensor
<u>AE6/AP-1A</u>	Inductive sensor
	Inductive sensor
	sensor
<u>AE6/AN-2A</u>	
<u>AE6/CN-2A</u>	
<u>AE6/AP-2A</u>	
<u>AE1/CP-2A</u>	ha da a tê a a
AE6/CP-2A	Inductive sensor

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 2 / 23





Product	Description
AE1/AN-3A	Inductive sensor
AE6/AN-3A	
AE1/CN-3A	
AE6/CN-3A	
AE1/AP-3A	Inductive sensor
SS2/LN-0A	Photoelectric sensor
AE6/CP-3A	
AE1/AN-4A	
<u>AE6/AN-4A</u>	
AE1/CN-4A	
AE6/CN-4A	
<u>AE1/AP-4A</u>	
<u>AE6/AP-4A</u>	
<u>AE1/CP-4A</u>	
<u>AE6/CP-4A</u>	
<u>AE1/AN-1F</u>	
AE6/AN-1F	
AE1/CN-1F	
AE6/CN-1F	
AE6/AP-1F	
AE6/CP-1F	
AE1/AN-2F	Inductive sensor
AE6/AN-2F	
AE1/CN-2F	
AE6/CN-2F	Inductive Proximity Switches
AE1/AP-2F	Inductive Proximity Switches
AE6/AP-2F	
AE1/CP-2F	Inductive Proximity Switches
AE6/CP-2F	Inductive Proximity Switches
<u>AE1/AN-3F</u>	
AE6/AN-3F	Inductive Proximity Switches
<u>AE1/CN-3F</u>	
AE6/CN-3F	Inductive Proximity Switches
<u>AE1/AP-3F</u>	Inductive sensor
AE6/AP-3F	Inductive Proximity Switch
AE1/CP-3F	hade at the Decederate Or database
	Inductive Proximity Switches
AE1/AN-4F	Industive Drevisity Cryitakaa
AE6/AN-4F	Inductive Proximity Switches
AE1/CN-4F	Inductive Drovinsity Quitabas
AE6/CN-4F	Inductive Proximity Switches
AE1/AP-4F	Inductive sensor
AE6/AP-4F	Inductive Proximity Switches
AE1/CP-4F	Inductive Proximity Switches
AE6/CP-4F	Inductive Proximity Switches

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 3 / 23





Product	Description
AE1/CN-1H	
AE1/CP-1H	Inductive Proximity Switches
AE1/AN-2H	Inductive Proximity Switches
AE1/CN-2H	Inductive Proximity Switches
AE1/AP-2H	Inductive Proximity Switches
AE1/CP-2H	Inductive Proximity Switches
AE1/AN-3H	Inductive Proximity Switches
<u>AE1/CN-3H</u>	Inductive Proximity Switches
AE1/CP-3H	
<u>AE1/AN-4H</u>	Inductive Proximity Switches
<u>AE1/AP-4H</u>	
<u>HEE/00-3A</u>	M8 miniaturized through-beam sensors DC
HER/AP-3A	M8 miniaturized through-beam sensors DC
HER/CP-3A	M8 miniaturized through-beam sensors DC
HER/AN-3A	
HER/CN-3A	M8 miniaturized through-beam sensors DC
<u>HEE/00-4A</u>	M8 miniaturized through-beam sensors DC
HER/AP-4A	M8 miniaturized through-beam sensors DC
HER/CP-4A	M8 miniaturized through-beam sensors DC
HER/AN-4A	M0 ministurized through beam sensors D0
HER/CN-4A	M8 miniaturized through-beam sensors DC
HEE/00-3F HER/AP-3F	M8 miniaturized through-beam sensors DC M8 miniaturized through-beam sensors DC
HER/CP-3F	
HER/AN-3F	M8 miniaturized through-beam sensors DC
HER/CN-3F	M8 miniaturized through-beam sensors DC
HEE/00-4E	M8 miniaturized through beam sensors DC
HER/AP-4F	M8 miniaturized through beam sensors DC
HER/CP-4F	M8 miniaturized through-beam sensors DC
HER/AN-4F	M8 miniaturized through-beam sensors DC
	M8 miniaturized through-beam sensors DC
DME/00-1A25	M12 cylindrical photoelectric sensors
DME/X0-1A25	M12 cylindrical photoelectric sensors
DMP/0N-1A25	M12 cylindrical photoelectric sensors
DMP/0P-1A25	M12 cylindrical photoelectric sensors
DME/00-1H25	M12 cylindrical photoelectric sensors
DME/X0-1H25	M12 cylindrical photoelectric sensors
DMP/0N-1H25	M12 cylindrical photoelectric sensors
DMP/0P-1H25	Photoelectric sensor
<u>DME/00-1A</u>	
DME/X0-1A	M12 cylindrical photoelectric sensors
<u>DM2/0N-1A</u>	M12 cylindrical photoelectric sensors
<u>DM3/0N-1A</u>	M12 cylindrical photoelectric sensors
<u>DM7/0N-1A</u>	M12 cylindrical photoelectric sensors
DMP/0N-1A	M12 cylindrical photoelectric sensors

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 4 / 23





Product	Description
DMR/0N-1A	M12 cylindrical photoelectric sensors
DM2/0P-1A	M12 cylindrical photoelectric sensors
DM3/0P-1A	
DM7/0P-1A	M12 cylindrical photoelectric sensors
DMP/0P-1A	Photoelectric sensor
DMR/0P-1A	
DME/00-1H	Photoelectric sensor
<u>DME/X0-1H</u>	
<u>DM3/0N-1H</u>	
DM7/0N-1H	M12 cylindrical photoelectric sensors
DMP/0N-1H	
DMR/0N-1H	
DM3/0P-1H	
DM7/0P-1H	Photoelectric sensor
DMP/0P-1H	
DMR/0P-1H	Photoelectric sensor
SBCR03/S-A0	
AM1/AP-2A	Inductive proximity sensor
<u>BV2/00-0E</u>	
DM2/0N-1H	M12 cylindrical photoelectric sensors
FARN/BP-1E	Photoelectric sensor
UT1B/E2-0EUL	Ultrasonic Sensor
UT1B/EP-0EUL	Ultrasonic Sensor
UT1B/EN-0EUL	Ultrasonic Sensor
UT1B/EW-0EUL	Ultrasonic Sensor
UT1B/EM-0EUL	Ultrasonic Sensor
UT1B/E5-0EUL	
UT1B/E6-0EUL	
UT1B/E4-0EUL	Ultrasonic Sensor
UT1B/E7-0EUL	Ultrasonic sensor
UT1B/E9-0EUL	
UT1B/E1-0AUL	Ultrasonic Sensor
UT1B/E2-0AUL	Ultrasonic Sensor
UT1B/EP-0AUL	
UT1B/EN-0AUL	
UT1B/EW-0AUL	
UT1B/EM-0AUL	
UT1B/E6-0AUL	
UT1B/E4-0AUL	Ultrasonic Sensor
UT1B/E7-0AUL	Ultrasonic Sensor
UT1B/E9-0AUL	Ultrasonic Sensor
AF/ER7	Termin.S/R fibra core 1 mm 90° 800 mm
<u>AK1/AN-1A</u>	Inductive sensor M18 shielded NO/NPN cable 2m axial
<u>AK1/AP-1A</u>	Inductive sensor M18 shielded NO/PNP cable 2m axial
<u>AK1/AP-2A</u>	sensor

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 5 / 23





Product	Description
<u>AK1/AP-3A</u>	
AM1/AN-1A	Inductive sensor M12 shielded NO/NPN cable 2m axial
AM1/AN-1H	
AM1/AN-2A	Inductive sensor
AM1/AN-2H	
<u>AM1/AN-3H</u>	
<u>AM1/AP-2C</u>	
<u>AM1/AP-4A</u>	
AM1/CP-2A	
UT2F/E6-0EUL	
<u>AM6/AP-2A</u>	
<u>AM6/AP-4A</u>	
AM6/AP-4H	sensor
<u>PM3/00-1H</u>	
<u>PM3/00-2A</u>	
<u>AT1/AP-1A</u>	
BX10SR/0A-HB	Area sensor Kit
BX10SR/0A-HB6X	
<u>CD08/0A-050A1</u>	Connector
<u>CD08/0A-050C1</u>	Connector M8 90° CEI 2022 II 3 poles cable 5 m
<u>CD08/0A-100A1</u>	
<u>CD08/0B-050A1</u>	
<u>CD08/0B-050C1</u>	Connector
<u>CD08/0B-100A1</u>	
CD12M/0B-020A1	
CD12M/0B-020C1	
<u>AM1/CP-2H</u>	Inductive sensor
CD12M/0B-100A1	
CD12M/0B-100C1	
<u>CD12M/0B-150A1</u>	
CD12M/0B-150C1	
CD12M/AA-050A1	
<u>CD12M/AA-050C1</u>	
<u>CD12M/AA-070C1</u>	Connector
CD12M/AA-100A1	
<u>CD12M/AA-100C1</u>	
<u>CD12M/AA-150C1</u>	
<u>CL12/0B-00A</u>	
AT1/AP-1H	Inductive sensor
<u>CV12/0B-00A</u>	Connector
<u>CV12/0B-00B</u>	
AF/1S	
<u>CF/RB6-10</u>	
<u>CF/RB6-20</u>	
<u>CF/RBA-10</u>	





Product	Description
FAI7/BN-0A	Photoelectric sensor
FAI7/BN-0E	sensor
FAI7/BN-1E	Photoelectric sensor
CD12M/0B-050C1	Connector Female
FAI7/BP-1E	
FAI8/BP-0E	Photoelectric sensor
FAIC/BN-0A	
FAIC/BN-0E	
FAIC/BP-0A	
FAIC/BP-2E	
FAID/BP-0E	
FAIM/BP-0E	
FAIZ/BN-0E	
FALN/BP-0E	Photoelectric sensor
FAR2/BN-0A	
FAR2/BN-0E	Photoelectric sensor
FAR2/BP-0A	
FAR2/BP-1E	Photoelectric sensor
FARP/BP-0E	Photoelectric sensor
FARS/BP-0E	Photoelectric sensor
FC7I/0P-M304-0F	
FGRW/0P-0E	
<u>MSC/00-0A</u>	Photoelectric sensor
<u>MSE/00-0E</u>	
<u>MSP/00-0E</u>	Photoelectric sensor
<u>MV2/A0-0A</u>	Photoelectric sensor Diffuse 100 mm plast. cable 2m axial
PKS/0P-1H	Inductive sensor M18 shielded PNP conn. M12
PMS/0N-2H	Inductive sensor M12 unshielded NPN conn. M12
PMS/0P-1H	Inductive sensor M12 shielded PNP conn. M12
FAIZ/BP-0E	Photoelectric sensor
QMIS/0P-0F	Photoelectric sensor
QMR7/0P-0F	Photoelectric sensor
QMR8/0P-0F	Photoelectric sensor
QMRG/0N-0A	Photoelectric sensor
QMRG/0N-0F	
QMRHD/0P-0F	
QMRL/0P-0F	Photoelectric sensor
QMRN/0P-0F	Retro-reflective photoelectric sensor
QMRS/0N-0F	
QMRS/0P-0A	Photoelectric sensor
<u>STQMO</u>	
<u>STQMS</u> <u>PMS/0P-2H</u>	Inductive concer
<u>PMS/0P-2H</u> <u>RX6/0T-3B</u>	Inductive sensor Photoelectric sensor
<u>KV0/01-38</u>	

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 7 / 23





Product	Description
<u>RX8/00-3B</u>	Photoelectric sensor
<u>RX8/0T-3B</u>	Photoelectric sensor
<u>RXC/00-3A</u>	Photoelectric sensor
<u>RXC/0T-3B</u>	Photoelectric sensor
RXL/0T-3B	Photoelectric sensor
SAT/0P-0C	Photoelectric sensor
SSF/0P-0E	Optical Fibre Amplifier
SH4/E-0EIA	
SH4/E-1EIA	Safety sensor
SH4/E-1KIA	
SH4/R-0EIA	Safety sensor
SH4/R-1EIA	Safety sensor
SH4/R-1KIA	
<u>RL 106G</u>	Retroreflective
<u>SS7/0P-0E</u>	
<u>RL 110</u>	
<u>RL 111G</u>	
<u>RL 113G</u>	
<u>RL 116</u>	
<u>RX6/00-3B</u>	
<u>RX8/00-1A</u>	Photoelectric sensor
<u>RXC/00-3B</u>	Photoelectric sensor
<u>STF-12</u>	Photoelectric sensor Focalizz. 12 mm for SST
<u>STF-25</u>	
<u>STF-50</u>	Photoelectric sensor Focaliser 50 mm for SAT
<u>TH6/E-KIA</u>	
<u>TH6/R-KIA</u>	
<u>UK1A/E1-0EUL</u>	
<u>UK1A/E5-0EUL</u>	Ultrasonic sensor
UK1A/EP-0EUL	Ultrasonic sensor
<u>ST 03</u>	
<u>ST 101</u>	
<u>ST 102</u>	
UK1D/E1-0EUL	
<u>ST 12-C</u>	
UK1D/E2-0EUL	
<u>ST 18-A</u>	
<u>ST 18-C</u>	
<u>ST 86</u>	
UK6A/H1-0EUL	
<u>VK2/A0-1B</u>	
<u>VK2/A0-2B</u>	
<u>VK2/C0-2B</u>	
<u>VM2/A0-2B</u>	Inductive sensor M12 unshielded NO cable 2m
<u>AE1/AN-1A86</u>	





Product	Description
AE1/AN-1A8F	
AE1/AN-1A8Q	
<u>AE1/AN-2A86</u>	
<u>AE1/AN-4A86</u>	
<u>AE1/AP-1A84</u>	
<u>AE1/AP-1A86</u>	
<u>AE1/AP-1A8F84</u>	
<u>AE1/AP-1AAN</u>	
<u>AE1/AP-1FAN</u>	
AE1/AP-1FDP	Inductive sensor
AE1/AP-1FE5	Inductive sensor
AE1/AP-1HAN	Inductive sensor
<u>AE1/AP-2A84</u>	Inductive sensor
<u>AE1/AP-2A86</u>	Inductive sensor
<u>AE1/AP-3A4W</u>	Inductive sensor
<u>AE1/AP-3A84</u>	Inductive sensor
AE1/AP-3A86AN	Inductive sensor
<u>AE1/AP-4A86</u>	Inductive sensor
AE1/AP-4AAN	Inductive sensor
AE1/AP-4FAN	Inductive sensor
<u>AE1/CN-1A84</u>	Inductive sensor
<u>AE1/CP-1A84</u>	Inductive sensor
AE1/CP-1A8R	Inductive sensor
AE1/CP-2A8R	Inductive sensor
AE1/CP-3FAN	Inductive sensor
<u>AE6/AN-1A82</u>	Inductive sensor
<u>AE6/AN-1A85</u>	Inductive sensor
<u>AE6/AN-1A8Q</u>	Inductive sensor
<u>AE6/AP-1A848QV5</u>	Inductive sensor
AE6/AP-1AAN	Inductive sensor
AE6/AP-1AVFAK	Inductive sensor
<u>AE6/AP-1F4W</u>	Inductive sensor
AE6/AP-2F4W	Inductive sensor
AE6/AP-2FAN	Inductive sensor
<u>AE6/AP-3A84</u>	Inductive sensor
<u>AE6/AP-3A86</u>	Inductive sensor
AE6/AP-3AAN	Inductive sensor
AE6/AP-3F4W	Inductive sensor
AE6/AP-3FAN	Inductive sensor
<u>AE6/CN-3A86</u>	Inductive sensor
AF/ER2	Access,Opt.fibre
AF/ER3	PLASTIC OPTICAL FIBRES
AF/ER4	Access,Opt.fibre,Focaliser AF/1F,E+R
AF/ER5	Access,Opt.fibre,Focaliser AF/1F,E+R
<u>AF/ER9</u>	Access,Opt.fibre,Focal. CF/RB3,E+R,90°

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 9 / 23





Product	Description
AH1/AN-1A	Inductive sensors
AH1/AN-1F	Inductive sensor
AH1/AN-1H	CYLINDRICAL INDUCTIVE SENSORS
AH1/AN-2A	Inductive sensor
AH1/AN-2F	Inductive sensor
<u>AH1/AN-2H</u>	CYLINDRICAL INDUCTIVE SENSORS
AH1/AN-3A	Inductive sensor
AH1/AN-3F	Inductive sensor
AH1/AN-4A	Inductive sensor
<u>AH1/AN-4F</u>	Inductive sensor
<u>AH1/AP-1A</u>	Inductive sensor
AH1/AP-1F	Inductive sensor
<u>AH1/AP-1H</u>	Inductive sensor
<u>AH1/AP-2A</u>	Inductive sensor
AH1/AP-2F	Inductive sensor
<u>AH1/AP-2H</u>	Inductive sensor
<u>AH1/AP-3A</u>	Inductive sensor
AH1/AP-3F	Inductive sensor
AH1/AP-3FAN	Inductive sensor
<u>AH1/AP-4A</u>	Inductive sensor
<u>AH1/AP-4F</u>	Inductive sensor
<u>AH1/CN-1A</u>	Inductive sensor
<u>AH1/CN-1F</u>	Inductive sensor
<u>AH1/CN-1H</u>	Inductive sensor D6,5 mm shielded NC/NPN plug M12
AH1/CN-2A	Inductive sensor
AH1/CN-2F	Inductive sensor
AH1/CN-2H	Inductive sensor
AH1/CN-3A	Inductive sensor
AH1/CN-3E	Inductive sensor
<u>AH1/CN-4A</u>	Inductive sensor
<u>AH1/CN-4F</u>	Inductive sensor
AH1/CP-1A AH1/CP-1F	
	Inductive sensor
<u>AH1/CP-1H</u>	Inductive senso
AH1/CP-2A AH1/CP-2E	Inductive sensor
<u>AH1/CP-2F</u> <u>AH1/CP-2H</u>	Inductive sensor
<u>AH1/CP-3A</u>	Inductive sensor
	Inductive sensor
AH1/CP-3F AH1/CP-3FAN	Inductive sensor
<u>AH1/CP-4A</u>	Inductive sensor Inductive sensor
<u>AH1/CP-4A</u> <u>AH1/CP-4F</u>	
<u>AH1/CP-4F</u> AH6/AN-1A	Inductive sensor Inductive sensor
<u>AH6/AN-1A</u> <u>AH6/AN-1F</u>	
<u>AH6/AN-1F</u> AH6/AN-2A	Inductive sensor Inductive sensor





Product	Description
<u>AH6/AN-2F</u>	Inductive sensor
AH6/AN-3F	Inductive sensor
AH6/AN-4A	Inductive sensor
<u>AH6/AN-4F</u>	Inductive sensor
<u>AH6/AP-1A</u>	Inductive sensor
AH6/AP-1A86	Inductive sensor
AH6/AP-1F	Inductive sensor
<u>AH6/AP-2A</u>	Inductive sensor
AH6/AP-2AAN	Inductive sensor
AH6/AP-2F	Inductive sensor
<u>AH6/AP-3A</u>	Inductive sensor
AH6/AP-3AAN	Inductive sensor
AH6/AP-3F	Inductive sensor
<u>AH6/AP-4A</u>	Inductive sensor
<u>AH6/AP-4F</u>	Inductive sensor
<u>AH6/CP-1A</u>	Inductive sensor
<u>AH6/CP-1A86</u>	Inductive sensor
AH6/CP-4A	Inductive sensor
AH6/CP-4F	Inductive sensor
<u>AK1/A0-1A</u>	Inductive sensor
<u>AK1/A0-1A86</u>	Inductive sensor
<u>AK1/A0-1ANL</u>	Inductive sensor
<u>AK1/A0-1H</u>	Inductive sensor
<u>AK1/A0-2A</u>	Inductive sensor
<u>AK1/A0-2A86</u>	Inductive sensor
<u>AK1/A0-2AAN</u>	Inductive sensor
<u>AK1/A0-2H</u>	Inductive sensor
<u>AK1/A0-3A</u>	Inductive sensor
<u>AK1/A0-3H</u>	Inductive sensor
<u>AK1/A0-4A</u>	Inductive sensor
<u>AK1/A0-4H</u>	Inductive sensor
AK1/AN-1H	Inductive sensor
AK1/AN-1H4W	Inductive sensor
AK1/AN-2A	Inductive sensor
<u>AK1/AN-2A86</u>	Inductive sensor
<u>AK1/AN-2A8R</u>	Inductive sensor M18 unshielded NO/NPN cable 10m axial
AK1/AN-2AAN	Inductive sensor
AK1/AN-2H	Inductive sensor
AK1/AN-3A	Inductive sensor
<u>AK1/AN-3A8T</u>	Inductive sensor
<u>AK1/AN-3H</u>	Inductive sensor
<u>AK1/AN-4A</u>	Inductive sensor
<u>AK1/AN-4A86</u>	Inductive sensor
AK1/AN-4A8R	Inductive sensor
<u>AK1/AN-4H</u>	Inductive sensor





Product	Description
<u>AK1/AP-1A84</u>	Inductive sensor
<u>AK1/AP-1A86</u>	Inductive sensor
<u>AK1/AP-1A8R</u>	Inductive sensor
AK1/AP-1H4W	Inductive sensor
<u>AK1/AP-2A86</u>	Inductive sensor
AK1/AP-2AAN	Inductive sensor
AK1/AP-2H4W	Inductive sensor
AK1/AP-2HAN	Inductive sensor
<u>AK1/AP-3A86</u>	Inductive sensor
<u>AK1/AP-3A8R</u>	Inductive sensor
<u>AK1/AP-3A8T</u>	Inductive sensor
AK1/AP-3A8W	Inductive sensor
AK1/AP-3AAN	Inductive sensor
AK1/AP-3AETNL	
AK1/AP-3AFGNL	Inductive sensor
<u>AK1/AP-3HAN</u>	Inductive sensor
<u>AK1/AP-4A</u>	Inductive sensor
<u>AK1/BP-3H</u>	Inductive sensor M18 shielded NO+NC/PNP conn. M12
<u>AK1/BP-3HAN</u>	Inductive sensor
<u>AK1/BP-4H</u>	Inductive sensor M18 unshielded NO+NC/PNP conn. M12
AK1/CN-1A	Inductive sensor M18 shielded NC/NPN cable 2m axial
AK1/CN-1H	Inductive sensor
AK1/CN-2A	Inductive sensor
AK1/CN-2H	Inductive sensor M18 unshielded NC/NPN conn. M12
AK1/CN-3A	Inductive sensor M18 shielded NC/NPN cable 5m axial
<u>AK1/CN-3A86</u>	Inductive sensor
AK1/CN-3H	Inductive sensor
<u>AK1/CN-4A</u>	Inductive sensor
<u>AK1/CN-4H</u>	Inductive sensor
<u>AK1/CP-1A</u>	Inductive sensor
<u>AK1/CP-1A86</u>	Inductive sensor
AK1/CP-1A8R	Inductive sensor
AK1/CP-1H	Inductive sensor
<u>AK1/CP-2A</u>	Inductive sensor
AK1/CP-2A8R	Inductive sensor
<u>AK1/CP-2H</u>	Inductive sensor
<u>AK1/CP-3A</u>	Inductive sensor
<u>AK1/CP-3H</u>	Inductive sensor
<u>AK1/CP-4A</u>	Inductive sensor
<u>AK1/CP-4H</u>	Inductive sensor
<u>AK6/AN-3A</u>	Inductive sensor
<u>AK6/AN-3H</u>	Inductive sensor
<u>AK6/AP-1A</u>	Inductive sensor
AK6/AP-1H	Inductive sensor
<u>AK6/AP-2A</u>	Inductive sensor





Product	Description
<u>AK6/AP-2H</u>	Inductive sensor
AK6/AP-3A	Inductive sensor
<u>AK6/AP-3H</u>	Inductive sensor
AK6/AP-4A	Inductive sensor
<u>AK6/AP-4H</u>	Inductive sensor
AK6/BN-1A	Inductive sensor
<u>AK6/BN-1H</u>	Inductive sensor
<u>AK6/BN-2A</u>	Inductive sensor
<u>AK6/BN-2H</u>	Inductive sensor
<u>AK6/BN-3A</u>	Inductive sensor
<u>AK6/BN-3H</u>	Inductive sensor
<u>AK6/BN-4A</u>	Inductive sensor
<u>AK6/BN-4H</u>	Inductive sensor
AK6/BP-1A	Inductive sensor
AK6/BP-1H	Inductive sensor
AK6/BP-2A	Inductive sensor
<u>AK6/BP-2H</u>	Inductive sensor
AK6/BP-3A	Inductive sensor
AK6/BP-3H	Inductive sensor
AK6/BP-4A	Inductive sensor
<u>AK6/BP-4H</u>	Inductive sensor
<u>PK3/00-1A</u>	Inductive sensor
<u>PK3/00-1A86</u>	Inductive sensor
<u>PK3/00-1A8R</u>	Inductive sensor
<u>PK3/00-2A</u>	Inductive sensor
<u>PK3/00-2A86</u>	Inductive sensor
<u>PK3/00-2H</u>	Inductive sensor
<u>AM1/0B-3A</u>	Inductive sensor
<u>AM1/0B-4A</u>	Inductive sensor
<u>AM1/A0-1A</u>	Inductive sensor
<u>AM1/A0-1H</u>	Inductive sensor
<u>AM1/A0-2A</u>	Inductive sensor
<u>AM1/A0-2H</u>	Inductive sensor
<u>AM1/A0-3A</u>	Inductive sensor
<u>AM1/A0-3H</u>	Inductive sensor
<u>AM1/A0-4A</u>	Inductive sensor M12 unshielded NO cable 2m axial
<u>AM1/A0-4H</u>	Inductive sensor
AM1/AN-1A4W	Inductive sensor
<u>AM1/AN-1A86</u>	Inductive sensor
AM1/AN-1C	Inductive sensor
<u>AM1/AN-2A86</u>	Inductive sensor
AM1/AN-2C	Inductive sensor
<u>AM1/AN-2C86</u>	Inductive sensor
AM1/AN-3A	Inductive sensor
AM1/AN-3A4W	Inductive sensor





Product	Description
<u>AM1/AN-3A86</u>	Inductive sensor
AM1/AN-4A	Inductive sensor
<u>AM1/AN-4A2Q</u>	Inductive sensor
<u>AM1/AN-4A4W</u>	Inductive sensor
AM1/AN-4H	Inductive sensor
<u>AM1/AP-1A84</u>	Inductive sensor
<u>AM1/AP-1A85</u>	Inductive sensor
<u>AM1/AP-1A86</u>	Inductive sensor
<u>AM1/AP-1A864W</u>	Inductive sensor
<u>AM1/AP-1A8T</u>	Inductive sensor
AM1/AP-1AVE80	Inductive sensor
AM1/AP-1C	Inductive sensor
AM1/AP-1HAN	Inductive sensor
<u>AM1/AP-2A86</u>	Inductive sensor
<u>AM1/AP-2A8R</u>	Inductive sensor
AM1/AP-2A8W	Inductive sensor
AM1/AP-2AAN	Inductive sensor
AM1/AP-2CVE80	Inductive sensor
AM1/AP-2CVEAK	Inductive sensor
AM1/AP-2H4W	Inductive sensor
AM1/AP-2HAN	Inductive sensor
<u>AM1/AP-3A84</u>	Inductive sensor
<u>AM1/AP-3A86</u>	Inductive sensor
<u>AM1/AP-3A868F</u>	Inductive sensor
<u>AM1/AP-3A86AN</u>	Inductive sensor
<u>AM1/AP-3A8R</u>	Inductive sensor
AM1/AP-3AAN	Inductive sensor
AM1/AP-3AET	
AM1/AP-3ANL	Inductive sensor
AM1/AP-3H7F	Inductive sensor
AM1/AP-4A2Q	Inductive sensor
<u>AM1/AP-4A8R</u>	Inductive sensor
<u>AM1/CN-1A</u>	Inductive sensor
<u>AM1/CN-1C</u>	Inductive sensor
<u>AM1/CN-1H</u>	Inductive sensor
<u>AM1/CN-2A</u>	Inductive sensor
<u>AM1/CN-2C</u>	Inductive sensor
AM1/CN-2H	Inductive sensor
<u>AM1/CN-3A</u>	Inductive sensor
<u>AM1/CN-3H</u>	Inductive sensor
<u>AM1/CN-4A</u>	Inductive sensor
AM1/CN-4A2Q	
AM1/CN-4H	Inductive sensor
<u>AM1/CP-1A</u>	Inductive sensor
AM1/CP-1C	Inductive sensor





Product	Description
AM1/CP-1H	Inductive sensor
AM1/CP-1HAN	Inductive sensor
<u>AM1/CP-2C</u>	Inductive sensor
AM1/CP-3A	Inductive sensor
AM1/CP-4A	Inductive sensor M12 unshielded NC/PNP cable 2m axial
AM1/CP-4H	Inductive sensor
<u>AM6/AN-1A</u>	Inductive sensor
AM6/AN-1C	Inductive sensor
<u>AM6/AN-1H</u>	Inductive sensor
<u>AM6/AN-2A</u>	Inductive sensor
<u>AM6/AN-2A86</u>	Inductive sensor
AM6/AN-2C	Inductive sensor
<u>AM6/AN-2C86</u>	Inductive sensor
AM6/AN-3A	Inductive sensor
<u>AM6/AN-3A87AN</u>	Inductive sensor
AM6/AN-3H	Inductive sensor
AM6/AN-4A	Inductive sensor
AM6/AN-4H	Inductive sensor
<u>AM6/AP-1A86</u>	Inductive sensor
AM6/AP-1AAN	Inductive sensor
AM6/AP-1C	Inductive sensor
<u>AM6/AP-1C86</u>	Inductive sensor
AM6/AP-1HAN	Inductive sensor
<u>AM6/AP-2A86</u>	Inductive sensor
AM6/AP-2C	Inductive sensor
<u>AM6/AP-2C86</u>	Inductive sensor
AM6/AP-2HAN	Inductive sensor
<u>AM6/AP-3A86</u>	Inductive sensor
AM6/AP-3AAN	Inductive sensor
AM6/AP-3C8F	Inductive sensor
AM6/AP-3HAN	Inductive sensor
AM6/AP-4HAN	Inductive sensor
AM6/CN-1A	Inductive sensor
<u>AM6/CN-1C</u>	Inductive sensor
AM6/CN-1H	Inductive sensor
<u>AM6/CN-2A</u>	Inductive sensor
AM6/CN-2C	Inductive sensor
AM6/CN-2H	Inductive sensor
AM6/CN-3A	Inductive sensor
<u>AM6/CN-3A86</u>	Inductive sensor
<u>AM6/CN-3H</u>	Inductive sensor
<u>AM6/CN-4A</u>	Inductive sensor
AM6/CN-4H	Inductive sensor
<u>AM6/CP-1A</u>	Inductive sensor
AM6/CP-1C	Inductive sensor





Product	Description
AM6/CP-1CVE80	Inductive sensor
AM6/CP-1H	Inductive sensor
AM6/CP-2A	
AM6/CP-2C	Inductive sensor
AM6/CP-2H	Inductive sensor
AM6/CP-3A	Inductive sensor
AM6/CP-3H	Inductive sensor
AM6/CP-4A	Inductive sensor
AM6/CP-4H	Inductive sensor
AM6/CP-4HAN	Inductive sensor
AM9/AN-3H	Inductive sensor
AM9/AP-3H	Inductive sensor
<u>PM3/00-1A</u>	Inductive sensor
<u>AT1/0P-1H</u>	Inductive sensor
<u>AT1/0P-2H</u>	Inductive sensor
<u>AT1/0P-3H</u>	Inductive sensor
<u>AT1/0P-4H</u>	Inductive sensor
<u>AT1/A0-1A</u>	Inductive sensor
<u>AT1/A0-1H</u>	Inductive sensor
<u>AT1/A0-2A</u>	Inductive sensor
<u>AT1/A0-2H</u>	Inductive sensor
<u>AT1/A0-3A</u>	Inductive sensor
<u>AT1/A0-3H</u>	Inductive sensor
<u>AT1/A0-4A</u>	Inductive sensor
<u>AT1/A0-4H</u>	Inductive sensor
<u>AT1/AN-1A</u>	Inductive sensor
<u>AT1/AN-1B</u>	Inductive sensor
<u>AT1/AN-1H</u>	Inductive sensor
<u>AT1/AN-2A</u>	Inductive sensor
<u>AT1/AN-2B</u>	Inductive sensor
<u>AT1/AN-2H</u>	Inductive sensor
<u>AT1/AN-3A</u>	Inductive sensor
AT1/AN-3AVE80	Inductive sensor
<u>AT1/AN-3H</u>	Inductive sensor
<u>AT1/AN-4A</u>	Inductive sensor
<u>AT1/AN-4H</u>	Inductive sensor
<u>AT1/AP-1B</u>	Inductive sensor
<u>AT1/AP-1B86</u>	Inductive sensor
<u>AT1/AP-2A</u>	Inductive sensor
<u>AT1/AP-2A86</u>	Inductive sensor
AT1/AP-2A8R	Inductive sensor
<u>AT1/AP-2B</u>	Inductive sensor
<u>AT1/AP-2B86</u>	Inductive sensor
AT1/AP-2H	Inductive sensor
<u>AT1/AP-3A</u>	Inductive sensor





Product	Description
<u>AT1/AP-3A86</u>	Inductive sensor
AT1/AP-3A8R	Inductive sensor M30 shielded NO/PNP cable 10m axial
AT1/AP-3H	Inductive sensor
AT1/AP-3HAN	Inductive sensor
<u>AT1/AP-4A</u>	Inductive sensor
AT1/AP-4H	Inductive sensor
AT1/AP-4HAN	Inductive sensor
<u>AT1/CN-1A</u>	Inductive sensor
AT1/CN-1B	Inductive sensor
<u>AT1/CN-1H</u>	Inductive sensor
AT1/CN-2A	Inductive sensor
<u>AT1/CN-2B</u>	Inductive sensor
AT1/CN-2H	Inductive sensor
<u>AT1/CN-3A</u>	Inductive sensor
AT1/CN-3H	Inductive sensor
<u>AT1/CN-4A</u>	Inductive sensor
AT1/CN-4H	Inductive sensor
<u>AT1/CP-1A</u>	Inductive sensor
AT1/CP-1B	Inductive sensor
<u>AT1/CP-1H</u>	Inductive sensor
<u>AT1/CP-2A</u>	Inductive sensor
<u>AT1/CP-2B</u>	Inductive sensor
<u>AT1/CP-2H</u>	Inductive sensor
<u>AT1/CP-3A</u>	Inductive sensor
<u>AT1/CP-4A</u>	Inductive sensor
AT1/CP-4H	Inductive sensor
<u>AT6/AN-1A</u>	Inductive sensor
AT6/AN-1H	Inductive sensor
<u>AT6/AN-2A</u>	Inductive sensor
AT6/AN-2H	Inductive sensor
<u>AT6/AN-3A</u>	Inductive sensor
AT6/AN-3H	Inductive sensor
<u>AT6/AN-4A</u>	Inductive sensor
<u>AT6/AN-4H</u>	Inductive sensor
<u>AT6/AP-1A</u>	Inductive sensor
<u>AT6/AP-1H</u>	Inductive sensor
<u>AT6/AP-2A</u>	Inductive sensor
<u>AT6/AP-2H</u>	Inductive sensor
<u>AT6/AP-3A</u>	Inductive sensor
<u>AT6/AP-3H</u>	Inductive sensor
	Inductive sensor
<u>AT6/AP-4H</u>	Inductive sensor
<u>AT6/BN-1A</u>	Inductive sensor
AT6/BN-1H	Inductive sensor
<u>AT6/BN-2A</u>	Inductive sensor





Product	Description
AT6/BN-2H	Inductive sensor
AT6/BN-3A	Inductive sensor
AT6/BN-3H	Inductive sensor
AT6/BN-4A	Inductive sensor
AT6/BN-4H	Inductive sensor
<u>AT6/BP-1A</u>	
AT6/BP-1H	Inductive sensor
<u>AT6/BP-2A</u>	Inductive sensor
AT6/BP-2H	Inductive sensor
<u>AT6/BP-3A</u>	Inductive sensor
AT6/BP-3H	Inductive sensor
AT6/BP-4A	Inductive sensor
<u>AT6/BP-4H</u>	Inductive sensor
<u>NX14SR/XAN-A010</u>	Area sensor Kit
NX14SR/XAP-A000	Area sensor Kit
NX14SR/XAP-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX14SR/XCN-AT10	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
<u>NX14SR/XCN-C010</u>	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX14SR/XCN-CT10	Area sensor Kit
NX16SR/XAN-C000	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAN-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAN-CT10	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAN-CT1020	Area sensor Kit
NX16SR/XAP-A010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAP-C010	Area sensor
NX16SR/XAP-C01020	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-A010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-AT10	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-AT1020	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-CT10	Area sensor Kit
<u>BS2/00-0C</u>	Photoelectric sensor Diffuse 100 mm cable 2m 90°
<u>BS2/00-0E</u>	CUBIC PHOTOELECTRIC SENSORS DECOUT
<u>BS4/00-0C</u>	Photoelectric sensor
<u>BS4/00-0E</u>	Photoelectric sensor
<u>BS6/00-0C86</u>	Photoelectric sensor
<u>BS8/00-0C</u>	Photoelectric sensor
<u>BS8/00-0C86</u>	Photoelectric sensor
<u>BS8/00-0E</u>	
<u>BSC/00-0C</u>	Photoelectric sensor
<u>BSC/00-0C86</u>	Photoelectric sensor
<u>BSC/00-0E</u>	Photoelectric sensor
<u>BV2/00-0C</u>	Photoelectric sensor
<u>BVC/00-0C</u>	Photoelectric sensor
<u>BVC/00-0E</u>	Photoelectric sensor





Product	Description
BX04R/AD-HB	MEDIUM RESOLUTION AREA SENSORS
BX04S/00-HB	MEDIUM RESOLUTION AREA SENSORS
BX04SR/0A-HB	MEDIUM RESOLUTION AREA SENSORS
BX04SR/0A-HB79	Area sensor Kit
BX10R/AD-HB2D	Area sensor receiver
BX10R/AD-HB70	Area sensor Receiver
BX10R/CD-ABVE80	Area sensor Receiver
BX10R/CD-ABVE806A	Area sensor Receiver
BX10R/CD-HB	Area sensor Receiver
BX10R/CD-HB6X	Area sensor Receiver
BX10S/00-ABVE80	Area sensor Emitter
BX10S/00-ABVE806A	Area sensor Emitter
<u>BX10S/00-HB6X</u>	Area sensor Emitter
<u>BX10S/00-HB70</u>	Area sensor Emitter
BX10S/X0-HB	Area sensor Emitter
BX10SR/0A-AB	Area sensor Kit
BX10SR/0A-ABAT	Area sensor Kit
BX10SR/0A-HB6XLS	Area sensor Kit
BX10SR/0A-HB6XSY	Area sensor Kit
<u>BX10SR/0A-HB74</u>	complete emitter+receiver kit
<u>BX10SR/0A-HB79</u>	Area sensor Kit
BX10SR/0A-HBAN	Area sensor Kit
BX10SR/0A-HBLS	Area sensor Kit
BX10SR/0A-HBLSAN	Area sensor Kit 10 beams adj. P+N DO conn. M12 A
BX10SR/0C-HB	Area sensor Kit
BX10SR/0C-HB6A	Area sensor Kit
BX10SR/0C-HB6XLS	Area sensor Kit
BX10SR/XA-HB	Area sensor Kit
BX80A/1N-0H	Area sensor Receiver
BX80A/1P-0H2D	Area sensor Receiver
BX80A/1P-0HAN	Area sensor Receiver
BX80A/1P-1A86	Area sensor Receiv
BX80A/1P-1HDA	Area sensor Receiver
BX80A/1P-2H	Area sensor Receiver
BX80A/2N-0H	Area sensor Receiver
<u>BX80A/2P-0H</u> <u>BX80A/2P-2H</u>	Area sensor Receiver 1,5m 10ms PNP NO/NC conn. Area sensor Receiver
<u>BX80A/3P-0H</u> BX80A/3P-1A	Area sensor Receiver Area sensor Receiver
<u>BX80A/3P-1A</u> BX80A/3P-1H	Area sensor Receiver
<u>BX80A/3P-2H</u>	Area sensor Receiver
<u>BX80A/4P-0H</u>	Area sensor Receiver
<u>BX80A/4P-0H</u> BX80A/4P-0H2D	Area sensor Receiver
BX80A/4P-1H	Area sensor Receiver
<u>BX80A/4P-2H</u>	Area sensor Receiver
0/00//41-211	הובמ שבוושטו וובניבועבו

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC !+ 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 19/23





Product	Description
<u>BX80A/5P-0H</u>	Area photoelectric sensors, Receiver
<u>BX80A/5P-2H</u>	Area sensor Receiver
<u>BX80B/1P-0H</u>	Area sensor
BX80B/1P-0H6XLS	Area sensor Receiver
<u>BX80B/1P-1H</u>	Area sensor
<u>BX80B/2P-0H</u>	Area sensor
<u>BX80B/3P-0H</u>	Area sensor Receiver crossed beam 1m 3ms PNP NO/NC conn.
<u>BX80B/4P-0H</u>	Area sensor Receiver
<u>BX80E/20-0H</u>	Area sensor Emitter
BX80S/10-0H6XLS	Area sensor Emitter
<u>BX80S/10-0H9K</u>	Sensor
<u>BX80S/10-0HAN</u>	Area sensor
<u>BX80S/10-1A86</u>	Area sensor
BX80S/10-1HDA	Area sensor
BX80S/10-1HDA74	Area sensor
<u>BX80S/10-2H</u>	Area sensor
<u>BX80S/20-0H</u>	Area sensor Emitt. adj. 1,5m 10ms connettore
<u>BX80S/20-2H</u>	Area sensor
<u>BX80S/30-0H</u>	Area sensor Emitter
<u>BX80S/30-1H</u>	Area sensor Emitter
<u>BX80S/30-2H</u>	Area sensor Emitter
<u>BX80S/40-0H</u>	Area sensor Emitter
<u>BX80S/40-1H</u>	Area sensor Emitter
<u>BX80S/40-2H</u>	Area sensor Emitter
<u>BX80S/50-2H</u>	Area sensor Emitter
CX0E1RP/05-016V	Area sensor Intrinsic optical
CX0E1RP/10-016V	
CX0E1RP/10-032V	Area sensor
CX2E0RA/05-016V	Area sensor
CX2E0RA/05-032V	Area sensor
CX2E0RA/05-048V	Area sensor
<u>CX2E0RA/05-048VTB</u>	Area sensor
CX2E0RA/10-016V	Area sensor
CX2E0RA/10-032V	Area sensor
<u>CX2E0RA/10-032VTB</u>	Area sensor
CX2E0RA/10-048V	Area sensor
CX2E0RA/10-064V	Area sensor
CX2E0RA/10-080V	Area sensor
CX2E0RA/10-096V	Area sensor
CX2E0RA/20-016V	Area sensor
CX2E0RA/20-032V	Area sensor
CX2E0RA/20-048V	Area sensor
CX2E0RA/20-064V	Area sensor
CX2E0RA/20-080V	Area sensor
CX2E0RA/20-096V	Area sensor





Product	Description
CX2E0RB/05-016V	Area sensor
CX2E0RB/05-048V	Area sensor
CX2E0RB/10-016V	Area sensor
CX2E0RB/10-032V	Area sensor
CX2E0RB/10-048V	Area sensor
CX2E0RB/10-064V	Area sensor
CX2E0RB/10-096V	Area sensor
CX2E0RB/20-016V	Area sensor
CX2E0RB/20-032V	Area sensor
CX2E0RB/20-048V	Area sensor
CX2E0RB/20-064V	Area sensor
CX2E0RB/20-080V	Area sensor
CX2E0RB/20-096V	Area sensor
CX2E0RF/05-016V	Area sensor
CX2E0RF/05-032V	Area sensor
CX2E0RF/05-048V	Area sensor
CX2E0RF/10-016V	Area sensor
CX2E0RF/10-032V	Area sensor
CX2E0RF/10-048V	Area sensor
CX2E0RF/10-064V	Area sensor
<u>CX2E0RF/10-080V</u>	Area sensor
CX2E0RF/10-096V	Area sensor
CX2E0RF/20-016V	Area sensor
CX2E0RF/20-032V	Area sensor
CX2E0RF/20-048V	Area sensor
CX2E0RF/20-064V	Area sensor
CX2E0RF/20-080V	Area sensor
CX2E0RF/20-096V	Area sensor
<u>C18P/A0-1A</u>	Capacitive sensor
<u>C18P/A0-1E</u> <u>C18P/A0-2A</u>	Capacitive sensor
<u>C18P/A0-2E</u>	Capacitive sensor Capacitive sensor
<u>C18P/BN-1A</u>	Capacitive sensor
<u>C18P/BN-1E</u>	Capacitive sensor
<u>C18P/BN-2A</u>	Capacitive sensor
<u>C18P/BN-2E</u>	Capacitive sensor
C18P/BP-1A	Capacitive sensor
C18P/BP-1E	Capacitive sensor
C18P/BP-2A	Capacitive sensor
<u>C18P/C0-1A</u>	Capacitive sensor
<u>C18P/C0-1E</u>	Capacitive sensor
<u>C18P/C0-2A</u>	Capacitive sensor
<u>C18P/C0-2E</u>	Capacitive sensor
<u>C30M/00-1A</u>	Capacitive sensor
<u>C30M/00-1E</u>	Capacitive sensor





Product	Description
<u>C30M/00-2A</u>	Capacitive sensor
<u>C30M/00-2E</u>	Capacitive sensor
<u>C30M/BN-1A</u>	Capacitive sensor
<u>C30M/BN-1E</u>	Capacitive sensor
<u>C30M/BN-2A</u>	Capacitive sensor
<u>C30M/BN-2E</u>	Capacitive sensor
<u>C30M/BP-1A</u>	Capacitive sensor
<u>C30M/BP-1E</u>	Capacitive sensor
<u>C30M/BP-2A</u>	Capacitive sensor
<u>C30M/BP-2E</u>	Capacitive sensor
<u>C30P/00-1A</u>	Capacitive sensor
<u>C30P/00-1E</u>	Capacitive sensor
<u>C30P/00-2A</u>	Capacitive sensor
<u>C30P/00-2E</u>	Capacitive sensor
<u>C30P/BN-1A</u>	Capacitive sensor
<u>C30P/BN-1E</u>	Capacitive sensor
<u>C30P/BN-2A</u>	Capacitive sensor
<u>C30P/BN-2E</u>	Capacitive sensor
<u>C30P/BP-1A</u>	Capacitive sensor
<u>C30P/BP-1E</u>	Capacitive sensor
<u>C30P/BP-2A</u>	Capacitive sensor
<u>C30P/BP-2E</u>	Capacitive sensor
CD08/0A-020A1	Connector
<u>CD08/0A-020A5</u>	Connector
CD08/0A-020C1	Connector
<u>CD08/0A-020C5</u>	Connector
CD08/0A-050A1US	Connector
<u>CD08/0A-050A5</u>	Connector
CD08/0A-050A5US	Connector
CD08/0A-050C1US	Connector
CD08/0A-050C5	Connector
CD08/0A-050C5US	Connector
CD08/0A-100A1US	Connector
<u>CD08/0A-100A5</u>	Connector
<u>CD08/0A-100A5US</u>	Connector
<u>CD08/0A-100C1</u>	Connector
CD08/0A-100C1US	Connector
CD08/0A-100C5US	Connector
CD08/0A-150A1US	Connector
CD08/0A-150A5US	Connector
<u>CD08/0A-150C1</u>	Connector
CD08/0A-150C1US	Connector
CD08/0A-150C5US	Connector
<u>CD08/0A-200A1</u>	Connector
<u>CD08/0A-200A5</u>	Connector





Product	Description
CD08/0A-200C1	Connector
CD08/0A-200C5	Connector
<u>CD08/0B-020A1</u>	Connector M8 Axial CEI 2022 II 4 poles cable 2 m
CD08/0B-020A5	Connector M8 Axial PUR 4 poles cable 2 m M8
CD08/0B-020C1	Connector M8 90° CEI 2022 II 4 poles cable 2 m
CD08/0B-050A1US	Connector M8 Axial 4 poles cable 5 m CSA
CD08/0B-050A5	Connector M8 Axial PUR 4 poles cable 5 m M8
CD08/0B-050A5US	Connector
CD08/0B-050C1US	Connector
CD08/0B-050C5	Connector M8 90° PUR 4 poles cable 5 m M8
CD08/0B-050C5US	Connector
CD08/0B-100A1US	Connector
CD08/0B-100A5	Connector
CD08/0B-100A5US	Connector
<u>CD08/0B-100C1</u>	Connector M8 90° CEI 2022 II 4 poles cable 10 m
CD08/0B-100C1US	Connector M8 90° 4 poles cable 10 m CSA
CD08/0B-100C5US	Connector
CD08/0B-150A1	Connector
CD08/0B-150A1US	Connector

Micro Detectors / Diell