







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





TECHNOR

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
<u>ZBWE101</u>	Base mounted NO contact element
XAWP8272 9 ENG	PORTABLE FIBERGLASS
XAWP882	console(Control Panel)
XAWP9421	White push button
XAWP9422	Black push button
XCKWD2102P16 (1117406)	HarmAtex Atex Limit Switch
331849_TEAXCKWJ210541H29	limit switch
XCWD2115L2	Position switch
XMLW-C300D2S12	pressure switch
ZBWE102 old code/ B090601040029	NF contact element mounted on base
<u>new code</u>	
XCWD2110L5	Position switch with fixing by the body with rectilinear movement by means of a metallic push button
<u>07-3711-12154000</u>	Control unit
<u>05-0056-0073</u>	Purge gas valve
<u>05-0056-0041</u>	Pressure reducer
ELBF351-001	control unit
XCKWD2145P16	Position switch
ZBWV3 B090602040011	GREEN LIGHT BULB
XCW-D2102L1	Spring return roller metal plunger
XBW5AS542 old code/ B090601040049	
new code	
XCW-D21F0L5	Position switch
XCWD2115L10	Position switch
XADW12110P11IC	box
<u>XCWD2110L1</u>	LIMIT SWITCH WITH METAL PLUNGER ACTUATOR
<u>XAWP9411</u>	White hooded push button head
XAWP9412	BT POUSSOIR CAPUCH. NOIR
XCKWM2110H29	limit switches
<u>FL-40IM</u>	
<u>FL-40HG</u>	
XCKWJ210541H29	Position switch
<u>B170112110 - 1 packet = 100 pcs.</u>	PLUG
<u>B141101010 - 1 packet = 100 pcs.</u>	GASKET
<u>B170112210 - 1 packet = 100 pcs.</u>	PLUG
<u>B141101020 - 1 packet = 100 pcs.</u>	GASKET
<u>B170112310 - 1 packet = 100 pcs.</u>	PLUG

Enapart Group

! Address 93 S Railroad Avenue Bergenfield NJ 07621 USA ! Onrion LLC ! + 1 862 3004034 ! sales@enapart.com ! www.onrion.com Page 1 /6





B141101030 - 1 packgt = 100 pcs. GASKET B170112410 - 1 packgt = 100 pcs. PLUG B17101040 - 1 packgt = 100 pcs. GASKET B170112510 - 1 packgt = 100 pcs. GASKET B170112510 - 1 packgt = 100 pcs. GASKET XCWD21151. XAWP06003791 XCWD21102 Position switch B600100501128 Position switch XCWD2121012 Position switch XCWD2121012 Position switch XCR1AIP11C XUM5AV053 A027711 Switch XCR1AIP11C Limit switch XCR1AIP115 Limit switch XCR1AIP116 Limit switch XCWD214511 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B000601040030 XEW5AS8442 buton XCWD21451 CONTACT BLOCK, SLOW BREAK ZWW101 ARROW FOR SINGLE	Product	Description
B170112410-1 packet = 100 pcs. PLUG B141101040-1 packet = 100 pcs. GASKET B141101050-1 packet = 100 pcs. PLUG B141101050-1 packet = 100 pcs. GASKET XCWD2115L GASKET XCWD2115L Position switch B090100501128 Position switch XQETAPLIC Position switch XQETAPLIC Position switch XQETAPLIC Switch XCETAPLIC Switch XCETAPLIC Switch XCETAPLIC Switch XCETAPLIC Limit switch XCETAPLIC CONTACT BLOCK, SLOW BREAK ZCWD21L1 CONTACT BLOCK, SLOW BREAK ZEWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY4951 ARROW FOR SINGLE STEP PUSHEDUTON (UP) ZBWY4952	<u>B141101030 - 1 packet = 100 pcs.</u>	
B170112510 - 1 packet = 100 pcs. PLUG B141101050 - 1 packet = 100 pcs. GASKET XQW02115L XXW0201531428 XQW02115L2 Position switch B090100501128 Position switch XQWP272[ENG] English labels YCWP272[ENG] English labels XQWP272[ENG] English labels Position switch XQWP272[ENG] English labels Switch XQRT11 PROJECTOR XQBTA1P11C Limit switch XCBTA1P151 Limit switch XCBTA1P152 Limit switch XCBTA1P141 Desition switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 XBW5A58442 button XCWD214511 CONTACT BLOCK, SLOW BREAK ZAWE102 CONTACT BLOCK, SLOW BREAK ZAWE102 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY29204 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY29204 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2920 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2920 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2920 ARROW FOR SINGLE S		PLUG
B141101050 - 1 packet = 100 pcs. GASKET XGWD2115L XGWD2115L XGWD2115L Position switch B090100501128 Position switch XGWD21F0L2 Position switch XGWD21F0L2 Position switch XGWD21F0L2 Position switch XGTAIP11C XLW5AV053 AQ27711 Switch A01011111311 PROJECTOR XGBTAIP15J Limit switch XGSTAIP141 Umit switch XGWD2145L1 Position switch with fixing through the body with angular movement by lever themoplastic roller adjustable B090601040030 Dation switch with fixing through the body with angular movement by lever themoplastic roller adjustable S090601040030 CONTACT BLOCK, SLOW BREAK ZGWE012 CONTACT BLOCK, SLOW BREAK ZGWE102 CONTACT BLOCK, SLOW BREAK ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (ICFT) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (ICFT) ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (ICFT) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (ICFT) ZBWY2954 ARROW FOR SINGLE STEP P	B141101040 - 1 packet = 100 pcs.	GASKET
XCWD2115L XAWP06003791 XCKW210513H29 Position switch B090100S01128 Position switch XCWD21EDL2 Position switch XAWP8272[ENG] English labels Position switch XCBTAILIO Processor XLWSAV053 Processor A027711 ProJECTOR A027711 Switch XCBTAIP11C Limit switch XCBTAIP11C Limit switch XCBTAIP11C Limit switch XCBTAIP11C Limit switch XCWD2145L1 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 XCWD2145L1 Position switch XCWD2145L1 Position switch ZCWD212 ZOWD21L1 CONTACT BLOCK, SLOW BREAK ZBWY2954 ZARE00 SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (UF) ZBWY29254 ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT) ZBWY29254 ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT) ZBWY29254 ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)	B170112510 - 1 packet = 100 pcs.	PLUG
XAWP06003791 XCKWJ210513H29 Position switch B090100501128 Position switch XCWD21E0L2 Position switch XAWP8272[ENG] English labels PROJECTOR XLWSAV053 A027711 A0101111311 PROJECTOR XCREW171 Switch XC8TA1P151 Limit switch XC8TA1P151 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 E0990601040030 XBW5AS8442 button ZCWD21L1 CONTACT BLOCK, SLOW BREAK ZOWD21L1 CONTACT BLOCK, SLOW BREAK ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBW74952 ARROW FOR SINGLE STEP PUSHBUTTON (IGHT) ZBW74952 <t< th=""><td>B141101050 - 1 packet = 100 pcs.</td><td>GASKET</td></t<>	B141101050 - 1 packet = 100 pcs.	GASKET
XCKWJ210513H29 Position switch B090100501128 Position switch XCWD21F0L2 Position switch A027711 Switch A0101111311 PROJECTOR XCRENNT1 Switch XCREATAIP161 Limit switch XCRTAIP162 Limit switch XCRTAIP161 Limit switch XCREATAIP162 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 SUMPASS8442 button XCKWMR54D1H29EX Position switch ZCWD2111 CONTACT BLOCK, SLOW BREAK ZEWY102 CONTACT BLOCK, SLOW BREAK ZEWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (DOWN) ZEWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) <	XCWD2115L	
B090100S01128 XCWD21E0L2 Position switch XAWP8272[ENG] English labels XaWF8272[ENG] English labels XCBTA1P11C XLW5AV053 A027711 PROJECTOR A0101111311 PROJECTOR XCBTA1P151 Limit switch XCBTA1P151 Limit switch XCBTA1P151 Limit switch XCBTA1P152 Distich XCBTA1P141 Distich XCBTA1P151 Limit switch XCBTA1P151 Limit switch XCBTA1P141 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 StaW5A58442 B090601040030 Dotton XCWD21141 CONTACT BLOCK, SLOW BREAK ZAWE102 CONTACT BLOCK, SLOW BREAK ZBWY2951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (CIEFT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2930 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2930 <td< th=""><td>XAWP06003791</td><td></td></td<>	XAWP06003791	
XCWD21E0L2 Position switch XAWP8272[ENG] English labels XCBTA1P11C XLW5AV053 A027711 A0101111311 PROJECTOR XCBFW171 Switch XCBTA1P151 Limit switch XCBTA1P141 Limit switch XCBTA1P141 Limit switch XCBTA1P141 Limit switch XCWD2145L1 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 E090601040030 XBW5AS8442 button XCKWME54D1L29EX Position switch ZCWD21L1 CONTACT BLOCK, SLOW BREAK ZBWY1951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY1951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY1 White LED signaling element B06030101011 White LED signaling element XGWD21151 Position switch XGWD21151 Position switch <t< th=""><td>XCKWJ210513H29</td><td>Position switch</td></t<>	XCKWJ210513H29	Position switch
XAWP8272[ENG] English labels X08TA1P110 A0101111311 PROJECTOR XCRFW171 Switch XCRFW171 Switch XCRTP110 Switch XCRFW171 Switch XCRTP111C Limit switch XCRTATP111C Limit switch XCRTATP111C Limit switch XCRTATP111C Limit switch XCRTATP1124 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 XBW5AS8442 button XCWD21L1 CONTACT BLOCK, SLOW BREAK ZCWD21L1 CONTACT BLOCK, SLOW BREAK ZAWE102 CONTACT BLOCK, SLOW BREAK ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (DOWN) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2300 Iabel ZBSAS834 Punch button XAWP08UDLRFR3ES1	<u>B090100S01128</u>	
XC8TA1P11C XLW5AV053 A027711 A0101111311 PROJECTOR XCRFW171 Switch XC8TA1P151 Limit switch XC8TA1P151 Limit switch XC8TA1P151 Limit switch XC8TA1P141 Limit switch XC8TA1P141 Limit switch XC8TA1P142 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 Dutton XCKWMR54D1H29EX Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable ZGWD21L1 CONTACT BLOCK, SLOW BREAK ZGWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (DOWN) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4901 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2930 Iabel ZBWY2330 Iabel ZBWY2304 SIGNALLING LIGHTING FIXTURE A04014131 O230 SIGNALLING LIGHTING FIXTURE ZBWY1 White LED signalling element B060301010011 Push button XAWP08UDLRFR3E	XCWD21F0L2	Position switch
XLW5AV053 A027711 A0101111311. PROJECTOR XCRFW171 Switch XCBTAIP151 Limit switch XCBTAIP151 Limit switch XCBTAIP151 Limit switch XCBTAIP141 Limit switch XCWD2145L1 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 button XCKWMR54D1H29EX Position switch ZCWD2111 CONTACT BLOCK, SLOW BREAK ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (DOWN) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2905 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2905	XAWP8272[ENG] English labels	
A027711 PROJECTOR A0101111311 PROJECTOR XCRFW171 Switch XCRFW171 Switch XCRTAIP151 Limit switch XC8TA1P110 Limit switch XC8TA1P141 Limit switch XCWD2145L1 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 Dutton XCWD2145L1 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 Dutton XCWMD4401H29EX Position switch ZGWD21L1 CONTACT BLOCK, SLOW BREAK ZAWE102 CONTACT BLOCK, SLOW BREAK ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2904 SIGNALLING LIGHTING FIXTURE A041431 O230 SIGNAL	XC8TA1P11C	
A0101111311PROJECTORXCREW171SwitchXCREW171SwitchXCRTAIP151Limit switchXC8TAIP161Limit switchXC8TAIP161Limit switchXC8TAIP161Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030Vertex Position switchXCWD214511Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030Vertex Position switchXCWD21L1CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2300IabelZ55AS834IabelA041431 O230SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB060301010011Punch buttonXAWP08UDLRFR3ES1Punch buttonXCWD21151Position switchZBW4B8241Push buttonXC8JC1613P111CLimit switchXBW5AG41Selector switch	XLW5AV053	
XCREW171SwitchXC8TA1P15Limit switchXC8TA1P110Limit switchXC8TA1P1110Limit switchXC8TA1P111Limit switchXCWD2145L1Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030StatusXCWD2145L1Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030StatusXCWD2145L1Position switch fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030StatusXCWWR54D1H29EXPosition switchZCWD211CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330IabelZBWY2330IabelZBSA834SIGNALLING LIGHTING FIXTUREZBWY1White LED signalling elementB06030101011SIGNALLING LIGHTING FIXTUREXBW4B8442Punch buttonXCWD211511Position switchZBW4102XBW4BA21XBW4BA21Push buttonXC8LC10131P110CLimit switchXBW5AG41Selector switch	<u>A027711</u>	
XC8TA1P15ILimit switchXC8TA1P11ICLimit switchXC8TA1P11ICLimit switchXC8TA1P14ILimit switchXCWD2145L1Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030buttonXEW5AS8442buttonXCKWMR54D1H29EXPosition switchZCWD21L1CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (IEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2903ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2930BabelZBWY2330IabelZBWY2330SIGNALLING LIGHTING FIXTUREZBWY1White LED signalling elementB06030101011White LED signalling elementXGWD2115L1Position switchZBW4B8442Punch buttonXGWD2115L1Push buttonXGWD2115L1Push buttonXBW4B821Push buttonXBW4B821Push buttonXC8JC161P11CLimit switchXBW5AG41Selector switch	<u>A0101111311</u>	PROJECTOR
XC8TA1P11IC Limit switch XC8TA1P14I Limit switch XCWD2145L1 Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustable B090601040030 Environment of the body with angular movement by lever thermoplastic roller adjustable XBW5AS8442 button XCKWMR54D1H29EX Position switch ZGWD21L1 CONTACT BLOCK, SLOW BREAK ZBWY4951 ARROW FOR SINGLE STEP PUSHBUTTON (UP) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (DOWN) ZBWY2954 ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2904 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTON (LEFT) ZBWY10 White LED signalling element B06030101011 White LED signalling element XGWD2115L1 Position switch ZBWE102	XCRFW171	Switch
XC8TA1P14!Limit switchXCWD2145L1Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030XBW5A588442buttonXCKWMR54D1H29EXPosition switchZCWD21L1CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (BIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2330IabelZBWY2330SIGNALLING LIGHTING FIXTUREZBWY1White LED signalling elementB060301010011White LED signalling elementXGWD2115L1Position switchZBWE102Punch buttonXGWD2115L1Push buttonXG8JC161P11CLimit switchXG8JC161P11CLimit switchXBW5AG41Selector switch	XC8TA1P15I	Limit switch
XCWD2145L1Position switch with fixing through the body with angular movement by lever thermoplastic roller adjustableB090601040030buttonXBW5AS8442buttonXCKWMR54D1H29EXPosition switchZCWD21L1CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY2905SIGNALLING LIGHTING FIXTUREZBWY2904SIGNALLING LIGHTING FIXTUREZBWY1White LED signalling elementB06030101011Supported Step Pushed Step Pu	XC8TA1P11IC	Limit switch
ACWD2[143L]thermoplastic roller adjustableB090601040030XBW5AS8442buttonXCKWMR54D1H29EXPosition switchZAWE102CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (EIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (EIGT)ZBWY2300IabelZBWY2330IabelZBWY2330SIGNALLING LIGHTING FIXTUREZBWY1White LED signalling elementB060301010011Punch buttonXBW4BS8442Punch buttonXAWP08UDLRFR3ES1Push buttonXCWD2115L1Position switchXBW4BA21Push buttonXC8JC161P11CLimit switchXBW5AG41Selector switch	<u>XC8TA1P14I</u>	Limit switch
XBW5AS8442buttonXCKWMR54D1H29EXPosition switchZOWD21L1CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2300IabelZBSAS834IabelZBMY1White LED signalling elementB06030101011White LED signalling elementXAWP08UDLRER3ES1Punch buttonXCWD2115L1Position switchZBWE102YBW4BA21XC8JC161P11CLimit switchXBW4BA21Selector switchXBW5AG41Selector switch	XCWD2145L1	
XCKWMR54D1H29EXPosition switchZCWD21L1CONTACT BLOCK, SLOW BREAKZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY4901ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330IabelZBSAS834SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB060301010011Vhite LED signalling elementXBW4BS442Punch buttonXCWD2115L1Position switchZBWE102XBW4BA21XC8JC161P11CLimit switchXC8JC10131P111CLimit switchXBW5AG41Selector switch	<u>B090601040030</u>	
ZCWD21L1ZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY4901ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330labelZB5AS834IabelZB5AS834SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB060301010011Punch buttonXAWP08UDLRFR3ES1Position switchZBWE102XBW4BA21XBW4BA21Push buttonXC8JC161P11CLimit switchXBW5AG41Selector switch	XBW5AS8442	button
ZAWE102CONTACT BLOCK, SLOW BREAKZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY4901ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330IabelZBWY2330IabelZBWY2330SIGNALLING LIGHTING FIXTUREZBWY1White LED signalling elementB060301010011Punch buttonXBW4BS8442Punch buttonXCWD2115L1Position switchZBWE102XBW4BA21XBW4BA21Push buttonXC&JC161P11CLimit switchXBW5AG41Selector switch	XCKWMR54D1H29EX	Position switch
ZBWY4951ARROW FOR SINGLE STEP PUSHBUTTON (UP)ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY4901ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2300IabelZBSAS834IabelA041431 O230SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB06030101011Vhite LED signalling elementXBW4BS8442Punch buttonXAWP08UDLRFR3ES1Position switchZBWE102SUGNALLING HUTONXBW4BA21Push buttonXC8JC161P11CLimit switchXC8JC10131P111CSelector switch	ZCWD21L1	
ZBWY2954ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)ZBWY4901ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330labelZBSAS834IabelZBWY1White LED signalling elementB060301010011White LED signalling elementXBW4BS8442Punch buttonXAWP08UDLRFR3ES1Position switchZBWE102XCWD2115L1XBW4BA21Push buttonXC8JC161P11CLimit switchXC8JC10131P11ICSelector switch	ZAWE102	CONTACT BLOCK, SLOW BREAK
ZBWY4901ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330labelZBSAS834A041431 O230SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB060301010011XBW4BS8442Punch buttonXAWP08UDLRFR3ES1XCWD2115L1Position switchZBWE102XBW4BA21Push buttonXC8JC161P11CXC8JC10131P11ICLimit switchXBW5AG41Selector switch	ZBWY4951	ARROW FOR SINGLE STEP PUSHBUTTON (UP)
ZBWY2904ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY4952ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)ZBWY2330labelZB5AS834IabelA041431 O230SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB060301010011Image: Step Push ButtonXBW4BS8442Punch buttonXAWP08UDLRFR3ES1Image: Step Push ButtonXCWD2115L1Position switchZBWE102Image: Step Push ButtonXC8JC161P11CImage: Step Push ButtonXC8JC10131P111CLimit switchXBW5AG41Selector switch	ZBWY2954	ARROW FOR SINGLE STEP PUSHBUTTON (DOWN)
ZBWY4952 ARROW FOR SINGLE STEP PUSHBUTTON (LEFT) ZBWY2330 label ZB5AS834	ZBWY4901	ARROW FOR SINGLE STEP PUSHBUTTON (RIGHT)
ZBWY2330 Iabel ZB5AS834 A041431 Q230 SIGNALLING LIGHTING FIXTURE ZBWV1 White LED signalling element B060301010011 XBW4BS8442 Punch button XAWP08UDLRFR3ES1 XCWD2115L1 Position switch ZBWE102 XBW4BA21 Push button XC8JC161P11C XC8JC10131P11IC Limit switch XBW5AG41 Selector switch	ZBWY2904	ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)
ZB5AS834A041431 O230SIGNALLING LIGHTING FIXTUREZBWV1White LED signalling elementB060301010011XBW4BS8442Punch buttonXAWP08UDLRFR3ES1XCWD2115L1Position switchZBWE102XBW4BA21Push buttonXC8JC161P11CXC8JC10131P11ICLimit switchXBW5AG41Selector switch	ZBWY4952	ARROW FOR SINGLE STEP PUSHBUTTON (LEFT)
A041431 O230 SIGNALLING LIGHTING FIXTURE ZBWV1 White LED signalling element B060301010011 White LED signalling element XBW4BS8442 Punch button XAWP08UDLRFR3ES1 Position switch ZBWE102 Push button XBW4BA21 Position switch XC8JC161P11C Push button XC8JC10131P11IC Limit switch XBW5AG41 Selector switch	ZBWY2330	label
ZBWV1 White LED signalling element B060301010011	ZB5AS834	
B060301010011 XBW4BS8442 Punch button XAWP08UDLRFR3ES1 Position switch XCWD2115L1 Position switch ZBWE102 Push button XC8JC161P11C Push button XC8JC10131P11IC Limit switch XBW5AG41 Selector switch		
XBW4BS8442Punch buttonXAWP08UDLRFR3ES1XCWD2115L1ZBWE102XBW4BA21XC8JC161P11CXC8JC10131P11ICXC8JC10131P11ICXBW5AG41Selector switch		White LED signalling element
XAWP08UDLRFR3ES1XCWD2115L1Position switchZBWE102XBW4BA21Push buttonXC8JC161P11CXC8JC10131P11ICLimit switchXBW5AG41Selector switch		
XCWD2115L1Position switchZBWE102XBW4BA21XC8JC161P11CXC8JC10131P11ICXC8JC10131P11ICXBW5AG41Selector switch	XBW4BS8442	Punch button
ZBWE102 XBW4BA21 Push button XC8JC161P11C Limit switch XC8JC10131P11IC Selector switch		
XBW4BA21 Push button XC8JC161P11C		Position switch
XC8JC161P11C XC8JC10131P11IC XBW5AG41 Selector switch		
XC8JC10131P11IC Limit switch XBW5AG41 Selector switch		Push button
XBW5AG41 Selector switch	XC8JC161P11C	
XBW5AD41		Selector switch
	XBW5AD41	





Product	Description
XBW4BS9442	
B011000S00006	Pendant control unit
<u>A600903030008</u>	
PSRC-C-220	COMMUTATOR
XCWD2102L2	Position switch with body fixing
XAWP08MDGDAAM0	Hanging box 8 units XAWP089 GRP
XAWP08MDGDAAMES1	Hanging box 8 units
XCWD4102L5	Position switch with body fixing
XCWD41F0L5	Position switch
P/N: 119476, Type: CES-I-AR-M-C04-	MULTICODE SAFETY SWITCH
<u>U10-119476</u>	
XAWP6271	Control box
XBW5AS	MUSHROOM BUTTON WITH ROTATING UNLOCK
<u>A042600</u>	Fluorescent light
<u>A054552</u>	switch
XAWP52325057	control box
ZCWE02	STEEL ROLLER PUSH
XBW5AS8442-XAWP	
ZB8MA02 SAV	Push Button
ZC1BF0101 SAV	Kit
ZB8MA04 SAV	Push Button
ZC1BF0103 SAV	Kit
ZC1BF0105 SAV	Kit
<u>B090100S00057</u>	limit switch
XLW5AV013	LED indicator light
<u>XLW5AV043</u>	LED indicator light
<u>XLW5AV033</u>	LED indicator light
XAWP0824MUD01	Button box
XAWP08UDLRFRHS11	Hanging box of 8 units
<u>B090602040010</u>	Lamp
<u>A054452</u>	
XCKWJ2161H29	METAL END PLUNGER LIMIT
XCKWJ2161H29 (cable entry for Ø8 to	Position switch
<u>13mm cable)</u>	Hanging boy
XAWP8272[ENG]	Hanging box Position switch
XCKWJ210559H29 ZBWE-101 (lth:10A)	Position switch
ZBWE-102 (lth: 10A)	
<u>ZBWE-102 (itn: 10A)</u> XCWD2102L5	
XCWD2102L5 XCWD4102L10	Position switch
XAWP672[ENG] English labels	control box
XAWP072[ENG] English labels XAWP4272	
XBW5AP42	Pushbutton
ZB8MD01 SAV	BT TOURN. MANET. 2POS SAV
ZB8MD01 SAV ZB8MD03 SAV	

Enapart Group





Product	Description
XC8JC161P14I	Position switch
XAWG504	
XCWD21F0L1	Position switch
<u>B090601000010</u>	
<u>B090603000015</u>	
<u>A027618</u>	
XBW5AJ21	rotating button
ZC1BF0102 SAV	Replacement KIT
XLW4BP4832	push button
XBW4BD21	push button
XBW4BG41	switch
XLW4BV013	indicator
XLW4BV053	indicator
ZCWD21L5	position switch
XAWP16ESFRUDLR1.2	control station
ZCWE01	
ZCWY12	
<u>B016Y12117935</u>	
<u>B090603000022</u>	PSRC-C-220 — SWITCH
<u>B090602000030</u>	RED LUMINOUS GEM
XAWP08UDLRFR21	
XAWG8DMGD03AU	
XAWG8DMGD03AU (with 2 more	
<u>contacts)</u>	
<u>XBW4BS8445</u>	
XAWP94SC	
XAWP92SC	
PSRC-220	DISCONNECTOR
XBW4BP31	GREEN EX BUTTON
XBW4BP42	RED EX BUTTON
<u>B090601040003</u>	
<u>A500923600001 EB-236 (EX-D) -</u> <u>220/240V 50/60HZ</u>	
A020143610003 RMS-560-02/PNL -EX	
<u>DE- 2X36W</u>	
<u>11/118514-01</u>	
XCRF171	
XAWP08002608 SV	
<u>A027714</u>	
XAWP04003125	
<u>B090602000027</u>	
<u>B090602000011</u>	
XAWP94MD	
ZBWV3	Indication light
XCWD4116L5	

Enapart Group





Product	Description
A027712	PILOT LAMP
A027611	TRIP RESET PUSH BUTTON
XBW5AS8342-XAWP	
XAWP08UDLRFR0ES2 SV	
<u>B090601040049</u>	
<u>B011043010149</u>	
C010111100001	
<u></u> <u>C070700000014</u>	
C07070000002	
<u></u> <u>C070800040005</u>	
XBW5AD21	
XAWZ3	BLANK PLATE
XAWP682	
XAWP682 9	
XAWP882 9	
XAWP882 SV	
XAWP682 SV	
XCKWM2106H29	
<u>XBW5AP31</u>	Push button with protruding impulse with green cap and plastic collar (1 NO 10A)
XBW5AP21	Black capped overhead push button with 1 NO 10A plastic collar
XBW5AP41	Push button with protruding impulse with red cap and plastic collar (1 NO 10A)
XBW5AD33	Full green 400V transformer light
XBW8MV3V5	PILOT LIGHT
XBW8MV4V5	PILOT LIGHT,
P/N: B1301.514005, Type: XBW4BG21	black switch
P/N: B1307.000369, Type: ZBWE101	Contact element NO
XAWG003784	CONTROL BOX
XLW4BV033	LED green light and metal collar
<u>XLW4BV043</u>	Red LED light and metal collar
<u>PLD10</u>	white indicator light head and body
A021441800002 G2X-218 -EX NA- 2X18W	
<u>A601102010015</u>	
<u>TNAE151510</u>	stainless steel junction box
XAWP8272 SV ENG	
<u>B090100S00470</u>	
<u>XAWP9413</u>	
F-395.PA/230/1700	
F-250.50-4/000/1800	outlet valve
<u>B130700099000</u>	NC contacts
<u>B090601000004</u>	Buttons
<u>B090602000026</u>	GEMMA LUMINOSA
<u>B090602000016</u>	
<u>B090601000005</u>	
<u>B090601000006</u>	





Product	Description
<u>B090603000016</u>	
<u>B090603000013</u>	
B090601040003 XBW4BP31S	
B090601040011 XBW4BP42S	
<u>B090601040033 + B090601040030</u> <u>XBW4BL45</u>	
B090601040002 XBW4BP21S	
ZCWE24	
<u>B090601030001</u>	
<u>B090601030002</u>	
<u>B1310.000201</u>	Emergency push button
XAWP06UDLR0ES1	
<u>B090603000010</u>	PSRC-D-220 — DIVERTER
<u>B012074010114</u>	Selector switch
<u>B040I12265901</u>	
<u>B040I12265902</u>	
<u>B090601000014</u>	BLACK BUTTON
<u>B090602000005</u>	MONOLED RED
<u>B090602040001</u>	pilot lights 24V to 254V AC/DA current from 2 to 10 mA
<u>B090601000015</u>	
<u>B090601000016</u>	
XC8-JC10111P11C	LIMIT SWITCH