



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Alre

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

| Product | Description |
|---|---|
| EKFM2/0-10/100 | built-in duct sensor |
| JA060100 / JSF-1E | flow protector |
| 1599254 | ALRE Differenzdruck-Schalter |
| G8000004 / JSL-20 | airflow monitor |
| p/n: JA010100; Type: HI-1 | Channel hygostat mech. |
| ATR83.100 | thermostat |
| KR 85.400-5 | regulator |
| P/N: C1850506 Type: KR 85.406-2 | Double thermostat |
| KR 80.309 - C1801590 | |
| P/N: JA070100 Type: JSL-1E | Air flow sensing relay |
| P/N: D4780041 Type: ETR 78.005 | Differenz-Temperaturregler |
| H5309098 / JDL-111 | Differential pressure switch |
| P/N: G9030200 Type: HFC 10/S | |
| P/N: G9030140 Type: HFP 100/S | Hülsenfühler |
| P/N: G9040010 Type: AFP 100 | Außentemperaturfühler |
| P/N: H530996 Type: JDW-5 | Differential pressure switch |
| H530996 / JDW-5 | Differential pressure switch |
| P/N: H531000, Type: JDW-5 Z | Differential pressure switch with angle bracket |
| G9240020 | |
| H530960 / JDL 116 | differential pressure switch |
| P/N: G9240020 Type: MUD/4-20/0.16 | Druckmessumformer für Fluide und Gase |
| P/N: H5309136 Type: JDL-115 | |
| H5309136 | Pressure switch |
| JDL-112 | Differential pressure switch |
| C1850506 / KR 85.406-2 | Double boiler thermostat |
| P/N: H531001 Type: JDW 3-Z | Differential Pressure Switch |
| P/N: JA042200 Type: JET-130 XF | SWITCH, THERMOSTAT |
| P/N: JA044800 Type: JTF-112 | THERMOSTAT, FROST PROTECTION |
| P/N: E6090330 Type: JTF-21/12 | THERMOSTAT, ANTI-FREEZE |
| JDL-112 (H5309100) | Differential pressure switch |
| P/N: JA060100, Type: JSF-1E | Flow switch |
| KA000200 | Universalkapillarthmostat |
| KA999901 | fastening set |
| KA000201 | Universal capillary thermostat |
| KA969903 | sensor well |
| H5309136 / JDL 115 | Differential pressure switch |

| Product | Description |
|---|--|
| JSF-1 E (JA060100) | Flow switch |
| C1801743 | thermostat |
| G9270020 | differential pressure sensor |
| H5309229 | connection set with duct connections made of plastic |
| KA000200 / RTKSA-002.410 | |
| IT RTKSA-001.300 | Universal Capillary Thermostat KA000102 |
| KA969901 | Thermowell |
| IT JZ-29 | Mounting kit |
| 1599244 | |
| 1599252 JDL-112 | differential pressure switch |
| RTBSS-111.250/05 | ALRE Control Cabinettherm |
| JA060300 / JSF-2 E | flow switch |
| JA070100 | Industrial Relay |
| JBT-22A | Electronic twostage controller |
| RTKSA-000.200 (KA000001) | Universal capillary thermostat KA000001 |
| E6090301 / JTF-1 | antifreeze thermostat |
| JDL-115 / H5309136 | differential pressure switch |
| JA046200 / JET-120 RF | |
| KTRTB-251.108 | thermostat |
| E6120077 / JTL-17 NR | Air heater thermostat |
| JMT-206 X | capillary thermostat |
| JSF-1E | flow switch |
| G8000300 | dew point sensor |
| D4780587 | dew point monitor |
| JTL-8 | Air heater thermostat |
| G8000428 / WSERD-134.446 | Airflow monitor |
| KA001100 / RTKSA-014.210 | universal capillary thermostat |
| KA979901 / THK-2-100x17 | Immersion sleeve |
| KA999902 / JZ-30 | mounting kit |
| RTKSA-003.310+THK-2-100+JZ-29 | Universal capillary thermostat |
| KR 80.310 | Universal capillary thermostat |
| JTL 11 | |
| P/N: E6090328, Type: JTF-1/12 | 1-stage 12m capillary frost protection thermostat |
| Type: JSF-1RE (JA060200) | Flow Monitor |
| E6090320 / JTF-21 | Frost protection thermostat |
| JZ-05/6M | Mounting clips (metal) |
| JZ-05/6K | mounting clips |
| JZ-04 | Capillary tube outlet for air ducts |
| E6100048 / JTU-5 | Duct thermostat |
| JDI-0 | |
| E 6060011 / JMT-202 X | Two stage thermostat |
| KTRRN-267.014 | Control cabinet thermostat |
| JMT-203XF | |
| H530978 / JDL-116 A | Differential pressure switch |
| G8000299 / TPS 1 | Dew point sensor |

| Product | Description |
|--|--|
| D4780572 / WFRRN-210.018 | Dew point monitor |
| D4780587 / WFRRN-240.018 | Dew point monitor |
| RTKSA-204.020 | antifreeze thermostat |
| RTKSA JZ-31 KA999903 | RTKSA JZ-31 pipe mounting attachment controller KA999903 |
| JTL-8NRW(TW/STB) | |
| RTKSA-001-301 | IMMERSION THERMOSTAT |
| THK-2-100 | POCKET |
| E6120038 / JTL-8 NR | Air heater thermostat |
| JZ-29 | |