



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Barksdale

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
p/n: 0111-507; Type: UNS-PA16-PA18-G3/4	
0113-182 / UNS2000	COMPLETE SENSORS WITH electrical boxes.
0303-029	Limit Switch GK03 incl. 3 m Silicon cable
0402-056 D2T-M150SS	PRESSURE OR VACUUM ACTUATED SWITCH
P/N: 0401-432 Type: D2T-M80SS-ST3	Pressure switch
0403-076 / E1H-H15-P7	pressure switch
0417-015 / 8151-PL1-B	Pressure switch
9221-PL1-V (0419-002)	pressure switch
0419-020	Special pressure switch
205R6WC3	Valve
316030	Trockenschutzschalter
96101-BB1	Pressure Switch
0405-280 / B2T-H32SS	Pressure switch
BFS-10-N-G1/4-MS-NO-ST 0,4 - 2 l (0711-256.5)	
BFS-10-N-G1/2-SS-WE-ST	Flow rate: 2-7 ml / min350 bar1 ~ 230 V - 1.5 A - 50 VA
BNA-S22-3/4"150-RF VA30/02-MA-LM 1.0-1.50m (0332=1037)	
0401-136 / D1T-H18SS	pressure switch
0401-215	pressure switch
0401-224 / D1T-M80SS	pressure switch
DPD1T-M150SS (p/n 0402-056)	Diaphragm Differential Switch
E1H-H250-P7	pressure switch
E1H-H500	
E1H-H90-P4 (0403-126)	Druckschalter
KLM-025-M4-ST0-1	Pressure switch
p/n: 0601-048; Type: ML1H-H202S	Temperature switch
0402-082, DPD2T-GH18SS-EXI	
0602-061 / L2H-H354S	temperature switch
P/N: 0711-259.5, Type: BFS-10-N-G1/4-SS-NO-ST	Optical flow controller
0402U101 / CD2H-M150SS	pressure switch
0711-347.4	Strömungswächter
D2X-H18SS-UL-S0084	Explosion Proof Diaphragm Pressure Switches
0401-432	PRESSURE SWITCH
B1T-H12SS	Druckschalter
UPA2/11bA/420/G1/4E/M12/ F (0431-409)	Electronic Pressure Transducer UPA2
0406-021 / C9622-2	Pressure switch

Product	Description
96211-BB4-T2 (0406U081)	
ML1H-H354-WS (0601-096)	Temperaturschalter
D2T-M80SS (0401-416)	pressure switch
0405-318 / B2T-M48SS	pressure switch
DPD1T-M3SS	pressure switch
HDIXHH80SSUL	Druckschalter
0801-142	Valve
9045ROAC3	Ventil
96101-BB2	Sealed Piston Pressure Switch
9653-2-WA	Pressure Switch
0423-125 / UDS3V3/400bar/4-20 mA	Electric pressure switch
E1H-H15-P7-GL	Membran-Kolben-Druckschalter
0221-357	
pn 0113-776 / UNS2000-ABS/VA/FLS-PG-PE33-L2/3.3-Dual Lo268	
BPS312VM0050BP	pressure switch
0112-729	float switch
PN: 0711-260.7, Type: BFS-10-N-G1/2-SS-NO-ST	
905-0211	
P1H-M340	Druckschalter
DPD2T-M80SS-EXI	Druckschalter
BFS-10-N-G1/2-MS-NO-M12 2,0 ... 7,0 l/min/Sonder	
D2T-GH18SS-P2-Exi	
0401-216	Druckschalter
D1T-H2SS-EXI	Druckschalter
D1T-H3SS-Exia	Pressure switch
0401-168 D1T-H3SS-EXI	Pressure Switch / Druckschalter
D1T-H2SS-EX1 (0401-155)	Pressure Switch / Druckschalter
0405U001	
KLM-025-M4-ST0-1 - OEM	pressure switch
0407U036 / 9048-4	pressure switch
96201-BB4-T2	compact pressure switch
96211-BB6-T2	pressure switch
96211-BB1-T2-Z17	Compact Pressure Switch
96221-BB1	Compact Pressure Switch
0406-050 / 9675-4	pressure switch
0406U096 / A9675-4-AA	Pressure switch
0406U006	Sealed Piston Pressure Switch
0406-010 / C9612-3	Pressure switch special
0401-331 / D2T-A80SS	diaphragm pressure switch
E1H-H15-P6-PLS	
0403U082	Pressure switch UL + CSA
E1H-H90-BR	pressure switch
0412-018 / MSPS-JJ100SS	Industrial Pressure Switch
CSK12-11-41B	Mechanical Pressure Switch
CSK16-12-33B	Compact Pressure Switch

Product	Description
0404-128 / P1H-K85	pressure switch
P1H-B340SS	Dia-Seal Pistons
0404-110 / P1H-K30SS-T	pressure switch
(0412-019) MSPS-JJ15SS	pressure switch
MSPS-FF100SS	Industrial Pressure Switch
MSPS-FF15SS-E	pressure switch
CSP13-31-12B	
0406U085 / 96201-BB3	Pressure Switch
0406-038 / 96201-BB3-T2	Compact Switch
96201-BB3-T4	Pressure switch
96211-BB1-T2	Mechanical Pressure Switches
96211-BB3-T1	Mechanical Pressure Switch
96211-BB3-T2	pressure switch
96211-BB4-T2	compact pressure switch
96221-BB1-T4	
0403-028 / E1H-GH250-P4	Econ-O-Trol Switch
0403-035 / E1H-GH90-P4	pressure switch
0403-059 / E1H-H15-P4	Econ-O-Trol Pressure Switch
E1H-H15-F2	Pressure Switch
0403-069 / E1H-H15-P6	pressure switch
0403-075 / E1H-H15-P6-V	pressure switch
0403-520 / E1H-H250-F2	Econ-O-Trol Switch
0403-080 / E1H-H250-P4	pressure switch
E1H-H250-P6	pressure switch
0403U084 / E1H-H500-F2	UL listed Pressure switch
P/N: 0403-105, Type: E1H-H500-P4	pressure switch
0403-138 / E1H-H90-P6	pressure switch
E1H-M15-P4-V	Prerssure switch
E1H-M90-V	Econ-O-Trol Switch
0403-184 / E1H-R250-P4	Econ-O-Trol Switch
E1S-H15-P4 (p/n 0403-216)	Pressure Switches
E1S-H90	pressure switch
E1S-H90-P4	pressure switch
E1S-M250-V	pressure switch
E1S-M90-V	pressure switch
EPD1H-BB40	Differential Pressure Switch
724S-43-2B	
VCD1H-A18SS	
0402U192 / CD2H-M80SS	Pressure Switch
D2T-H2SS	Druckschalter
D2T-M2SS	pressure switch
0401U697 / D1T-A3SS	Pressure Switch
0401-870 / D2T-A3SS	pressure switch
D2T-H18SS (0401-373)	pressure switch
0401-209 / D1T-M18SS	pressure switch

Product	Description
D2T-M18SS	pressure switch
P/N: 0401-224, Type: D1T-M80SS	Terminal Block Diaphragm Switch
0401-416 / D2T-M80SS	diaphragm pressure switch
D2T-A150SS	Pressure Switch
D2T-M150SS	switcher
0401-074 / D1T-GH150SS	pressure switch
D2T-M2SS-P2	Terminal Block Diaphragm Switch
D2H-H18SS	diaphragm pressure switch
D2S-H18SS	diaphragm pressure switch
D1H-A80SS	Diaphragm Switch
D2H-M80SS	Mechanical Pressure Switch
D2H-GH80SS	Diaphragm Switch
0401U680 / D1H-A150SS	Pressure Switch
0401U718 / D2H-A150SS	Diaphragm Switch
D2H-M150SS	Diaphragm Switch
D1H-H3SS-P2	
0406U111 / 9681X-2CC-2	Explosion Proof Compact Switch
P/N: 0406u102, Type: 9692X-1CC-3	Ex-proof pressure switch
9AC1TB	Compact Pressure Switch
9EB1TV	pressure switch
96211-BB5-T2-P1	Compact Switch
P/N: 0431-341 Type: UPA2-LMP307	Probe
P/N: 0111-203 Type: UNS-PA1/2 NPT-PA18	PVC cable on the side
0499-025	PVC cable with built-in. air hose
P/N: 0405-215, Type: B2S-H48SS	pressure switch
0406U097 / 9675-2	pressure switch
0404-114 / P1H-K340	Pressure switch
(316030) OEM	Dry circuit breakers
X1T-4100-40-GE140/166	Pressure switch
D1T-GM 3SS	Druckschalter
96201-BB2-T2	Pressure switch
8131-PL1-B	Druckschalter
D1X-GM150SS-EX	Druckschalter
UAS3/420/NA	El. Anzeigegerät
BPS32GVM0400B	pressure switch
0601-218 / ML1H-H351	temperature switch
0417-283 / 8001-PL1-B-EA1-GE261	Pressure switch
0111-201	Float switch
0111-203	
BPS342EM0400BP	
MSPS-XX100-Q96 / 0412U008	pressure switch
UNS2000-VA/T2NPT-KLS BN30-L1/3-VV Lo300 - OEM product	LEVEL TRANSMITTER
0113-182 (OEM)	Level Switch
0414-081	
0113-152	ONLY Mechanical Sensor

Product	Description
0431-093	
BPS32GVM0010B	
T2H-M154S-A	
50-ML1H-SB1	Temp switch
0111-396	Liquid Level Sensor
0402-056	
0401-388 / D2T-M150SS	pressure switch
0111-542, Type: UNS-VA1/8-K2/2-PP19/2(1) -Exi	
BPS31GVM0100B	El. pressure switch
BPS32NVM6000PP	
BPS32GVM0200B	pressure switch
E1H-M250-P6-PLS	Pressure Switch UL
0405-109	Pressure switch
0401U882 / D1X-J80SS-P2-UL	Pressure Switch
0111-751	Switch
0423-119 UDS3V3/50bar/4-20mA El.	
BPS342EM0010BP	
0401-154	Pressure switch TYPE D1T-H2SS
9692X-1CC-2	PRESSURE SWITCH
KLM-025-M4-ST0-1-V/ 0416-144	PRESSURE SWITCH
0401-853 D2T-A150SS	
0402U103	Druckschalter
Nr.: 0403-126, Type: E1H-H90-P4	pressure switch
0401-215 / D1T-M3SS	pressure switch
UPA1-040-Z21 (0437-036)	
E1H-H250-P7-Exi	pressure switch
0409-123 / X1T-4000-25-GE262	pressure switch
0407U007 / 9048-2-Z11	pressure switch
D1X-J150SS-UL	pressure switch
UNS-VA1/8-K3-VA27/1(2) 3m PVC-K. 105°C NO/NC	probe
UNS-VA1/8-K3-VA27/1(2)HT 3m Silikonk. 150°C NO/NC	
BFS-10-N-G1/4-MS-NO-ST (0711-256.1)	Switch
071-348.5	
E1H-H90-P7-ST1	relay
0303-033 / GK03	Limit value switch
P/N: 0416-035, Type: KLM-025-M1-K4-2	pressure switch
P/N: 0401-189, Type: D1T-M150SS	pressure switch
p/n: 0401-216; Type: D1T-M3SS-EXI	Microswitch
0431-844	Pressure transducer
0602-130, T2H-H251S-25-A	temperature transmitter
0112-824	
0112-764	
0221-361	
0221-358	
0221-359	

Product	Description
P/N: 0416-157, Type: KLM-025-M4-ST0-1	pressure switch
9211-PL1-V (0419-001)	pressure switch
9231-PL1-V (0419-003)	pressure switch
BPS34GVM0200B	pressure switch
907-0344	
0403-115 / E1H-H500-P7	Pressure Switch
E1H-H500-P4 0403-105	pressure switch
0501.328.133	pressure switch
E1H-H15-P7	Pressure switch
Part No. 0713-349.10	
0801-503	valve
921R3WQ3-Q2	DIVERTER VALVE
Part No. 0113-882	
UDS3V3/50bar/0-10V	Pressure switch
0402-097 / DPD2T-M150SS	Pressure switch
BPS34GVM0100B	100b/420-2/G1/4E/F El. Druckschalter
998-2999	Voreinstellung Druck pre-setting pressure
0402-066	Pressure switch
0111-210	Level switch
P1H-K30SS-T-GE148	PRESSURE SWITCH
0713-354.4	
D1H -AB0SS 50-80 PSI	
P/N: 0401-274, Type: D1X-H18SS-EX	pressure switch
BPS32GVM0600BP	El. pressure switch
BPS32GVM9000PP	
96100-BB2	
316030 (Trockenschutzschalter)	Dryer circuit breaker
T1X-H601S-A-EX	Temperature switch
0405-111	pressure contact
0423-127	Pressure switch
PN: 0404-291 Type: P1H-M340SS-GE6/86	Pressure switch
190060	
0416-160 / KLM-025-M4-ST0-1-V 13 bar increasing (s)	
PN:0601-328 Type: MT1H-M251S-A	Temperature switch
PN:0423-127 Type:UDS3	4-way pressure switch
9048-2	SEALED PISTON PRESSURE SWITCH
82C1TB	Compact Pressure Switch
0417-013 8131-PL1-B	Pressure switch
906-0954	Port adaptor
625H4-13	PRESSURE TRANSDUCER
013-182	Complete sensor
0407U049 / 9048-5	Pressure Switch
BPS34EVM3000P	
9022-M-B-CD	Control Products Valve
0409-041 Typ X1T-4100-40	Pressure Switches

Product	Description
D1T-GH80SS	Terminal Block Diaphragm Switch
625H3-16	PRESSURE TRANSDUCER
0428-115	electr. Pressure switch
6141R3HC3-MC (Valve)	Valve
BPS34GEM0010BRPQ1 (0427-180)	
0499-002	
907-0185	
T2H-H251	REMOTE MOUNT TEMPERATURE SWITCH
425H3-06	Pressure Transducer
MT1H-H351S-A-EXI	Temperature switch
9617-4	Mechanical Pressure Switch
T8014-2-12	
0417-014 / 8141-PL1-B	pressure switch
BPS34NVM6000PP	
0221-356	
0405-132	Pressure contact
p/n: 0221-473; Type: USE3000-VA/T2-KLS-VA44 R12-350-MU3L Lo442	
E1H-H-VAC-P4 (0403-052)	pressure switch
D1T-M150SS-EXI	pressure switch
D1T-M3SS	Pressure Switch
0631-017	Temperature Feel
P/N: 0405-095, Type: B1T-H32SS	Pressure Switch
0403U094 / E1H-H250	Switch
BPS312VM0020BP	pressure switch
BTS31GVM0300M1	El. temperature switch
425T2-04	SENSOR TRANSDUCER
p/n: 0402-099; Type: DPD2T-M18SS	pressure switch
P/N: 0403U085, Type: E1H-H90-Z27	Pressure switch
0401-130 (D1T-H150SS)	pressure switch
6901R3HC3	Control Products Valves
p/n: 0701-035; Type: BFS-10-O	flow switch
BTS34GVM0017M2	
E1H-H90	
425X-15 / 0400U155	Pressure transducer Ex d
9692X-1CC-3 pn 0406u102	Ex-proof pressure switch
BTS32NXM2.00Z4	
0419-004 / 9211-PL1-V-GL	pressure switch
0419-032	
p/n: 0112-765; Type: UNS1000-MS/M20x1,5-ST1- PP18-L1/1 Lo250	
BPS342EM0050BP (50b/420-2/G1/2F/E)	
HB1T-CC32SS	Switch
423H3-03-A	
DMP333	
B2T-A48SS-P5	Pressure switch

Product	Description
B2S-H32SS	pressure switch
0423-164	PRESSURE TRANSDUCUTOR
9675-1	
TC9622-0-V	switch
9675-3-V	
0406-049 / 9675-3	pressure switch
0423-129 / UDS3V3	
0111-531 / UNS-VA/SB5	BilgeGuard & Testoption NO(NC)
9023-M	Directional Control Valve
0007-017	PRESS SWITCH
0401-189 / D1T-M150SS	pressure switch
CD1H-H2SS	Pressure Switches
0417-469 / 8001-PL1-B-EA1-GE261	pressure switch
T2H-H251S-A	remote mount temperature switch
0111-457	
0400U052 / 425N1-14	
0631-053	
0406U261 / C9612-3-CS	pressure switch
BPS323VM0150PP	Electronic Dual Pressure Switch
p/n: 0412-039; Type: MSPS-EE05-Q11	pressure switch
0303-030 / GK03	Magnetic level switch
0801-136 / 6144R3HO3	
BPS3000 / 1670196	pressure switch
BTLS24DV1220075	
6142R3HO3	Control Products Valves, 614 Series
0113=1433	
DPD2T-H18SS	diaphragm differential pressure switch
8111-PL1-B / 0417-011	pressure switch
1330-4100	Valve
0416-105 / KLM-025-M1-S1-2-V-EXI 6.0 bar fallend	
0416-156 / KLM-025-M1-S1-1-V 5.0 bar (s)	
0401U408 / D1T-A3SS-FX	
BPS31GVM0200B	Pressure switch
0111-327 / UNS-PP1/2NPT-PP18 1m PVC-Kabel	Level switch
0601-063 / ML1H-H204	
0406U145 (T96201-BB3SS-S0123)	Pressure Switch
0406U387 (T96201-BB3SS-S0171)	Pressure Switch
0406U386 (T96201-BB3SS-S0123)	Pressure switch
0711-260.3	
0711-259.2	
0711-259.3	
8261-PL1-B	pressostat compact
HL1X-AA351S-WS-EX	
0405-673 / B1X-S48SS-UL	
96201-BB1-T2	pressure switch

Product	Description
p/n: 0601-049, Type: ML1H-H202S-EXI	temperature switch
MT1H-H251S-12-A	temperature switch
BNA-S22	Level indicator
UNS1000-S-VAT1.5-KLS1- VA27-L3/1-DR Lo293	
KLM-025-M4-ST0-1-V / 0416-116	
0406U394 / 9681X-1CC-3	
0406U176 / 9692X-1CC-3	
0232-016 BLP2/P/Xbar/PVXm/F level probe	
0601U485 / THR-L2S-10X-Q10	Temperature Switch
9022-M-A-B	Directional Control Valve
P/N: 0111-199, Type: UNS-PA16/PA18	1 m PVC cable
0417-062 / 8221-PL1-B-EXI	pressure switch
CSM17-31-12B	
CSM18-31-12B	
81E2MB	
8AE2MB	
0405U001/B2T-A48SS-P5	pressure switch
0401U395 / HD1T-AA80SS-P2-U	Diaphragm Pressure Switch
C9612-3-W60-CS	Control Products Mechanical Pressure Switches
0416-159 / KLM-025-M4-ST0-1-V	
0417-020 / 8241-PL1-B	pressure switch
0407U033 / 9048-1	pressure switch
BPS31GVM0400B	pressure switch
P/N: 0112=1283 Type: UNS1000-VA/T1-STDB-BN25 L3/1.1.1 Lo200	Float switch
0111-510	
BPS31EVM0150PAP	Electric 2-way pressure switch
0417-011 / 8111-PL1-B	pressure switch
0417-012 / 8121-PL1-B	pressure switch
0417-694 / 8141-PL1-B-D-LH-ES-PC- GE354	Compact Pressure Switch
0401-470 / D2X-M80SS-P2-EX	pressure switch
0801U546 / 5963SOAQ3-H	valve
BPS312VM0400BP	pressure switch
P/N: 0711-347.5, Type: BFS-10-O-G1/2-MS-NO-ST	Flow Switch
P/N: 0431-343, Type: UPA2-LMK358	sensor
0601-052 / ML1H-H203	temperature switch
0400U082 / 423T4-13	Pressure transducer
P/N: 0406-063, Type: T96201-BB3SS-T5-J36	Pressure Switch
0713-349.8 / BFS-30-N-G1-MS-WE-ST	
0403-097 / E1H-H250-P7	pressure switch
TC9622-3-Z27	
0437-081 / 625T4-13-P3	Pressure Transducer
BPS32PVM6000PP	Pressure Sensor
DPD2T-A80SS-CS-L6	differential pressure switch
9675-0	Mechanical Pressure Switch
0122-032	

Product	Description
C9622-1-H-A	
9048-4	pressure switch
T8014-3-33	valve
T96201-BB3SS-T4W48	Pressure Switch
ML1H-S203S	temperature switch
9010206MB	
9671X-1CC	Switch
P/N: 0406U139, Type: L96211-BB1-S0062	Pressure switch
T96201-BB2-T2P1	Mechanical Pressure Switch
TXR-L2S-10-Q10	temperature Switch
0431-630	Electronic Pressure Transducers
0431-631	Electronic Pressure Transducers
diaphragm for D2T-M18 (071114)	diaphragm
6181S3HC3	valve
0417-421 / 8151-PL1-B-LH-ES	pressure switch
P/N: 0431-897, Type: UPA2-DMP343-100-2500-1-3 TR0-100-000	
CSM2-33-32B-100R	Pressure Switch
E1H-H15-P4	pressure switch
E1H-H250-P4	pressure switch
9022-M-A-C	Valve
P/N: 0711-347.5, Type: BFS-10-N-G1/2-MS-NO-ST	Flow Switch
0801-435 / 9021-M	valve
0111-636	
0711-257.1 / BFS-10-N-G1/2-MS-NO-ST	
0601-387 / MT1H-H251-12	temperature switch
0401U695 / D1T-B 3SS-U	Terminal Block Diaphragm Switch
0401-852 / D1T-A150SS	pressure switch
425X-14-P6	
0721-015 / BFS-10-N-G1/2-SS-WE-ST- Exi 3-13 l /min	flow switch
0111-652	wires
0111-534	wires
0417-701 / 8141-PL1-B-D-LH-ES-PC-GE 354	Compact Pressure Switch
0712-348.4	
0401-277 / D1X-H18SS-UL	Pressure Switch
0713-267.6 / BFS-30-N-G1-MS-NO-ST	Pressure sensor
0713-267.8 / BFS-30-N-G1-MS-NO-ST	
E1H-H500-P4-BR	pressure switch
0407U042 / 9048-3	pressure switch
0402-061 / DPD1T-M3SS	pressure switch
0402-049 / DPD1T-H3SS-EXI	pressure switch
DPD1T-M3SS-EXI / 0402-062	pressure switch
0434-182 / UPA53-100-XXXX-1-3/5-XXX -XXX 000	pressure controls
P/N: 0401-302, Type: D1X-M80SS-EX	pressure switch
D1T-H2SS	Terminal Block Diaphragm Pressure Switch
MT1H-H154-A	temperature switch

Product	Description
Nr. 0713-352.10 Type BFS-30-N-G1-SS-WE-ST	
BPS34GEM0010BP	Pressure transmitter
E1H-H-VAC-P6 / 0403-054	Pressure switch
BPS342VM0010BP	pressure switch
0721-089.6 / BFS-10-N-G1/4-MS-NO-ST- EXI 0.5-3 l/min	
0431-041 / UPA2/1.6b/020/G1/4E/DIN/ E	
0400U139 / 423X-18-Z10	pressure transducer
423X-12-Z10	pressure transducer
0332-624 / BNA-S22	level gauge
P/N: 0419-017, Type: 9311-PL1-V-VA-GL-PC	pressure switch special
P/N: 0711-334.2, Type: BFS-10-O-G1-MS-WE-ST	
0405U728 / B1T-H12SS-CS	Pressure Switch
96211-BB5-S0444	Pressure Switch
BPS32GEM0010B	
BPS34GVM0400B	pressure switch
0405-316 / B2T-M32SS	pressure switch
E1H-H250-BR	ECON O TROL
0332=1419 / BNA-S21-G1/2" VA30/02-MA-PO LM0.5<1.0m	
0112=1959	
UNS1000-MS/T1/2-M12x1 BN18-L1-TS70/2 Lo401-600	float switch
E1H-G250-P4-RD	pressure switch
UAS3-5-5	
0431-844 / UPA2V2/600b/420/G1/2F DIN/F	
0416-159 / KLM-025-M4-ST0-1-V 14 bar decreasing (f)	
0416-173 / KLM-025-M4-ST0-1-V 8.5 bar increasing (s)	
0403-099 / E1H-H250-P7-ST1	pressure switch
425H3-14-P1	TRANSDUCER
8CE1CBS	Pressure switch
D1X-A80SS-UL	EXPLOSION PROOF DIAPHRAGM SWITCH
p/n: 0122-002, Type: UNS1000-VA/T1-ST1-VA27- L2/1(2)	
0111-641 / UNS-MS1/4NPT-K1- BN30/1(2)-TP60/2	Level Switch
0400U034 / 423T2-04-A	Pressure transducer
55320101	Press. Switch
B1T-H48SS	Bourdon tube - pressure switch
0406-017 / C9622-0	pressure switch
0801-024 / 143R3WC3	valve
D1X-A80SS-EX	Explosion Proof Diaphragm Switch
0332-625	Visual level meter
0411-008 / EPD1S-AA40	pressure switch
BPS31GVM0400BP	Pressure switch
T2X-S251S-EX	Switch, Temperature, Explosion Proof
0406U151 / 96201-BB4-Q46	pressure switch
0423-192 / UDS3-16-N-6	
BPS35GVM0400B / 400b/0-10/G1/4E/F	Electronic Pressure Switch
0602U041 / T2H-H251-A	UL version/USA

Product	Description
9001-M	valve
0403-329 / E1H-M250-P6-PLS-V	pressure switch
0403U096 / E1H-H90-P6-PLSV	Pressure Switch
0112=1086 / UNS1000-MS/T1/2-M12x1- BN18-L1/1-TS70/2-GE275	
B1X-S48SS	pressure switch
p/n: 0713-267.2, type: BFS-30-N-G1-MS-NO-ST	
914-0069 / 22507-3B	Washer
BFS-10-N-G1/4-MS-NO-ST (0711-256.3)	
P/N: 0405-136, Type: B1T-M48SS	Pressure switch
D2T-M150SS-EXI	pressure switch
0111-465 / UNS-MS1/8-K3-BN25/1(2)	level switch
0402-066 / DPD1T-M80SS	pressure switch
0403-146 / E1H-H90-P7	pressure switch
0431-705	
0400U117/ 425X-07-A-Q19	Pressure transmitter
MSPS-JJ15SS	pressure switch
27-010001	Temp switch
BPS31GVM0010B	pressure switch
9675-3	pressure switch
C9612-3	Pressure switch
0401-573 / D1T-GM18SS-EXI	pressure switch
P/N: 0405-132, Type: B1T-M32SS	pressure switch
0113=1318 / UNS2000-VA/T2-KX4-VA52- L2/1.2-DUAL-Exi Lo245	
0405U148 / B2T-M12SS-CS	Bourdon tube switch
0221-440 / USE3000-VA/T2-KLS-VA44 R12-250-MU3L Lo342	level pointer
0303-031	Limit value switch
0303-031 / GK03	Limit value switch
P/N: 0701-297, Type: BFS-10-N-G1/4 MS-NO-ST**	
BPS342VM0400BP	pressure switch
E1H-0016 Type E1H - H90 - P4	
0710-007.5	VARIABLE AIR FLOW SWITCH
0801U669 / F20415S3WQ2-1	Valve
0711-256.4 / BFS-10-N-G1/4-MS-NO-ST	
BT5-T5-11BG-P16P	Industrial Pressure Transducer
0403-142 / E1H-H90-P6-PLS	Mechanical pressure switch
DPD1T-GM150SS	
627T4-05	pressure transducer
0406U077 / A9675-0-AA	Pressure switch
0111-369 / UNS-VA1/8NPT-BN30/1 1 m PVC-Cabel	
625H4-05	pressure transducer
425T4-14-Z15	pressure transducer
205P6WC3	Valve
239537	
BPS342FM0400BPQ6	pressure sensor
P/N: 0406-023, Type: C9622-3	pressure switch

Product	Description
0400U116 / 425X-03	
0400U104 / 425X-08	
625T4-16-Q2 (0437-036)	transducer
BPS34GVM0010B	
P/N: 0417-014, Type: 8141-PL1-B	pressure switch
T2X-S251S-A-EX	Mechanical temperature switch
0631-112 / UTA2/-30+150C/420/G1/4E M12/F/17 KM	
P/N: 0704-021, Type: BFS-40-N-G1/2-MS-NO-ST HT 0,2 ... 4,0 L/min	
BPS33GEM0200B	
907-0357	Connector
BPS31GVM0050B	ELECTRONIC PRESSURE SWITCH
BPS38GVM0050B	ELECTRONIC PRESSURE SWITCH
E1H-H500-P4-EXI	pressure switch
CRK-77A-240A-30-8-70-01*	
P/N: 0303-033, Type: GK03 5m	PVC cable/cable limit switch
P/N: 0406-004, Type: C9612-1	pressure switch
P/N: 0403-505, Type: E1H-H250-P7-V-ST1	pressure switch
9675-2	
P/N: 0405-300, Type: B2T-M12SS	pressure switch
68/30010	conversion kit
BPS382VM0050BP	
UNS-PP16-PP18	
26.600 G-2502-R-3-5-100-300-1-000	
BT6-T5-43BG-P9C	
BPS34GEM0002BAPQ1	
B1T-H32SS-FX	
D1H-A80SS-FX	
A9692X-2CC-3	
208128 / 906-0045	Screw
208129-C / 906-0040	
4518014742 / UNS-PP16/18	float switch
BT5-Q50-16BG-P9C	
0406u106 / 9681X-1CC-2	pressure switch
BT5-T4-16BG-C	
0801U152 / 6182S3HC3-MC	Valve
B2T-M12SS/ 0405-300	pressure switch
425T4-22	
T96201-BB3-T2-Z17	Pressure Switch
ART.NR.: 0417-294 / TYPE: 8161-PL1-V-LH-GE42	
UNS1000-S-VA/T1-KLS1 BN18HV-L1/3-CBM Lo82	level temp sensor
UNS1000-VA/T1-KL6-VA27-L1/1(2)-HT Lo82-1000 (0122-260)	Level Gauge
908-0361	Connector
0113=1290	
P/N: 0403-113, Type: E1H-H500-P6-F2	pressure switch
0801u126 / 6142R3HC3	Valve

Product	Description
P/N: 0111-708, Type: PP18-DM-GE301	PVC-Cable
0713-354.2/ BFS-30-O-G1-MS-WE-ST	
P1X-B30-S0426	Pressure Switch
0711-257.7	Flow meter
P/N: 0401-459, Type: D2X-M150SS-EX	pressure switch
0401U934 / D2T-H18SS-CS-U	Pressure switch
P/N: BPS32NVM0150P, Type: 150p/420-1/1/4NE/F	ELECTRONIC DUAL PRESSURE SWITCH
0111-591 / UNS-VA1/4NPT-K5- VA52/1(2) 5m PVC-Cable	
0111-594 / UNS-VA1/4NPT-K5-VA52/3 5m PVC-Cable	
0111-715 / UNS-VA1/4NPT-K5-VA52/3- HT 5m Si-cable	
0403U095 / E1H-H15	UL Pressure Switch
B2T-M12SS D	pressure switch
0405U270 / B2T-M32SS-CS	Pressure Switch
0402U123 / DPD2T-A150SS	pressure switch
D2T-M80SS-EXI / 0401-418	Pressure switch
P/N: 0416-116, Type: KLM-025-M4-ST0-1	pressure switch
P/N: 0401-373, Type: D2T-H18SS	pressure switch
0416-119, KLM-025-M4-ST0-1-V 0501 328 133	
B1X-M12SSEX / 0405-184	pressure switch
P/N: 0406-038, Type: 96201-BB3-T2	pressure switch
9681X-1CC-2-S0271	Pressure switch
UNS2000-VA/T3/4-ST1-VA44 HT-L1/1-GE392 Lo135	
0122-153 / UNS1000-VA/T1-KX4-VA27- L2/1(2)-Exi Lo147-500	Level sensor
0801-120 / 6141R3HC3	Directional hydraulic valve
0225-108 / USE3200-VA/FLS-KLS-VX80 R12-900-DR-MUEx Lo1350	level sensor
P/N: 0111-717, Type: UNS-PP16-PP18-G3/4-GE301	10m PVC-Cable
P/N: 0431-620, Type: UPA2-DMP343-100-1000-1-3 -100-100-000	sensors
L96211-BB2SS-S0639	Pressure Switch
0406u103 / 9692X-1CC-4	Ex-proof pressure switch
P/N: 0603-093, Type: T1X-H351S-A-EX	temperature switch
UPA2-LMK382-H-566-XXXX-K-2-H-1-4-B-003-000	pressure switch
P/N: 0405-223, Type: B2S-M48SS	pressure switch
0113=1432	
0431-0620	level sensors
PSA30.BPS3.4.G.V.M.0100B.P	Electronic pressure switch and transmitter
BTS312VM0050M1	Temperature sensor
9692X-1CC-3 / 0406U103	Pressostat
BLP2/P/XmWs/PVXm/F	level probe
0332-604	
0402-102 / DPD2T-M80SS	pressure switch
P/N: 0403-074, Type: E1H-H15-P6-T	pressure switch
0712-263.10 / BFS-20-O-G1-MS-NO-ST	Sensor
0417-136 / 8151-PL1-B-LH	pressure switch
P/N: 0303-027, Type: GK03-EXI with 3 m Si-Kabel	Limit switch
P/N: 0801-088, Type: 6145R3HO3	valve

Product	Description
BPS344VM0400B	
RK1457	
0405-028 / B1S-M12SS	pressure switch
E1H-H90-Z27	Pressure switch
0122-144 / UNS1000-MS/T1-STDB-BN25- L2/1(2) Lo107...500 Gr.3	
0221-374 / XT-R12 5250 >= Lm > 5000	
0419-037 / 9A21-PL1-V	pressure switch
BPS34GVM00.5BP (500mbR/420-2/G1/4E/E)	Pressure switch
BPS34GVM0001BVP	electronic pressure switch
P/N: 0403U401, Type: E1H-G90-RD-LC	Pressure switch-UL
BT5-T5-36BG-P16P	
E1H-R-VAC-P6/ 0403-179	
E1H-H500-P8/ 0403-118	pressure switch
BNA-S22-3/4"150-RF-VA30/ /02-MA-GE409 LM=1,0<1,5m (0332=1037)	
UTA2/0+120C/420/G1/4E/F/ (0631-063)	
455ET4-01-P4-Z050	
0801U057 / A147R3WC2	Valve
BPS312FM0040BPQ6	pressure switches
BPS342FM0040BPQ6	pressure switch
UPA2-DMP333	
0711-339.7	
6143R3HC3/ 0801-130	
82C1-PL1-B-UL	pressure switch