



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Dynis

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

coBRAN'S oPAOUC'

Trdute	AsptT e r
MDMDT4M6MM 6 2F-214/-CD5	SAIL F3L1ES
96n0 MDMDPMM6MM, Oype0 I2-N1R8/-9F-RG	I2-N1R8/-9F-RG I23LAO3S N1R 8/ 9F
96n0 MDMDPTM6MM, Oype0 I2-YF4/-9F-YF-CDT78/6CDT7D4	I2-YF4/-9F-YF-CDT78/6CDT7D4 YIEBFASZI23LAO3S YF 4/ 9F 6CDTX8/-D4
96n0 MDMDP4M6MM, Oype0 I2-YF/M-9F-YF-CD578/6CD57D4	YIEBFASZI23LAO3S YF /M 9F 6CD5X8/-D4
96K0 MDMTTM6MD, Oype0 2A-Y2NT6CI-9F-YF-A(ML4M-84	Y2N T6CI 9F)GSSEKO)3LLE)O3S
96n0 MDM8JMM6MD, Oype0 2A-Y2NT6CI-9EG-ADTML4M-84	FEANH 1GOH)3LLE)O3S Y2N T6CI YS3GK1
96n0 MDM48D(6MM, Oype0 U8/68M2L(MMM	U8/ 6 8M2L(MMM SAIL 2OEEL WIOF)399ES FEA1 U 8/ 6 8M-(1ELINESH LEKYOF0 (C
96n0 MDM48T(6MM, Oype0 A8/68M2L(MMM	A8/ 6 8M2L(MMM ALL3H rail A 8/ 6 8M-(WIOF)399ES F EA1
96n0 MDTD/MT6MM, Oype0 CZ-RU-A-DMM)ontact grease
96n0 MDT(M856MM, Oype0 GTM6/M)-5MMM9F-VA	Insulated busbar G TM6/M) -5 9F
96n0 MDT(D856MM, Oype0 GTM6/M)-5MMM9E-AA	Insulated busbar G TM6/M) -5 9E
AF-RADML-DM6D5./-K-9A-D4	R3C9AROFALOEES RA DM-DM K
96n0 MD/TDTM6MD, Oype0 AF-NE925	
MD/TJPM6MM 6 2A-R12OLPM9F-TMMM	1ual)urrent)ollector
MD/TJMM6MM	+2A-R12OLPM9E TMMM 13GVLE 9AKO3YSA9F R12OL PM 9E Wth T 7 T C LEA1@
96n0 MD/8/D(6MM, Oype0 2A-ZU4-A-D,8-DD-TJ-)U2 U1.-2O 1IKD(TT4	2A ZU 4-A-D,8-DD-TJ-)U2 U1.-2O 1IKD(TT4 ZGYUE1ES ZU 4
96n0 MD/85PT6MM, Oype0 2A-R12OLDTM9E-TMMM	2A R12OLDTM9E TMMM 13GVLE 9AKO3YSA9F R12OL DTM 9E Wth T 7 T C LEA1
96n0 MD/448P6MM, Oype0 2A-R2O//9F-M4)-TMMM	Rst // 9h pantograph
96n0 MD/448J6MM, Oype0 2A-R2O//9E-M41-TMMM	Rst // 9e power collector
MD/444M6MM	
MD/44/86MM	

Product	Description
P/N: 103444.Type: CET1-AX-LDA-00-50X-SC	SECURITY SYSTEMS
VERT-MA4-MM1-NDC-BAR-R21-UNF-6PN-S06-F18-NTR-NCC	PRESSURE TRANSDUCER
PT4624-7.5M-6/18-T80-GC9	
TPT 463 E-1.5M 6/18	Pressure Transducer
ECHO-MA4-UNF-BAR-R23-6PN-S06-F18-NTR	
PT4624-5M-6/18-SIL2	pressure sensor
MDA462-1/2-3.5C-15/46 09-15-08342258	
MDA462-1/2-1C-15/46	
TPT463E-10M-9/18	
14804100; sn: 786051010 002	
PG442R-5M-6/30	
PT4624-5M-6/18-A	MELT PRESSURE SENSOR
PT415D-7.5M-6-B314	Pressure Sensor
IDA 334-2C	TRANSMITTER
1490-2-1-1.0	
PT422A-3M-6/30	
DYMT-F-1/2-J-15-15-1	TEMP SENSOR
901383 type J	
Model: MDT422F-1/2-2C-32/46-B171-SIL2	Pressure transmitter
PT4624-35MPA-12/18-SIL2	
4622NA00B21CEDDAAFZZGC7	
DYMT-S-1/2-PT100/4-30-15-G	
MDA460-1/2-7C-15	transducer
MDT420F-1/2-7C-15-SIL2	
PT462E-5M-6/30	Melt Pressure Transmitter
NP4624-1/2-35MPA-15/45-SIL2 PT4624-35MPA-6/18-SIL2)	PRESSURE TRANSMITTER
NP4634-1/2-35MPA-J-SIL2 TPT4634-35MPA-6/18-SIL2)	PRESSURE TRANSMITTER
MDA422-1/2-5C-15/45	pressure Sensor
PT4624-7.5M-9/18-A	Transducer diaphragm
PT4626-10M-12/18	TRANSDUCER
IDA354-3.5C-10V-S78B	pressure sensor
MDT460L-1/2-1M-15	sensor
cable for MDT460L-1/2-1M-15	cable
PT4624-50MPA-6/18-A	pressure sensor
200925	
TPT4634-5M-6-30-SIL2	
ECHO-MA4 BAR R21 UNF 6PN SO6 F18 NTR	sensor
4622NA00P24FEDDAAFZZGC8	
4622NA00B20CEDDAAFZZGC6	
socket for PT4624-20MPA-6/18-SIL2	socket
MDT462F-M18-2C-32/46-GC6	
DYMT-S-M18-PT100/4-5-38-G	
4622NA00B20FEDDAAFZZGC0	
149041000	Digital Indicator
PT4624-5M-6/30-SIL2	

Product	Description
MDT422H-1/2-7C-15/46-SIL2	mass pressure sensor
MDT462F-1/2-5C-15/46-SIL2	Pressure transmitter sensor
MDA462-1/2-2C-15/46	
BP420-1/2-5.5M-6	
ECHO-MV3-BAR-R21-UNF-S06-F18-NTR	
234908	thermocouple for sensor Model TPT
TPT484-5M-6/30-B379	Probe
470000172	Probe
PT4624-10MPa-6/18-SIL2	Probe
DYMT-S-1/2-PT100-4-15-23-G-4	
149010000	
MA4-PSI-R23-UNF-6PN-S06-F18-NTR	
PT4624-2CB-6/18-B171-SIL2	TRANSMITTER, MELTING PRESSURE
MDT422F-1/2-2C-15/46-B171-SIL2	BCF EXTRUDER PRESSURE SENSOR
DYKE-1/2-J-0-15G (F13)	
PT-462E-5M-12/18	
ECHO-MA4-BAR-R23-UNF-6PN-S06-F18-NTR	
301AUSX1546 (IDA332-5C-4-20MA)	
NP462-1/2-50MPa-15/45 (MDA462-1/2-5C-15/46)	pressure sensor
PT422A-7.5M-6/30	
ECHO-MA4-BAR-R21-UNF-6PN-S06-F18-NTR	
ECHO-MV3-PSI-R22-UNF-6PN-S06-F30-NTR	
E22711121	
462L0010	pressure sensor
MDT462F-M18-7C-15/46-GC9	Pressure Transducer
E32711121	
4672SA00B21EADDAAZZ	
ATC990400110000	
149021000	
0462000133B70	
929008	Connector cable
PT 4624-1/2-70MPa-15/45-B171-S1L2	
PT462E-7.5M-6/30-T80	pressure probe
4622NY00P22CEDDAFZZGC9	Pressure Sensor
ECHO-MV3-PSI-R21-6PN-S06-F18	
MDT462F 1/2 5C 15/46	
IDA354-5C-S78B	Shutdown Tonnage Pressure Sensor
MDT422F-1/2-2C-32/46-B171-SIL2	Pressure transmitter
422F-1/2-3.5C-15/46-SIL2	
PT462E-50MPa-6/18	
MDT462F-1/2-3.5C-15/46-GC8	Housing transducer
TDA463-1/2-3.5C-25/46	sensor
NP422-1/2-70MPa-15/45	PRESSURE TRANSMITER
BP420-1/2-5M-6	
MDA462-1/2-3.5C-32/46	

Product	Description
PT462E-10M-6/8	Transducer
PT4624-3.5CB-6/18-SIL2	Melt Pressure Transmitter
4622SA00B21FEDDAAAZZ	
PT199-2.5C	
MDT422F-1/2-3.5C-15/46-GC7	Pressure Transmitter
MDT422F-M10-3.5C-15/76-GC7	Pressure transmitter
DYMT-S-1/2-Pt100/3-10-15-G	Temperature probe
TPT463E-10M-6/18	Melt Pressure Transducer
MDT462F-1/2-3.5C-15/46-B171-SIL2	Pressure transmitter
ATC990-3-1-1-1-1-0-1-1	Pressure controller
PT462E-35MPA-6/18	
4222SA00B15FEFFBAAZZ	
TPT4634-3M-12 / 18-RTD1-SIL2	TRANSDUCER
TPT4634-35B-6/18-S137-SIL2	PRESSURE TRANSDUCERS
TDT432F.1/2.5C.32/46.S137	MELT PRESSURE TRANSDUCER
ECHO-MV3-PSI-R21-UNF-6PN-S06-F06-F18-NTR	
ECHO-MV3-BAR-R22-UNF-6PN-S06-F18-TCJ	Dynisco pressure and temperature transducer
MDA460-1/2-1M-15 (0460300642)	PRESSURE TRANSDUCER
E13512121	PRESSURE TRANSDUCER
ATC990.2.0.0.0.1.0000	PRESSURE REGULATOR
MDT422H.1/2.7C.15/46 24V	MELT PRESSURE TRANSDUCER
TPT4636H-10M 6/18	MELT PRESSURE TRANSDUCER
MDT460L-1/2-7C-15	
BP420-1/2-7.5M-6-1/4NPT	
PT4624-3M-6/30-SIL2	PRESSURE MELT TRANSMITTER
4P708013 / It Plug – Blind stop	Gauge Plug
VT460-16	Pressure cable
VT460-10	Pressure cable
TDT463FH-1/2-3.5C-15/46-SIL2	
LMFI-1NNNNNN	
MDT462H-1/2-5C-15/46-SIL2	
MDT462H-1/2-3.5C-15/46-SIL2	
MDT462H-1/2-1M-15/46	Pressure Sensor
VERT-MV3-MM1-NDC-PSI-R23-UNF-6PN-S06-F18-TCJ-NCC	
MDT460F-1/2-5C-15-M1100-GC3	
E12511211 / 09-10-14392175	
ECHO-MV3-BAR-R20-UNF-6PN-S09-NFL-NTR	
IDA354-2C-10V-S143	Pressure transmitter
PT462E-M10-35MPA-15/46	
0051-30	Piston Assembly
MDT462F-M18-2C-23/46-GC6	Sensor
PT460E-5M-6	sensor
ECHO-MV3-PSI-R21-6PN-S06-NFL-NTR	sensor
SPX 2242-S-A-00-M-20-CE-DD-B-AC-ZZ-SIL2-J8	
ECHO-MV3-BAR-R20-UNF-6PN-S06-F18-NTR	Pressure Transmitter

Product	Description
PT462E.3.5CB-6/18-GC8	
MDA422.1/2.3.5C.15/46.GC8	
MDT422F-1/2-2C-15/16-B171-SIL2	
MDT462F-1/2 2C-15/45-A	
4622NA00B2OCEDDAAFZZGC6 / SN12-14-11403626	
MDT462F-1/2-3-5c-15/76-T80-GC9	PRESSURE TRANSDUCERS
DYMT-S-1/2-J-10-15-G	
TMDT 462F-1/2-3.5C-15/91-A	PRESSURE PROBE
2243 SA 25 M 14 CEFFACAPA	
MDA462-G3-5C-15/46	
MDA460-G3-5C-15	
VERT-MA4-MM1-HT1-BAR-R21-UNF-6PN-S06-F18-NTR-NCC	pressure transmitter
DYMT-S-1/2-2XPT100/3-20-15-G-0.5M	Melt Temperature Probe
14804100 S/N: 1090029 030 013	
VERT-MA4-MM1-NDCBAR-R22-UNF-6PN-S06-F18-NTR-NCC	PRESSURE TRANSDUCER
ECHO-VT1-PSI-R23-UNF-6PN-S06-F18-NTR	Pressure Sensor
DYMT-S-M18-J-5-15-G-2M	
UPR900-2-0-1-0-0-0-0-0	
SPX2281SDDCA4B30B	
ECHO-MV3-MPA-R21-6PN-S06-F18-NTR	pressure sensor
TPT-463E-10M-12/18	Pressure Sensors
PT4626-7.5M-6/18	Pressure sensor
MDT462F-1/2-5C-15/46-B171-SIL2	
ECHO-PSI-VT1-R23-6PN-S06-F18-NTR	
TPT463E-5M-6/18 RTD1	
NP422-1/2-10MPA-23/45	PRESSURE SENSOR
mdt 462F-1/2-3.5C-15/46	
PT303-5C	Pressure Transmitter
PT4624-7.5M-6/18-SIL2	
TPT4636-10M-6/18-B171	
MDT462F-M18-35Mpa-32/46-SIL2	
MDT462F-5C-1/2-15/46-B171-SIL2	pressure transducer
NP460-G3-35MPA-23	pressure sensor
ECHO-MA4 BAR-R22-M18-6PN-S06	
CABLE8	
CABLE10	
CABLE15	
E21911122	
IDA354-3.5C-2V-S78	
TPT4636.10M.6/18	
TPT432A-5M-12/18	PRESSUREM SENSOR
MDT422H-1/2-5C-15/46-B171-SIL2	
PT4626-10M-6/18-B628	pressure trasnmmitter
VT460-3	PRESSURE TRANSMITTER CONNECTOR
PT4624-10M-6/18-SIL2	PRESSURE TRANSDUCERS

Product	Description
ECHO-MA4-PSI-R21-UNF-6PN-S06-F18-NTR	
929009	Connector
148041000	Panel Indicator
V462F31410	Pressure Transducer
TPT463-5M-6/18	
MDT460F-1/2-1M15SIL2	mass pressure transmitter
4622NA00B14CEFFAAFZZ	
MDA460-1/2-3.5c-15	
SPX4 622 S A05 B 15 CE DD A AA ZZ	
PT462E-20MPA-6/30	
BP420 1/2 12 5M 6	Burst Plugs
IDA 354-3.5C-5V	
ECHO-MV3-MPA-R20-6PN-S06-F12-NTR	
E22811131	
TDT463F-1/2-3.5C-15/46-SIL2	Pressure Sensor
TDA463-1/2-7C-15/46-B170	Sensor
ECHO-MV3-PSI-UNF-R23-6PN-S06-F18-NTR	
MDT422F-1/-3.5C15/46-516-2	Pressure Transmitter
VT460-5m	Cable
MDA465XL-1/2-1M-B225 / 04650300642B225	
2291SA48K20BSMMAACZZ	
TPT4634-5C-12/30-SIL2	Pressure Transducer
ECHO-MA4-BAR-R22-UNF-6PN-S06-F12-TC	
04620020130	
NP460-G3-50MPA-32 / 0460C11410	
PT4624-10M-12/30-SIL2	Pressure Transducers
TDA463-M18-5C-15/46	
MDT462L-1/2-7C-15/46	
BP1010	
224200002283	
MDT462F-1/2-2C-32/46-B171-SIL2	
MDA460.M18.5C.15	PRESSURE MELT TRANSDUCER DYNISCO
MDT 462H-1/2-5C-15/46... 0-500 bar	
MDT 462L ½ 3.5C-15/46 0-350 bar	
MDA 462-1/2 -2C-15/46 ..0-200	
224200002104	PRESSURE TRANSMITTER
224200003156	PRESSURE TRANSMITTER
224200002845	PRESSURE TRANSMITTER
DYMT-S-1/2-RTD-10-15-G	TEMPERATURE PROBE
PT460E-7.5M-6-T80	
PT4624-35MPA-18/18-SIL2	
MDA482-1/2-2C-15/46	
MDT462F-1/2-7C-15/46-B171-SIL2	
DYMT-S-M18-J-7-15-G-2M-A	THERMOCOUPLE
BP420-1/2-6.5M-6	

Product	Description
BP420-1/2-3M-4	
BP420-1/2-3M-6	
902344	Bursting screws
MDA462-M18-3.5C-32/46	pressure transducer
DYMT-S-1/2-PT100/3-25-15	TEMPERATURE SENSOR
PT4624-M18-35MPA-6/18-SIL2	
PT4626-50MPA-6/36	Pressure Transducer
E12611121	
PT4624-5M-15/18-SIL2	PRESSURE SENSOR
TDA463-1/2-3.5C-25/46-S137/1	PRESSURE TRANSMITTER
4222SA00B21FEDDBAAZZ	Pressure Transmitter
ECHO-MA4-MPA-R24-M22-6PN-S09-F18-TCK-N	
PT462XL-30M-6/18	
ECHO-MA4-MPA-R24-M22-6PN-S09-F18-TCK	
ECHO-MA4-BAR-R23-M18-6PN-S06-F18-NTR	
929026	
TDA463-1/2-7C-15/46	
1490-4-1	
ECHO-MV3-BAR -R22-UNF-6PN-S06-Tcj	
ECHO-MA4-BAR-R22-UNF-6PN-S06-F18-NTR	
1480-4-1	Panel Process Indicator
MDT462F-M10-3,5C-7,6/107-SIL2	
SJ-600H-U4	
ECHO-MA4-BAR-R21-UNF-6PN-S06-F18-TCJ	Pressure Sensor/Transducer
ECHO-MA4-PSI-R21-UNF-6PN-S06-F18-TCJ	melt pressure sensors
TPT4634-7CB-6/18	
UPR90020111000	
PT-160-5M-H88	PRESSURE TRANSDUCER
PT462E-10M-6/18-GC5	
462200000351	
462200000306	
200100	
711660	
MDT420L-1/2-7C-15-J8	pressure sensors
710700	
PT462E-7.5M-6/30	
PT450TA 1M	
PT462F-1/2-3.5C-15/46	
PT4624-10MPA-12/18-SIL2	
PT4626-5M-6/18 0-5.000	PSIG PRESSURE SENSOR
ECHO-MV3-PSI-R22-UNF-6PN-S06-F30-T C	
TPT463E-7.5M-6/18	
MDA422-1/2-1C-23/46	
PT124B-10M-M14-6/18-10V	Pressure transmitter
ECHO-VT1-MPA-R22-UNF-6PN-S06-F18-TCJ	

Product	Description
PT462E-10M-6/18-GC7	pressure transducer
PT462E-5M-6/18-GC7	pressure transducer
ECHO-MV3-MPA-R23-UNF-6PN-S06-F18-NTR	
SPX2242SA00B21CEFFBACPK	
TPT4634-3.5CB-6/18-SIL2	PRESSURE TRANSDUCER
ECHO-VT1-BAR-R21-UNF-6PN-S06-F18-NTR	PRESSURE TRANSDUCER WITH
MDT462F-1/2-7C-15/46-B171-A	
MDT462F-M18-3.5C-8/46-B171-SIL2	Pressure Sensor
MDT462N-1/2-2C-15/46-SIL2	Pressure Sensor
ECHO-VT1-BAR-R22-UNF-6PN-S06-F18-TCJ	PRESSURE PROBE
pt3034c	
VERT-MV3-MM1-NDC-BAR-R22-UNF-6PN-S06-NFL-NTR-NCC	
462200000322	
ECHO-MA4-BAR-R23-UNF-6PN-S06-F18-TCJ	Massedrucksensor
462F0152S	sensor
PT415-5M-6-B314	