



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Hotstart

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">P/N: CL140210-200, Type: CL 4000W 240V 100-120F</a>	
<a href="#">TPS102GT10-000</a>	
<a href="#">TPS152GT12-000</a>	Engine heater
<a href="#">CSM3060A-000</a>	400V 50Hz 3P 6kW COOLANT SYSTEM
<a href="#">AF40024</a>	HOT PAD 400W 240V W/72 CORD
<a href="#">TPS-T</a>	tank plastic TPS heater
<a href="#">SL130200-100</a>	240V W/O TSTAT 36IN CORD
<a href="#">CB115210-200</a>	Engine Heather
<a href="#">OE650500-000</a>	Lube Oil Heater
<a href="#">CB120210-200</a>	Tank Heater
<a href="#">CSM1030J-5A0</a>	
<a href="#">TPS152GT12-A00</a>	
<a href="#">P/N: CB125210-200, Type: CB 2500W 240V 100-120F</a>	Engine Block Heater
<a href="#">TPS052GT10-000</a>	
<a href="#">TPS052GT8-000</a>	Engine Heater
<a href="#">CTM15210-A00</a>	engine coolant heater
<a href="#">TPS102GT10-013</a>	Heating Resistor
<a href="#">TPS152GT10-019</a>	Thermosiphon Engine Heater TPS Model
<a href="#">590-600</a>	Heater
<a href="#">TPS102GT10-004</a>	Heater
<a href="#">PER-752FP</a>	Push in heater
<a href="#">PER-102FP</a>	
<a href="#">CTM15210-E00</a>	Engine Block Heater
<a href="#">E06021W-C0AT-00</a>	
<a href="#">11P72C</a>	Replacement Cord
<a href="#">CSM3060A-5A0</a>	Heating System
<a href="#">CSM3090A-5A0</a>	
<a href="#">E09033E-C0HA-00</a>	
<a href="#">CB125200-000</a>	
<a href="#">TPS-YC2</a>	
<a href="#">HB5/8X1/2NPT</a>	
<a href="#">HB5/8X1/4NPT</a>	
<a href="#">HB5/8X10MM</a>	
<a href="#">CSM1090J-5A0</a>	pump
<a href="#">TPS102GT10-006</a>	Heater
<a href="#">E060A3W-50BT-00</a>	heater

Product	Description
<a href="#">TPS057GT10-000</a>	
<a href="#">TPS151GT12-000</a>	
<a href="#">TL752-001 WOC</a>	
<a href="#">TF751-002</a>	
<a href="#">P/N: PF752-001, Type: IMM HTR, PF 750W 240V W/ CORD</a>	
<a href="#">CUB-752FP</a>	Push in heater
<a href="#">TF752-002</a>	
<a href="#">OW430110-000</a>	
<a href="#">21SCH12C</a>	CORD
<a href="#">CSM10902-5A0</a>	COOLANT SYSTEM
<a href="#">RECSM10902</a>	REPL ELEM
<a href="#">TFTA-5/8HB</a>	
<a href="#">CUN-152B</a>	Direct IMM heater
<a href="#">PRP228070-000S</a>	Recirculation pump
<a href="#">CB120200-000</a>	preheater
<a href="#">E01541E-15BV-00</a>	
<a href="#">21PR72T</a>	
<a href="#">TPS202GT10-008</a>	
<a href="#">P/N: E06021W-COAT-00</a>	Thermostat
<a href="#">FSU10</a>	thermostat
<a href="#">RE25210-CTM</a>	heating element
<a href="#">CSM30904-000</a>	coolant system
<a href="#">P/N: CL150210-200, Type: CL 5000W 240V 100-120F</a>	
<a href="#">OW415200-000</a>	OIL LUBE .75DIA 150W 240V WT
<a href="#">PRP228052-015</a>	PUMP
<a href="#">TPS102GT10-007 OEM</a>	HEATER
<a href="#">TPS152T10-000</a>	
<a href="#">TPS152T10-013</a>	
<a href="#">TPS102GT10-019</a>	
<a href="#">PRP231026-002</a>	Thermostat
<a href="#">DLV3180-060A-00</a>	DLV 400V 50Hz 3P COOLANT 18kW
<a href="#">CTM10210A00</a>	Pump
<a href="#">CL140212-200</a>	
<a href="#">E300A3E-C0NV-00</a>	
<a href="#">E090A3E-40NV-00</a>	
<a href="#">PRP228017-004</a>	pump
<a href="#">PRP228017-300</a>	seal kit
<a href="#">PRA228048-004</a>	pump
<a href="#">PRP228048-300</a>	SEAL KIT
<a href="#">PRP203010-000</a>	CHECK VALVE
<a href="#">PRP203251-000</a>	RELIEF VALVE
<a href="#">PRP224310-000</a>	GAUGE (P&T)
<a href="#">PRP215113-000</a>	V-CLAMP AND O-RING KIT
<a href="#">PRP127009-004S</a>	HOSE ASSY
<a href="#">PRP227038-000</a>	HOSE ASSY

Product	Description
<a href="#">PF752-002</a>	Heater
<a href="#">TPS152GT10-013</a>	Heater
<a href="#">PRP127017-007</a>	HOSE
<a href="#">TPS152GT10-000</a>	Heater
<a href="#">TF152-009</a>	
<a href="#">BW1015406S-000</a>	
<a href="#">CB125208-200</a>	Engine coolant heater
<a href="#">CL130208-200</a>	Engine coolant heater
<a href="#">TPS107GT10-000</a>	Engine heater
<a href="#">TFT12-200</a>	Remote Thermostat
<a href="#">CB115110-200</a>	
<a href="#">CL140EA2-000</a>	
<a href="#">E30043E-C0NV-00</a>	
<a href="#">PRP232117-009</a>	CONTACTOR
<a href="#">TPS102GT8-000</a>	TPS TANK STYLE ENGINE PRE-HEATER
<a href="#">TPS051GT10-000</a>	
<a href="#">CL130110-200</a>	
<a href="#">CSM10902-000</a>	
<a href="#">CSM10602-000</a>	COOLANT SYSTEM
<a href="#">CB115308-200</a>	
<a href="#">PRP228052-012</a>	Pump
<a href="#">PRP228052-000</a>	pump
<a href="#">CTM-P</a>	pump
<a href="#">CSM11202-000</a>	HOTflow® Engine Heater, CSM Model
<a href="#">TPS152GT8-005</a>	
<a href="#">E06021W-C0NT-00</a>	Thermostat
<a href="#">JDS-102</a>	
<a href="#">CKM1040250-000</a>	preheating module
<a href="#">OW430208-000</a>	
<a href="#">TPS101GT10-000</a>	PREHEATING RESISTANCE
<a href="#">TPS151GT10-000</a>	
<a href="#">CTM15210-N00</a>	
<a href="#">CTM25210-N00</a>	
<a href="#">CSM3090A-5AX</a>	
<a href="#">TPS151GT12-007</a>	
<a href="#">TFT8-220</a>	
<a href="#">P/N: CL130210-200, Type: CL 3000W 240V 100-120F</a>	
<a href="#">TPS202GT10-013</a>	
<a href="#">OC3M3090A10-000</a>	
<a href="#">CSM3120A-5A0</a>	
<a href="#">TFT8-200</a>	
<a href="#">C124948 OEM TPS151GT12-000</a>	Heating system
<a href="#">FSU90-130</a>	Sensing Unit
<a href="#">TFT8-200 TFT 80-100F 1NPT FEMALE</a>	
<a href="#">TFT8-220 TFT 80-100F 1NPT MALE</a>	

Product	Description
<a href="#">E01021W-156A-00</a>	
<a href="#">TPS202GT10-000</a>	
<a href="#">TPS151GT8-000</a>	
<a href="#">TPS202GT12-000</a>	
<a href="#">CTM-P-KIT</a>	O-RING & GASKET
<a href="#">TPS181GT10-000</a>	
<a href="#">TPS151GT10-002</a>	
<a href="#">REPS152T10</a>	
<a href="#">TPS-BOR</a>	BASE O-RING FOR TPS HEATER
<a href="#">TPS152GT8-000</a>	Coolant Preheater
<a href="#">TPS207GT10-000</a>	
<a href="#">CTM10210-E00</a>	
<a href="#">FSU8</a>	contact thermostat
<a href="#">CB115208-200</a>	
<a href="#">PRP228052-003S</a>	pumping
<a href="#">TPS202GT8-000</a>	
<a href="#">E15043E-50NS-00</a>	
<a href="#">CTM-IMK</a>	Isolation Mounting Kit
<a href="#">TPS052GT10-004</a>	
<a href="#">RECB1252</a>	
<a href="#">RECSM31203</a>	
<a href="#">P/N: 224003-008, Type: FSU8</a>	sensing unit
<a href="#">P/N: 224085-000, Type: HLC-165</a>	high limit control
<a href="#">HLC-165</a>	high limit control
<a href="#">P/N: CB120210-200, Type: CB 2000W 240V 100-120F</a>	
<a href="#">TPS207GT10-001</a>	
<a href="#">CLP3300A-00</a>	
<a href="#">P/N: CL150208-200, Type: CL 5000W 240V 80-100F</a>	
<a href="#">P/N : PRP228052-012 Type : UP 15-60 U 130</a>	circulation pump
<a href="#">P/N: CL130208-200, Type: CL 3000W 240V 80-100F</a>	
<a href="#">WL350A10-200</a>	HEATER
<a href="#">P/N: WL340A10-200, Type: WL 4000W 400V 3P 100-120F</a>	
<a href="#">CTM25210-E00</a>	
<a href="#">CSM10607-5A0</a>	
<a href="#">CL130710-200</a>	
<a href="#">TPS102GT10-011</a>	
<a href="#">PRP213009-001</a>	FLANGE KIT
<a href="#">TPS152GT12-001</a>	
<a href="#">CTM25110-A00</a>	Hot Flow Coolant Heater
<a href="#">CSM3090F-5A1</a>	Light & switch
<a href="#">TPS102GT10-008</a>	
<a href="#">30305030501</a>	
<a href="#">PRP228052-014</a>	pump
<a href="#">CL140210-200</a>	Hotstart Tank Heaters
<a href="#">E130210-000</a>	engine heater

Product	Description
<a href="#">TFT10ER (100-120F)</a>	
<a href="#">TPS152GT112-A00</a>	
<a href="#">TPS202GT8-001</a>	Block Heater
<a href="#">30305036001 oem</a>	engine coolant heater
<a href="#">RSU10</a>	DETECTION UNIT FOR TFT-TFTC
<a href="#">TPS102T10-000</a>	coolant heater
<a href="#">TFTCA-5/8HB</a>	
<a href="#">CTM25208-TD5</a>	
<a href="#">OCLA3180-060A-3B20</a>	
<a href="#">CAT-12023</a>	HEATER
<a href="#">PRP236302-001</a>	
<a href="#">E090A3W-C0BT-00</a>	
<a href="#">OE430200-000</a>	
<a href="#">E02033E-156A-00</a>	
<a href="#">CL1602A3-220</a>	
<a href="#">TPS151GT12-004</a>	
<a href="#">SL140200-100</a>	
<a href="#">SB120208-200</a>	coolant preheater
<a href="#">CSM4120A-5A0-E</a>	
<a href="#">LSU-10</a>	LUBE STAT SENSING UNIT
<a href="#">CB120208-200</a>	HEATER
<a href="#">DIT1012</a>	
<a href="#">CL160EA2-000</a>	
<a href="#">CB125310-200</a>	
<a href="#">CTM25210-A00</a>	CTM-ENGINE COOLANT HEATER
<a href="#">CB125410-200</a>	
<a href="#">RECSM3120F-0A0</a>	
<a href="#">RSU1013-CSM</a>	Thermostat
<a href="#">PRP235098-000</a>	Transformer
<a href="#">PRP232117-001</a>	Contactactor
<a href="#">PRP231154-100S</a>	24V Relay
<a href="#">PRP231153-000S</a>	Relay Socket
<a href="#">PRP231059-002</a>	Fuse
<a href="#">PRP231174-001</a>	Light Switch
<a href="#">TPS052GT10-013</a>	ENGINE
<a href="#">FSU12</a>	sensing unit
<a href="#">PS252</a>	pressure switch
<a href="#">SL140212-200</a>	
<a href="#">RSU10-TF</a>	sensing unit
<a href="#">CSM3060F-5A1</a>	
<a href="#">E24033E-C0NV-00</a>	
<a href="#">DD8L-102</a>	
<a href="#">CSM3120D-5A0</a>	
<a href="#">RECB1152</a>	Heater Element
<a href="#">RTCC</a>	Terminal box

Product	Description
<a href="#">BW0824606S-000</a>	
<a href="#">TPS152GT10-013 / 240 V 1500 W</a>	
<a href="#">PRP203010-001</a>	valve check 1 npt (standard)
<a href="#">TPS157GT10-000</a>	
<a href="#">BPC-62</a>	
<a href="#">AMT70210</a>	
<a href="#">TPS102GT12-000</a>	
<a href="#">CSM10301-000 (6kW)</a>	
<a href="#">HH-3/4</a>	
<a href="#">HH-5/8</a>	
<a href="#">LSU-10 -LUBE STAT SENSING UNIT 100-120F</a>	
<a href="#">CSM10608-000</a>	
<a href="#">CSM1060J-5A0</a>	
<a href="#">CSM10604-000</a>	
<a href="#">VH15210-000</a>	
<a href="#">RECSM30606-051</a>	GE1 water heater
<a href="#">E060G3W-50BT-00</a>	
<a href="#">E01511E-158A-00</a>	
<a href="#">TPS102GT10-007</a>	
<a href="#">OW650900-024</a>	oil heater
<a href="#">WL325A10-200</a>	
<a href="#">CB125810-200</a>	
<a href="#">Type CTM-P</a>	
<a href="#">OE650200-000</a>	HEATER
<a href="#">30305055301</a>	
<a href="#">Type TPS052GT10-013</a>	heater
<a href="#">Type LSU-10</a>	thermostat
<a href="#">CSM3030A-5A0</a>	
<a href="#">CSM4060A-5A0-E</a>	
<a href="#">CSM4090A-5A0-E</a>	
<a href="#">STD / OSE10252-220</a>	
<a href="#">CTM10210-N00</a>	
<a href="#">SB115210-200</a>	
<a href="#">RECSM1120J-0A0</a>	REPL ELEM ASM CSM
<a href="#">PRP232117-005</a>	CONTACTOR 65A 240V 2P
<a href="#">RE10210-CTM</a>	heating
<a href="#">TPS102GT8-006</a>	heater
<a href="#">PRP228048-301</a>	Set of mechanical seals
<a href="#">PRP228050-301</a>	Set Mechanical seal kit
<a href="#">Type PRA228076-001</a>	
<a href="#">PRP221106-00</a>	
<a href="#">Type PRP228052-001</a>	
<a href="#">PRP236249-001</a>	MOTOR
<a href="#">RECSM31202</a>	
<a href="#">RECSM3120A-0A0</a>	

Product	Description
<a href="#">A050V428</a>	Heater
<a href="#">Type CSM3120A-5A0</a>	
<a href="#">FR752-002</a>	
<a href="#">FR102-000</a>	
<a href="#">TPS202GT8-004</a>	
<a href="#">E02021E-156A-00</a>	
<a href="#">OW650200-000</a>	
<a href="#">OW212200-000</a>	
<a href="#">TPS057GT8-000</a>	
<a href="#">RSU8</a>	
<a href="#">VH15210-000</a>	
<a href="#">SB125208-200</a>	BLOCK PREHEATER 2500 W. 240 V.
<a href="#">JD1-102IN</a>	
<a href="#">E02021E-15BA-00</a>	
<a href="#">SB120200-000</a>	
<a href="#">LSU-8</a>	
<a href="#">E01521E-15BA-00</a>	
<a href="#">E300A3E-CONV-00</a>	
<a href="#">CKM1050250-000</a>	
<a href="#">CB125110-200</a>	CB2500W 120V 100-120F
<a href="#">CTM10110-A00</a>	
<a href="#">CL140208-200</a>	
<a href="#">VH15210-000</a>	
<a href="#">TPS151GT12-001</a>	
<a href="#">VH15208-000</a>	
<a href="#">CL130210-200</a>	