



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онĝл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Koino

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">KBL30MP</a>	Illuminated Push Button Switch, Protected type
<a href="#">KH- 503L-AC110V/RED</a>	Pilot lamp
<a href="#">KH-301</a>	Cam Switch
<a href="#">KH-3011</a>	
<a href="#">KH-3066EB GREEN (pack 1x5 pcs)</a>	Push button switch
<a href="#">KH-4022 (Dual)</a>	Alarm buzzer
<a href="#">KH-403D-24</a>	continous buzzer
<a href="#">KH-513DL-DC24V-Y</a>	
<a href="#">KH-513L-110VAC /green</a>	push button switch
<a href="#">KH-516-C00-W24</a>	
<a href="#">KH-60200-4</a>	TERMINAL BLOCK
<a href="#">KH-60300-3</a>	Terminal Block
<a href="#">KTM-1T</a>	Timer
<a href="#">KH 9016-RP</a>	switch
<a href="#">KH-302R-2401 Knob Type H</a>	Cam Switch
<a href="#">KH-309</a>	(KSL25L2-11) ** SELECTOR SWITCH
<a href="#">KH-103-4CL-DC12V</a>	** RELAY
<a href="#">KH-307</a>	(KPB25M-11) ** PUSH BUTTON SWITCH
<a href="#">KH-403F-24 (pack 1x5 pcs)</a>	Buzzer
<a href="#">KH-503TL</a>	.
<a href="#">KH-301C-1</a>	cam switch
<a href="#">KH-3065EB 30mm Emergency Green Push Button</a>	
<a href="#">KH-3065EB-11-Y</a>	PUSH BUTTON SWITCH
<a href="#">KH-3065EB-11-G</a>	push button switch
<a href="#">KH-3065EB-11-R</a>	Emergency Push Button Switch
<a href="#">KH-4065A</a>	Signal phone
<a href="#">KH-5040L</a>	
<a href="#">KH-60300-4</a>	4Pole Terminal Block
<a href="#">KH-3030-2</a>	2Position Key Switch
<a href="#">KH-3040-11</a>	PUSH BUTTON SWITCH
<a href="#">KH-3040 (pack x10)</a>	JOG BUTTON
<a href="#">KPB30MS-20-BK</a>	SELECTOR SWITCH
<a href="#">KPB30M (Red)</a>	Push button
<a href="#">KSL30K2-11</a>	SELECTOR SWITCH
<a href="#">KH-5030L-DC24V-W.B Alternative</a>	
<a href="#">KH-503L</a>	

Product	Description
<a href="#">KH-103-H2CL (AC6/12/24/50V)</a>	Relay
<a href="#">KH-6115S</a>	Terminal Block
<a href="#">KH-301-3109</a>	CAM SWITCH
<a href="#">KH-503L-R</a>	PILOT LAMP
<a href="#">KH-2201-10BK</a>	
<a href="#">KH-2201-10R</a>	
<a href="#">KH-2201-10Y</a>	
<a href="#">KH-2201ER-22R</a>	
<a href="#">KH-2201-G, R, B</a>	
<a href="#">KH-2201S-11B</a>	
<a href="#">KH-2201-20Y</a>	
<a href="#">KH-2202-2K 22MM</a>	2-POS KEY SWITCH
<a href="#">KH-2202-2S-11</a>	
<a href="#">KH-2202-3K</a>	
<a href="#">KH-2204LP-2-11G</a>	
<a href="#">KH-2204LP-2-11Y</a>	
<a href="#">KH-5020L-24 Red,Green,Yellow</a>	
<a href="#">KPB30M-G10, Y, BK, R, W</a>	
<a href="#">NF30-PM-Y</a>	
<a href="#">KSL30K2</a>	KEY SELECTOR SWITCH
<a href="#">KSL30S3</a>	
<a href="#">KPB30ER -11- X</a>	Push Button, Turn To Reset
<a href="#">KH-402-2</a>	Buzzer
<a href="#">KEPB16ER-R2B</a>	Push Button Turn to Reset Switch, Red
<a href="#">KH-9016-PBL (pack x10)</a>	Microswitch
<a href="#">KH-3011-11</a>	Selector switch
<a href="#">KH-3012-20</a>	SELECTOR SWITCH
<a href="#">KH-2203L-2-R</a>	
<a href="#">KH-9015-HL</a>	
<a href="#">KH-2202-3K-20</a>	KEY SWITCH
<a href="#">KH-60300-4 300A 4P</a>	
<a href="#">KH-3071EB-11-Y</a>	
<a href="#">KH-516-C00-R24</a>	
<a href="#">KSL30S3-20 30mm 3Position 2NO Selector Switch</a>	Selector Switch
<a href="#">KH-3011-2 30mm 2Position Selector Switch</a>	Selector Switch
<a href="#">KH-2202-3L-20 22mm 3Position 2NO Selector Switch</a>	Selector Switch
<a href="#">KH-2201EB-11Y 22mm 1NO+1NC Yellow Mushroom Push Button</a>	Push Button Switch
<a href="#">KPB30M-G11 30mm 1NO+1NC Green Push Button</a>	Push Button Switch
<a href="#">KPB30 IP65/Momentary/RED/1NO+1NC</a>	Push button switch
<a href="#">KH-2204LP-TL-11G 22mm 1NO+1NC Green LDED Illuminated Push Button</a>	
<a href="#">KH-2202-3S-20 22mm 3Position 2NO Selector Switch</a>	Selector Switch
<a href="#">KH-2204L-TL-R</a>	
<a href="#">KH-2204L-TL-Y</a>	
<a href="#">KH-2201-11-BK</a>	Push Button Switch

Product	Description
<a href="#">KH-2204L-TL-G</a>	
<a href="#">KH-2201-11-G</a>	
<a href="#">KH-2201-11-W</a>	
<a href="#">KPB30EM-11G</a>	
<a href="#">KH-5040L RED</a>	SQ LIGHT=HEAT TRACING
<a href="#">KH-5040L YELLOW</a>	
<a href="#">KH-5040L GREEN</a>	
<a href="#">KH-5040L WHITE</a>	
<a href="#">KH-5040L BLUE</a>	
<a href="#">YS24VR (RED COLOUR)</a>	
<a href="#">YS24VG (GREEN)</a>	
<a href="#">YS24VY (YELLOW)</a>	
<a href="#">YS 24V White</a>	
<a href="#">YS24VB (BLUE)</a>	
<a href="#">KPB30M-11R</a>	
<a href="#">KPB30M-11-G</a>	
<a href="#">KH-103-4CL (AC110/220V)</a>	
<a href="#">KH-103-4CL (DC 12/24V)</a>	RELAY
<a href="#">KH-103-4CL (AC6/12/24/50/230/240V)</a>	RELAY
<a href="#">KH-103-4CL(DC6/48/110V)</a>	RELAY
<a href="#">KH-4025-2</a>	BUZZER
<a href="#">KCB-303D</a>	CONTROL BOX
<a href="#">KH-2201ER-01R (1 box=10 pcs)</a>	
<a href="#">KLJN-A2</a>	
<a href="#">KH-2203-TL-24</a>	
<a href="#">KH-9016-RP</a>	
<a href="#">KSL25L2-11</a>	manual selector switch 25mm
<a href="#">KCB-252D</a>	ELECTRICAL BOX
<a href="#">KH-103-4CL DC24V (pack x10)</a>	
<a href="#">KH-103-H2CL 220VAC</a>	relay
<a href="#">KH-3040-11-G</a>	SWITCH
<a href="#">KH-8115</a>	FOOT SWITCH
<a href="#">KH-2204LP-TL-G</a>	PUSH BUTTONS LAMP
<a href="#">THE BUTTON ONLY FOR KH-3065EB</a>	
<a href="#">KH-9012-5HRL-C</a>	Micro Switch
<a href="#">KPB30M-11</a>	
<a href="#">KTM-3M-30S-D2</a>	
<a href="#">KH-102-3C DC24V</a>	
<a href="#">KH-3065EB-11-G:10.R:10</a>	PUSH BUTTON SWITCH
<a href="#">KH-2201-11-Y</a>	PUSH BUTTON SWITCH
<a href="#">KH-2201EB-11G</a>	
<a href="#">KCR-303-3109</a>	
<a href="#">KTM-AMT</a>	
<a href="#">KH-2204LP-TL-11R 22mm 1NO+1NC 24V Red LED Illuminated Push Button.</a>	

Product	Description
<a href="#">KLNJ IP67</a>	
<a href="#">KLCL</a>	
<a href="#">KLCA12</a>	limit switch
<a href="#">KH-9011</a>	
<a href="#">KH-503DL-DC24V-W</a>	PILOT LAMP
<a href="#">KH-503DL-DC24V-G</a>	PILOT LAMP
<a href="#">KH-516L-B00-DC24V-R.G.Y</a>	PILOT LAMP
<a href="#">KH-2201ER-22-G</a>	PUSH BUTTON SWITCH
<a href="#">KSL30K3-20</a>	SELECTOR SWITCH
<a href="#">KH-5030L-DC24V-R.G.Y</a>	SQUARE LIGHT
<a href="#">KBL30M-L3C-Y11</a>	
<a href="#">KH-3065EB-Y11</a>	
<a href="#">KPB30ER-11R</a>	
<a href="#">KBL25M-L2A</a>	
<a href="#">KBL30MP-LA2</a>	
<a href="#">KBL30MP-L2A -11-</a>	
<a href="#">KH-513TL</a>	
<a href="#">KH-516L-B00-DC24V-W.B</a>	PILOT LAMP
<a href="#">KH-5030L-DC24V-W.B</a>	SQUARE LIGHT
<a href="#">KH-101-2A</a>	relay
<a href="#">KPB25M-11BK</a>	
<a href="#">KPL30-L3C (Red,Green,Yellow)</a>	
<a href="#">KPL30-L3C (White,Blue)</a>	
<a href="#">KLCA12-LE</a>	
<a href="#">KLCA12-LD</a>	
<a href="#">KPB25ER-11-Y</a>	push button switch
<a href="#">KH-302KL-7*4</a>	KEY LOCKER
<a href="#">KSL30L3</a>	Selector Switch
<a href="#">KH-3066EB-11 (1a1b)</a>	PUSH BUTTON SWITCH
<a href="#">KH-514</a>	
<a href="#">KLD2</a>	limit switch
<a href="#">KH-2203-TL (WHITE) PILOT LIGHT</a>	
<a href="#">KH-2203-TL (GREEN) PILOT LIGHT</a>	
<a href="#">KH-2204LP-TL-DC24V-Y</a>	LED ILLUMINATED PUSH BUTTON
<a href="#">KPB25EM-Y11</a>	yellow push button
<a href="#">KH2201EB-11BK</a>	
<a href="#">KPB25EM-R11</a>	red push button
<a href="#">KPB25M-11Y</a>	PUSH BUTTON
<a href="#">KPB25M-11-R</a>	PUSH BUTTON SWITCH
<a href="#">KPB30M-11-BK</a>	
<a href="#">KTS-S25MGL (built-in resistors, cover, 50cm wire)</a>	
<a href="#">KSL25K2</a>	PB(MOMENTARY 24V DC)
<a href="#">KH-301-3109R</a>	SWITCH
<a href="#">K57-S01</a>	TEMPERATURE CONTROL
<a href="#">KH-2203-TL 24V 1W PILOT LAMP</a>	

Product	Description
<a href="#">KH-2202-2L-11</a>	SELECTOR SWITCH
<a href="#">KH-2204-2-11R</a>	
<a href="#">KH-2201-10G</a>	PUSH BUTTON
<a href="#">KH-2203L-TL-DC24V-G</a>	LED PILOT LAMP
<a href="#">KH-2203L-TL-DC24V-W</a>	LED lamp
<a href="#">KH-2204LP-TL-DC24V-G</a>	LED ILLUMINATED PUSH BUTTON
<a href="#">KH-8010-SLTA (NO.4 CORE DIE OUT)</a>	LIMIT SWITCH
<a href="#">KH-8010-SLTA</a>	LIMIT SWITCH
<a href="#">KSL 2</a>	KEY ONLY FOR SELECTOR SWITCH
<a href="#">KH-2202-2S 22MM</a>	2-POS SELECTOR SWITCH
<a href="#">KSL30S2-10</a>	
<a href="#">KH-3008-11-BK</a>	
<a href="#">KH-513DL DC24V</a>	
<a href="#">KPL30</a>	PILOT LAMP
<a href="#">KH-3046ER same as KH-3046ER-11</a>	EMERGENCY STOP BUTTON
<a href="#">KPL30-3C 24VAC/DC</a>	
<a href="#">KH-2202-3AL-20</a>	SELECTOR SWITCH
<a href="#">KH-2201ER-10-R Alternative</a>	
<a href="#">KH-2201ER-01R</a>	Ø22mm 1NC Contact Emergency Stop Push Button
<a href="#">KPB-25ER/RED/2NO+2NC</a>	
<a href="#">KH-2201ER-11R</a>	1A1B RED EMERGENCY STOP BUTTON
<a href="#">KPB25WM-20-B (MOQ 10 pcs)</a>	Push button
<a href="#">KH-9016-HLL</a>	LIMIT SWITCH
<a href="#">KH-103-4C AC110V</a>	
<a href="#">KH-103-4C/DC24V</a>	
<a href="#">KH-102-2C-DC125V</a>	
<a href="#">KH-RS-R8</a>	Relay Socket
<a href="#">KH-2202-2K-11</a>	KEY SWITCH
<a href="#">KH-2201ER-11</a>	EMERGENCY SWITCH
<a href="#">KH-302KL-5301</a>	
<a href="#">KH-9012-HLRC</a>	LIMIT SWITCH
<a href="#">KPS-P300S</a>	
<a href="#">KSC-22 4202</a>	
<a href="#">KH 6030-3</a>	
<a href="#">KH-103-4CL/220VAC (pack 1x10)</a>	Relay
<a href="#">KFS-PC8 (pack x5)</a>	Level switch
<a href="#">KH-3071EB (pack x10)</a>	Pushbutton Switch GREEN
<a href="#">KPB-25ER/RED/1NO+1NC (pack x20)</a>	
<a href="#">KH-9015-HR-M</a>	LIMIT SWITCH
<a href="#">KSL30AK2-11</a>	switch
<a href="#">KH-2203L-TL (lamp cup - R)</a>	Pilot lamp
<a href="#">KPB25M-BK11</a>	PUSH BUTTON
<a href="#">KBL30M-L3C-Y</a>	
<a href="#">KH-501-R</a>	PILOT LAMP RED
<a href="#">KBL30M-L3C-R</a>	

Product	Description
<a href="#">KH-516-C11-G24</a>	
<a href="#">KH-516-C11-R24</a>	
<a href="#">KH-8005-C</a>	Limit switch
<a href="#">KH-516-C31</a>	Ø16 PUSH BUTTON SWITCH
<a href="#">KH-2201-11-R</a>	Push button
<a href="#">KH-4025D</a>	
<a href="#">KH-9015-PBS</a>	Micro switch
<a href="#">KH-RS-14N (pack x20)</a>	MULTI TIMING RELAY
<a href="#">LED bulbs of KBL30M-L2A (Red,Green,Yellow)</a>	
<a href="#">LED bulbs of KBL30M-L2A (White,Blue)</a>	
<a href="#">KSC-22-2531</a>	switch tranfer
<a href="#">KSC-22-3234</a>	switch transfer
<a href="#">KH-3046ER-11-R</a>	PUSH BUTTON SWITCH
<a href="#">KH-2204LP-TL-11R</a>	
<a href="#">KH-2204LP-TL-11G</a>	
<a href="#">KH-516-C00-DC24</a>	LAMP
<a href="#">KH-4022 (Direct)</a>	Alarm buzzer
<a href="#">KH-4022 (Flicker)</a>	Alarm buzzer
<a href="#">KH-6060-3P (pack x10)</a>	
<a href="#">KH-6060-4P (pack x10)</a>	
<a href="#">KPB25ER-11-?</a>	Emergency Button
<a href="#">Z4G1P09B</a>	
<a href="#">KH-RS-14M</a>	Relay socket
<a href="#">KPB25ER-11-R</a>	Mushroom-head push button switch
<a href="#">KTM-3MN-1-D2</a>	MULTI TIMING RELAY
<a href="#">Red button for KH-3046ER</a>	Button
<a href="#">KPB 25 ER - R11 (package of 20 pcs)</a>	Push Button
<a href="#">KH-3081EB-11-G</a>	Pushbutton switch
<a href="#">KH-302K-2103</a>	SWITCH
<a href="#">KTM-3M-60S-D2</a>	
<a href="#">KH-302K-3233</a>	
<a href="#">KPB-25WER-R-11 (pack x10)</a>	ESTOP SWITCH
<a href="#">KPB25M-11-G</a>	switch
<a href="#">KH-5040L-24 Red</a>	
<a href="#">KH-5040L-24 White</a>	
<a href="#">KPB30ER-11 /red</a>	Emergency button
<a href="#">KH-2201-01R</a>	
<a href="#">KH3065EBG</a>	
<a href="#">KH-3046ER (pack x10)</a>	Push button switch (EMERGENCY STOP)
<a href="#">KH-403-1</a>	BUZZER
<a href="#">KH-8018</a>	Foot Switch
<a href="#">KBL25M-L3C-G11</a>	Illuminated Push Button Switch
<a href="#">KPB25M-B11</a>	Push-button spring blue
<a href="#">KH-103-H2CL (pack x10)</a>	
<a href="#">KLCA2-LD</a>	

Product	Description
<a href="#">KPB25WM-11G</a>	Push Button Switch
<a href="#">KSEP-25402</a>	Switch
<a href="#">KSEP-25404</a>	Switch
<a href="#">KSL25K3-20</a>	Switch
<a href="#">KSL25AK3-20</a>	Switch
<a href="#">KBL 30 WMP-L2A Red,Green,Yellow</a>	Switch with Light
<a href="#">KBL 30 WMP-L2A White,Blue</a>	switch with light
<a href="#">KPB25M-G11</a>	Push Button Switch
<a href="#">KPL30W-L2A Red,Green,Yellow</a>	
<a href="#">KPL30W-L2A White,Blue</a>	
<a href="#">KSL30WL3-20</a>	
<a href="#">KH-301-V33</a>	
<a href="#">KPB30WER-11</a>	
<a href="#">KH-5030L-24 Red,Green,Yellow</a>	
<a href="#">KC-22</a>	
<a href="#">KH-8005-PR</a>	
<a href="#">KH-2201-BK</a>	Push Button Switch
<a href="#">KH-9015-PBF</a>	MICRO SWITCH
<a href="#">KBL30MP-L3C-R</a>	Emergency button
<a href="#">KBL30MP-L3C-O</a>	Illuminated Push button switch
<a href="#">KH-3066EB (pack x10)</a>	
<a href="#">KPS-AP3000 (emitter+receiver)</a>	
<a href="#">KPB25M-Y11</a>	Push button switch
<a href="#">KH-513-TL-DC24V-G</a>	
<a href="#">KH513TL red</a>	
<a href="#">KH-513-G</a>	
<a href="#">KBL30MP-3C (Red)</a>	Illuminated Push Button
<a href="#">KBL30MP-3C (Green)</a>	Illuminated Push Button
<a href="#">KBL30MP-L3C11 DC24 (R.G.Y)</a>	Illuminated Push Button Switch
<a href="#">KH-2201-11</a>	Button
<a href="#">KH-2204P-2411</a>	22mm 1NO+1NC 24VAC/DC Illuminated Push Button
<a href="#">KH-2204LP-TL-11Y</a>	
<a href="#">KH-302R</a>	
<a href="#">KH-9015-PBL</a>	micro switch
<a href="#">P/N: KH-5002-1L-R</a>	Pilot lamp LED Red
<a href="#">P/N: KH-5002-1L-Y</a>	Pilot lamp, LED Yellow
<a href="#">P/N: KH-5002-1L-W</a>	Pilot lamp
<a href="#">P/N: KH-5002-1L-G</a>	Pilot lamp
<a href="#">P/N: KH-512-L-R</a>	Pilot lamp
<a href="#">P/N: KH-512-L-G</a>	Pilot lamp
<a href="#">KSL-25-L-3-20</a>	Selector
<a href="#">KPB-25-M-11</a>	Push button
<a href="#">KH-102-3C/LED/AC220V</a>	Electrical Switch & Accessory RELAY
<a href="#">KH-102-3C/no-LED/AC220V</a>	
<a href="#">KH-103-4CL, 230VAC</a>	relay



Product	Description
<a href="#">KH-9015-CRP</a>	Micro Switch
<a href="#">KSEP-224-02</a>	
<a href="#">KLCA2-2-LD3</a>	limit switch
<a href="#">KH8005-R</a>	limit switch
<a href="#">KBL30M-L3C-G11</a>	
<a href="#">KPB30M-11-Y</a>	
<a href="#">KBL30MP-L3C-Y11</a>	
<a href="#">KBL30MP-L3C-R11</a>	
<a href="#">KPB30M-BK11</a>	
<a href="#">KSL25W-S3</a>	
<a href="#">KPB25WAT-R20</a>	SWITCH
<a href="#">KA-005-25</a>	
<a href="#">KH-2203-2G(Ac220V)</a>	
<a href="#">KH-2203-2-W(AC220V)</a>	220V WHITE PILOT LAMP
<a href="#">KH-2204P-TL-DC24V</a>	PUSH BUTTON
<a href="#">KH-2204P-3(AC230V)</a>	PUSH BUTTON
<a href="#">KH-2204ER-3(AC230V)</a>	PUSH LOCK & TURN RESET BUTTON
<a href="#">NS22-S3-2A0B</a>	Manual Switch SELECTOR
<a href="#">KLCA12-2LD (pack x10)</a>	Limit Switch
<a href="#">KH-103-H2CL AC220V</a>	
<a href="#">KH-8012</a>	FOOT SWITCH
<a href="#">NF22-BM-3CG1</a>	Illuminated push button switch green NF22 (Intrinsic)
<a href="#">NF22-BM-3CB1</a>	Illuminated push button switch blue NF22 (Intrinsic)
<a href="#">KSD-2BC</a>	Safety switch
<a href="#">KSD-2BV</a>	Safety switch
<a href="#">KSC-22-6302H</a>	SWITCH
<a href="#">KSC-22-3501H</a>	SWITCH
<a href="#">KSC-22-3234F</a>	SWITCH
<a href="#">KSC-22-5201H</a>	SWITCH,
<a href="#">KSC-22-5204H</a>	SWITCH
<a href="#">KSC-22-5401H</a>	SWITCH
<a href="#">KPB 25 WM-11-R</a>	Push Button Switch
<a href="#">KPB25WM-01-G</a>	Push Button, Momentary
<a href="#">KPB25WM-11-B</a>	Push Button, Momentary
<a href="#">KH-3065EB GREEN</a>	Switch
<a href="#">KH-103-4CL/AC220V</a>	RELAY
<a href="#">KBL30MP-L2A -11-R</a>	
<a href="#">KBL30MP-L2A -11-G</a>	
<a href="#">KBL30MP-L2A -11-Y</a>	
<a href="#">KBL30MP-L2A -11-O</a>	
<a href="#">KBL30MP-L2A -11-W</a>	
<a href="#">KBL30MP-L2A -11-B</a>	
<a href="#">KSL30L2-11</a>	
<a href="#">KSL30AL3-20</a>	
<a href="#">KH-2201</a>	

Product	Description
<a href="#">KPB25WM-111-B</a>	Button- blue
<a href="#">KH-9015-RP</a>	Micro Switch
<a href="#">KH60200-3</a>	
<a href="#">KH-2204EB-TL</a>	
<a href="#">KH-8005-SR</a>	swich
<a href="#">KH-60300-4P</a>	
<a href="#">KBL30MP-L2A-G</a>	Push Button
<a href="#">KH-3040</a>	Push button switch
<a href="#">KTS-S25MG</a>	
<a href="#">KTS-S25MGL (no resistors, no cover, 50 cm wire)</a>	
<a href="#">KH-3046ER-11</a>	complete switch
<a href="#">KH-301-3103</a>	
<a href="#">button for KH-3046ER</a>	
<a href="#">KH-9012-HRS-C</a>	micro switch
<a href="#">KH-3008-11-Y</a>	
<a href="#">KH-516-C11-DC24V-W</a>	
<a href="#">KPS-M21</a>	sensor
<a href="#">KPL16-L3CW</a>	
<a href="#">KH-516-A31 green</a>	push button
<a href="#">KH-516-A31 red</a>	push button
<a href="#">KH-302K5303</a>	CAM switch
<a href="#">KH-2204-TL-DC24V-11-B</a>	ILLUMINATED PUSHBUTTON SWITCH
<a href="#">KH-301-3202(R)</a>	Cam Switch
<a href="#">KH-2204-TL-DC24V-11-R</a>	ILLUMINATED PUSHBUTTON SWITCH
<a href="#">KH-2204-TL-DC24V-11-G</a>	ILLUMINATED PUSHBUTTON SWITCH
<a href="#">KH-2204-TL-DC24V-11-Y</a>	ILLUMINATED PUSHBUTTON SWITCH
<a href="#">KH-2204-TL-DC24V-11-W</a>	ILLUMINATED PUSHBUTTON SWITCH
<a href="#">KCB-223D</a>	
<a href="#">KPL25-L2A-W11</a>	
<a href="#">KPL25-L2A-G11</a>	
<a href="#">Z4G1L07B</a>	Short Hinge Roller Lever Micro Switch
<a href="#">KH-9015-HR-L</a>	micro switch
<a href="#">KH3065EB</a>	PUSH BUTTON SWITCH
<a href="#">ZC4G1P05B / KH-9016-PB(L)</a>	Micro Switch
<a href="#">KPL30-L3C-R</a>	
<a href="#">KPL30-L3C-G</a>	
<a href="#">KPL30-L3C-Y</a>	
<a href="#">KPL30-L3C-W</a>	
<a href="#">KPL30-L3C-B</a>	
<a href="#">KH-500TL-DC24V-1-R</a>	
<a href="#">KH-500TL-DC24V-1-G</a>	
<a href="#">KH-500TL-DC24V-1-Y</a>	
<a href="#">KH-500TL-DC24V-1-W</a>	
<a href="#">KSL25K2-10</a>	selector switch
<a href="#">KH-4016D (Direct)</a>	

Product	Description
<a href="#">KH-4016F (Flicker)</a>	
<a href="#">KH-4016W (Whistle)</a>	
<a href="#">KH-302KL-4202</a>	CAM SWITCH
<a href="#">KH-8005-S</a>	limit switch
<a href="#">KH-103-2C</a>	relay
<a href="#">KH-9010-MT</a>	Limit switch
<a href="#">KH-2203L-TL-R</a>	Pilot Lamp
<a href="#">KH-2203L-TL-Y</a>	Pilot Lamp
<a href="#">KH-2204LP1-11-R</a>	Illuminated Push Button
<a href="#">KH-516L-B11-DC24V-G</a>	Illuminated Push Button Switch(Led)
<a href="#">KH-516L-B21-DC24V-R</a>	Illuminated Push Button Switch(Led)
<a href="#">KH-516L-C00-DC24V-B</a>	Pilot Lamp(Led)
<a href="#">KH-516L-C00-DC24V-G</a>	Pilot Lamp(Led)
<a href="#">KH-516L-C00-DC24V-R</a>	Pilot Lamp(Led)
<a href="#">KH-516L-C00-DC24V-W</a>	Pilot Lamp(Led)
<a href="#">KH-561L-B11-G(24V)</a>	Illuminated push button switch
<a href="#">KH-561L-B21-R(24V)</a>	Illuminated push button switch
<a href="#">KH-561L-C00-B(24V)</a>	Pilot lamp
<a href="#">KH-561L-C00-G(24V)</a>	Pilot lamp
<a href="#">KH-561L-C00-R(24V)</a>	Pilot lamp
<a href="#">KH-561L-C00-W(24V)</a>	Pilot lamp
<a href="#">KH-302KL 5505</a>	switch
<a href="#">KH-4065D</a>	
<a href="#">KH-4025</a>	Buzzer
<a href="#">KH-102-2C 230v</a>	Relay
<a href="#">KH-5030L-24VDC Green</a>	Panel Mounted Annunciator
<a href="#">KPB25M-R-11</a>	Push button switch
<a href="#">KSEB-3043C13</a>	ILLUMINATED EMERGENCY STOP PUSH BUTTON SWITCH
<a href="#">KH-B3</a>	CONTACT BLOCK
<a href="#">KH-301-2203</a>	
<a href="#">KH-301-3233</a>	
<a href="#">KH-3065EB-R</a>	EMERGENCY PUSH BUTTON SWITCH, RED
<a href="#">KH-301CL-1</a>	Cam Switch
<a href="#">KH-9012-HRL-C</a>	Micro switch
<a href="#">KPB25ER-02-R</a>	
<a href="#">KH-5030L-24PCK</a>	
<a href="#">KH-5001-1</a>	
<a href="#">KH2203-TL 22mm (24VDC) (Orange)</a>	Pilot Lamp
<a href="#">KSL16S2-1 (1a1b)</a>	Manual Return Round Selector Switch
<a href="#">KSL16S2-2 (2a2b)</a>	
<a href="#">KH-103-H2CL (AC110/220V)</a>	Relay
<a href="#">KH-103-H2CL (DC6/48/110V)</a>	Relay
<a href="#">KH-103-H2CL (DC12/24V)</a>	Relay
<a href="#">KFS-ES3</a>	Electrode holder

Product	Description
<a href="#">KH-103-4CL-AC110V</a>	
<a href="#">KS2D-3BH</a>	
<a href="#">KTM-3M10S-A2</a>	On-Delay Time Delay Relay
<a href="#">KH-516L-B21-G(24)</a>	Illuminated PushButton
<a href="#">KH-516L- B21-R(24)</a>	Illuminated PushButton
<a href="#">KH-516L- A21-G(24)</a>	Illuminated PushButton
<a href="#">KH-516L- A21-R(24)</a>	Illuminated PushButton
<a href="#">KH-516L- B11-G(24)</a>	Illuminated PushButton
<a href="#">KH-516L- A11-G(24)</a>	Illuminated PushButton
<a href="#">KH-516L- B11-R(24)</a>	Illuminated PushButton
<a href="#">KH-516L- A11-R(24)</a>	Illuminated PushButton
<a href="#">KH-2204P-TL-G</a>	Illuminated Push Buton
<a href="#">KH-5002-1 (34X34)</a>	Signal light
<a href="#">KH-KBL30MP-L3C</a>	
<a href="#">KH-3130</a>	
<a href="#">KPL30W-L3C (24V)</a>	
<a href="#">KPB30ER (1A1B)</a>	
<a href="#">KH-2201S (2A)</a>	
<a href="#">KTM-3M-10S-A22</a>	Timing relay
<a href="#">KPB30ER-11</a>	
<a href="#">KPL30W-L3C (24V) / Red, Green, Yellow</a>	
<a href="#">KPL30W-L3C (24V) / White, Blue</a>	
<a href="#">KH-513DL DC24V / Red, Green, Yellow</a>	
<a href="#">KH-513DL DC24V / White, Blue</a>	