



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Koino

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
KBL30MP	Illuminated Push Button Switch, Protected type
KH- 503L-AC110V/RED	Pilot lamp
KH-301	Cam Switch
KH-3011	
KH-3066EB GREEN (pack 1x5 pcs)	Push button switch
KH-4022 (Dual)	Alarm buzzer
KH-403D-24	continous buzzer
KH-513DL-DC24V-Y	
KH-513L-110VAC /green	push button switch
KH-516-C00-W24	
KH-60200-4	TERMINAL BLOCK
KH-60300-3	Terminal Block
KTM-1T	Timer
KH 9016-RP	switch
KH-302R-2401 Knob Type H	Cam Switch
KH-309	(KSL25L2-11) ** SELECTOR SWITCH
KH-103-4CL-DC12V	** RELAY
KH-307	(KPB25M-11) ** PUSH BUTTON SWITCH
KH-403F-24 (pack 1x5 pcs)	Buzzer
KH-503TL	.
KH-301C-1	cam switch
KH-3065EB 30mm Emergency Green Push Button	
KH-3065EB-11-Y	PUSH BUTTON SWITCH
KH-3065EB-11-G	push button switch
KH-3065EB-11-R	Emergency Push Button Switch
KH-4065A	Signal phone
KH-5040L	
KH-60300-4	4Pole Terminal Block
KH-3030-2	2Position Key Switch
KH-3040-11	PUSH BUTTON SWITCH
KH-3040 (pack x10)	JOG BUTTON
KPB30MS-20-BK	SELECTOR SWITCH
KPB30M (Red)	Push button
KSL30K2-11	SELECTOR SWITCH
KH-5030L-DC24V-W.B Alternative	
KH-503L	

Product	Description
KH-103-H2CL (AC6/12/24/50V)	Relay
KH-6115S	Terminal Block
KH-301-3109	CAM SWITCH
KH-503L-R	PILOT LAMP
KH-2201-10BK	
KH-2201-10R	
KH-2201-10Y	
KH-2201ER-22R	
KH-2201-G, R, B	
KH-2201S-11B	
KH-2201-20Y	
KH-2202-2K 22MM	2-POS KEY SWITCH
KH-2202-2S-11	
KH-2202-3K	
KH-2204LP-2-11G	
KH-2204LP-2-11Y	
KH-5020L-24 Red.Green.Yellow	
KPB30M-G10.Y,BK,R,W	
NF30-PM-Y	
KSL30K2	KEY SELECTOR SWITCH
KSL30S3	
KPB30ER -11- X	Push Button, Turn To Reset
KH-402-2	Buzzer
KEPB16ER-R2B	Push Button Turn to Reset Switch, Red
KH-9016-PBL (pack x10)	Microswitch
KH-3011-11	Selector switch
KH-3012-20	SELECTOR SWITCH
KH-2203L-2-R	
KH-9015-HL	
KH-2202-3K-20	KEY SWITCH
KH-60300-4 300A 4P	
KH-3071EB-11-Y	
KH-516-C00-R24	
KSL30S3-20 30mm 3Position 2NO Selector Switch	Selector Switch
KH-3011-2 30mm 2Position Selector Switch	Selector Switch
KH-2202-3L-20 22mm 3Position 2NO Selector Switch	Selector Switch
KH-2201EB-11Y 22mm 1NO+1NC Yellow Mushroom Push Button	Push Button Switch
KPB30M-G11 30mm 1NO+1NC Green Push Button	Push Button Switch
KPB30 IP65/Momentary/RED/1NO+1NC	Push button switch
KH-2202-3S-20 22mm 3Position 2NO Selector Switch	Selector Switch
KH-2204L-TL-R	
KH-2204L-TL-Y	
KH-2201-11-BK	Push Button Switch
KH-2204L-TL-G	

Product	Description
KH-2201-11-G	
KH-2201-11-W	
KPB30EM-11G	
KH-5040L RED	SQ LIGHT=HEAT TRACING
KH-5040L YELLOW	
KH-5040L GREEN	
KH-5040L WHITE	
KH-5040L BLUE	
YS24VR (RED COLOUR)	
YS24VG (GREEN)	
YS24VY (YELLOW)	
YS 24V White	
YS24VB (BLUE)	
KPB30M-11R	
KPB30M-11-G	
KH-103-4CL (AC110/220V)	
KH-103-4CL (DC 12/24V)	RELAY
KH-103-4CL (AC6/12/24/50/230/240V)	RELAY
KH-103-4CL(DC6/48/110V)	RELAY
KH-4025-2	BUZZER
KCB-303D	CONTROL BOX
KH-2201ER-01R (1 box=10 pcs)	
KLJN-A2	
KH-2203-TL-24	
KH-9016-RP	
KSL25L2-11	manual selector switch 25mm
KCB-252D	ELECTRICAL BOX
KH-103-4CL DC24V (pack x10)	
KH-103-H2CL 220VAC	relay
KH-3040-11-G	SWITCH
KH-8115	FOOT SWITCH
KH-2204LP-TL-G	PUSH BUTTON LAMP
THE BUTTON ONLY FOR KH-3065EB	
KH-9012-5HRL-C	Micro Switch
KPB30M-11	
KTM-3M-30S-D2	
KH-102-3C DC24V	
KH-3065EB-11-G:10,R:10	PUSH BUTTON SWITCH
KH-2201-11-Y	PUSH BUTTON SWITCH
KH-2201EB-11G	
KCR-303-3109	
KTM-AMT	
KLNJ IP67	
KLCL	
KLCA12	limit switch

Product	Description
KH-9011	
KH-503DL-DC24V-W	PILOT LAMP
KH-503DL-DC24V-G	PILOT LAMP
KH-516L-B00-DC24V-R.G.Y	PILOT LAMP
KH-2201ER-22-G	PUSH BUTTON SWITCH
KSL30K3-20	SELECTOR SWITCH
KH-5030L-DC24V-R.G.Y	SQUARE LIGHT
KBL30M-L3C-Y11	
KH-3065EB-Y11	
KPB30ER-11R	
KBL25M-L2A	
KBL30MP-LA2	
KBL30MP-L2A -11-	
KH-513TL	
KH-516L-B00-DC24V-W.B	PILOT LAMP
KH-5030L-DC24V-W.B	SQUARE LIGHT
KH-101-2A	relay
KPB25M-11BK	
KPL30-L3C (Red,Green,Yellow)	
KPL30-L3C (White,Blue)	
KLCA12-LE	
KLCA12-LD	
KPB25ER-11-Y	push button switch
KH-302KL-7*4	KEY LOCKER
KSL30L3	Selector Switch
KH-3066EB-11 (1a1b)	PUSH BUTTON SWITCH
KH-514	
KLD2	limit switch
KH-2203-TL (WHITE) PILOT LIGHT	
KH-2203-TL (GREEN) PILOT LIGHT	
KH-2204LP-TL-DC24V-Y	LED ILLUMINATED PUSH BUTTON
KPB25EM-Y11	yellow push button
KH2201EB-11BK	
KPB25EM-R11	red push button
KPB25M-11Y	PUSH BUTTON
KPB25M-11-R	PUSH BUTTON SWITCH
KPB30M-11-BK	
KTS-S25MGL (built-in resistors, cover, 50cm wire)	
KSL25K2	PB(MOMENTARY 24V DC)
KH-301-3109R	SWITCH
K57-S01	TEMPERATURE CONTROL
KH-2203-TL 24V 1W PILOT LAMP	
KH-2202-2L-11	SELECTOR SWITCH
KH-2204-2-11R	
KH-2201-10G	PUSH BUTTON

Product	Description
KH-2203L-TL-DC24V-G	LED PILOT LAMP
KH-2203L-TL-DC24V-W	LED lamp
KH-2204LP-TL-DC24V-G	LED ILLUMINATED PUSH BUTTON
KH-8010-SLTA (NO.4 CORE DIE OUT)	LIMIT SWITCH
KH-8010-SLTA	LIMIT SWITCH
KSL 2	KEY ONLY FOR SELECTOR SWITCH
KH-2202-2S 22MM	2-POS SELECTOR SWITCH
KSL30S2-10	
KH-3008-11-BK	
KH-513DL DC24V	
KPL30	PILOT LAMP
KH-3046ER same as KH-3046ER-11	EMERGENCY STOP BUTTON
KPL30-3C 24VAC/DC	
KH-2202-3AL-20	SELECTOR SWITCH
KH-2201ER-10-R Alternative	
KH-2201ER-01R	Ø22mm 1NC Contact Emergency Stop Push Button
KPB-25ER/RED/2NO+2NC	
KH-2201ER-11R	1A1B RED EMERGENCY STOP BUTTON
KPB25WM-20-B (MOQ 10 pcs)	Push button
KH-9016-HLL	LIMIT SWITCH
KH-103-4C AC110V	
KH-103-4C/DC24V	
KH-102-2C-DC125V	
KH-RS-R8	Relay Socket
KH-2202-2K-11	KEY SWITCH
KH-2201ER-11	EMERGENCY SWITCH
KH-302KL-5301	
KH-9012-HLRC	LIMIT SWITCH
KPS-P300S	
KSC-22 4202	
KH 6030-3	
KH-103-4CL/220VAC (pack 1x10)	Relay
KFS-PC8 (pack x5)	Level switch
KH-3071EB (pack x10)	Pushbutton Switch GREEN
KPB-25ER/RED/1NO+1NC (pack x20)	
KH-9015-HR-M	LIMIT SWITCH
KSL30AK2-11	switch
KH-2203L-TL (lamp cup - R)	Pilot lamp
KPB25M-BK11	PUSH BUTTON
KBL30M-L3C-Y	
KH-501-R	PILOT LAMP RED
KBL30M-L3C-R	
KH-516-C11-G24	
KH-516-C11-R24	
KH-8005-C	Limit switch

Product	Description
KH-516-C31	Ø16 PUSH BUTTON SWITCH
KH-2201-11-R	Push button
KH-4025D	
KH-9015-PBS	Micro switch
KH-RS-14N (pack x20)	MULTI TIMING RELAY
LED bulbs of KBL30M-L2A (Red,Green,Yellow)	
LED bulbs of KBL30M-L2A (White,Blue)	
KSC-22-2531	switch tranfer
KSC-22-3234	switch transfer
KH-3046ER-11-R	PUSH BUTTON SWITCH
KH-2204LP-TL-11R	Illuminated Push Button
KH-2204LP-TL-11G	Illuminated Push Button
KH-516-C00-DC24	LAMP
KH-4022 (Direct)	Alarm buzzer
KH-4022 (Flicker)	Alarm buzzer
KH-6060-3P (pack x10)	
KH-6060-4P (pack x10)	
KPB25ER-11-?	Emergency Button
Z4G1P09B	
KH-RS-14M	Relay socket
KPB25ER-11-R	Mushroom-head push button switch
KTM-3MN-1-D2	MULTI TIMING RELAY
Red button for KH-3046ER	Button
KPB 25 ER - R11 (package of 20 pcs)	Push Button
KH-3081EB-11-G	Pushbutton switch
KH-302K-2103	SWITCH
KTM-3M-60S-D2	
KH-302K-3233	
KPB-25WER-R-11 (pack x10)	ESTOP SWITCH
KPB25M-11-G	switch
KH-5040L-24 Red	
KH-5040L-24 White	
KPB30ER-11 /red	Emergency button
KH-2201-01R	
KH3065EBG	
KH-3046ER (pack x10)	Push button switch (EMERGENCY STOP)
KH-403-1	BUZZER
KH-8018	Foot Switch
KBL25M-L3C-G11	Illuminated Push Button Switch
KPB25M-B11	Push-button spring blue
KH-103-H2CL (pack x10)	
KLCA2-LD	
KPB25WM-11G	Push Button Switch
KSEP-25402	Switch
KSEP-25404	Switch

Product	Description
KSL25K3-20	Switch
KSL25AK3-20	Switch
KBL 30 WMP-L2A Red,Green,Yellow	Switch with Light
KBL 30 WMP-L2A White,Blue	switch with light
KPB25M-G11	Push Button Switch
KPL30W-L2A Red,Green,Yellow	
KPL30W-L2A White,Blue	
KSL30WL3-20	
KH-301-V33	
KPB30WER-11	
KH-5030L-24 Red,Green,Yellow	
KC-22	
KH-8005-PR	
KH-2201-BK	Push Button Switch
KH-9015-PBF	MICRO SWITCH
KBL30MP-L3C-R	Emergency button
KBL30MP-L3C-O	Illuminated Push button switch
KH-3066EB (pack x10)	
KPS-AP3000 (emitter+receiver)	
KPB25M-Y11	Push button switch
KH-513-TL-DC24V-G	
KH513TL red	
KH-513-G	
KBL30MP-3C (Red)	Illuminated Push Button
KBL30MP-3C (Green)	Illuminated Push Button
KBL30MP-L3C11 DC24 (R.G.Y)	Illuminated Push Button Switch
KH-2201-11	Button
KH-2204P-2411	22mm 1NO+1NC 24VAC/DC Illuminated Push Button
KH-2204LP-TL-11Y	Illuminated Push Button Switch
KH-302R	
KH-9015-PBL	micro switch
P/N: KH-5002-1L-R	Pilot lamp LED Red
P/N: KH-5002-1L-Y	Pilot lamp, LED Yellow
P/N: KH-5002-1L-W	Pilot lamp
P/N: KH-5002-1L-G	Pilot lamp
P/N: KH-512-L-R	Pilot lamp
P/N: KH-512-L-G	Pilot lamp
KSL-25-L-3-20	Selector
KPB-25-M-11	Push button
KH-102-3C/LED/AC220V	Electrical Switch & Accessory RELAY
KH-102-3C/no-LED/AC220V	
KH-103-4CL, 230VAC	relay
KH-9015-CRP	Micro Switch
KSEP-224-02	
KLCA2-2-LD3	limit switch

Product	Description
KH8005-R	limit switch
KBL30M-L3C-G11	
KPB30M-11-Y	
KBL30MP-L3C-Y11	
KBL30MP-L3C-R11	
KPB30M-BK11	
KSL25W-S3	
KPB25WAT-R20	SWITCH
KA-005-25	
KH-2203-2G(AC220V)	
KH-2203-2-W(AC220V)	220V WHITE PILOT LAMP
KH-2204P-TL-DC24V	PUSH BUTTON
KH-2204P-3(AC230V)	PUSH BUTTON
KH-2204ER-3(AC230V)	PUSH LOCK & TURN RESET BUTTON
NS22-S3-2A0B	Manual Switch SELECTOR
KLCA12-2LD (pack x10)	Limit Switch
KH-103-H2CL AC220V	
KH-8012	FOOT SWITCH
NF22-BM-3CG1	Illuminated push button switch green NF22 (Intrinsic)
NF22-BM-3CB1	Illuminated push button switch blue NF22 (Intrinsic)
KSD-2BC	Safety switch
KSD-2BV	Safety switch
KSC-22-6302H	SWITCH
KSC-22-3501H	SWITCH
KSC-22-3234F	SWITCH
KSC-22-5201H	SWITCH,
KSC-22-5204H	SWITCH
KSC-22-5401H	SWITCH
KPB 25 WM-11-R	Push Button Switch
KPB25WM-01-G	Push Button, Momentary
KPB25WM-11-B	Push Button, Momentary
KH-3065EB GREEN	Switch
KH-103-4CL/AC220V	RELAY
KBL30MP-L2A -11-R	
KBL30MP-L2A -11-G	
KBL30MP-L2A -11-Y	
KBL30MP-L2A -11-O	
KBL30MP-L2A -11-W	
KBL30MP-L2A -11-B	
KSL30L2-11	
KSL30AL3-20	
KH-2201	
KPB25WM-111-B	Button- blue
KH-9015-RP	Micro Switch
KH60200-3	

Product	Description
KH-2204EB-TL	
KH-8005-SR	swich
KH-60300-4P	
KBL30MP-L2A-G	Push Button
KH-3040	Push button switch
KTS-S25MG	
KTS-S25MGL (no resistors, no cover, 50 cm wire)	
KH-3046ER-11	complete switch
KH-301-3103	
button for KH-3046ER	
KH-9012-HRS-C	micro switch
KH-3008-11-Y	
KH-516-C11-DC24V-W	
KPS-M21	sensor
KPL16-L3CW	
KH-516-A31 green	push button
KH-516-A31 red	push button
KH-302K5303	CAM switch
KH-2204-TL-DC24V-11-B	ILLUMINATED PUSHBUTTON SWITCH
KH-301-3202(R)	Cam Switch
KH-2204-TL-DC24V-11-R	ILLUMINATED PUSHBUTTON SWITCH
KH-2204-TL-DC24V-11-G	ILLUMINATED PUSHBUTTON SWITCH
KH-2204-TL-DC24V-11-Y	ILLUMINATED PUSHBUTTON SWITCH
KH-2204-TL-DC24V-11-W	ILLUMINATED PUSHBUTTON SWITCH
KCB-223D	
KPL25-L2A-W11	
KPL25-L2A-G11	
Z4G1L07B	Short Hinge Roller Lever Micro Switch
KH-9015-HR-L	micro switch
KH3065EB	PUSH BUTTON SWITCH
KBL25MP-L3C-11	PUSH BUTTON
ZC4G1P05B / KH-9016-PB(L)	Micro Switch
KPL30-L3C-R	
KPL30-L3C-G	
KPL30-L3C-Y	
KPL30-L3C-W	
KPL30-L3C-B	
KH-500TL-DC24V-1-R	
KH-500TL-DC24V-1-G	
KH-500TL-DC24V-1-Y	
KH-500TL-DC24V-1-W	
KSL25K2-10	selector switch
KH-4016D (Direct)	
KH-4016F (Flicker)	
KH-4016W (Whistle)	

Product	Description
KH-302KL-4202	CAM SWITCH
KH-8005-S	limit switch
KH-103-2C	relay
KH-9010-MT	Limit switch
KH-2203L-TL-R	Pilot Lamp
KH-2203L-TL-Y	Pilot Lamp
KH-2204LP1-11-R	Illuminated Push Button
KH-516L-B11-DC24V-G	Illuminated Push Button Switch(Led)
KH-516L-B21-DC24V-R	Illuminated Push Button Switch(Led)
KH-516L-C00-DC24V-B	Pilot Lamp(Led)
KH-516L-C00-DC24V-G	Pilot Lamp(Led)
KH-516L-C00-DC24V-R	Pilot Lamp(Led)
KH-516L-C00-DC24V-W	Pilot Lamp(Led)
KH-561L-B11-G(24V)	Illuminated push button switch
KH-561L-B21-R(24V)	Illuminated push button switch
KH-561L-C00-B(24V)	Pilot lamp
KH-561L-C00-G(24V)	Pilot lamp
KH-561L-C00-R(24V)	Pilot lamp
KH-561L-C00-W(24V)	Pilot lamp
KH-302KL 5505	switch
KH-4065D	
KH-4025	Buzzer
KH-102-2C 230v	Relay
KH-5030L-24VDC Green	Panel Mounted Annunciator
KPB25M-R-11	Push button switch
KSEB-3043C13	ILLUMINATED EMERGENCY STOP PUSH BUTTON SWITCH
KH-B3	CONTACT BLOCK
KH-301-2203	
KH-301-3233	
KH-3065EB-R	EMERGENCY PUSH BUTTON SWITCH, RED
KH-301CL-1	Cam Switch
KH-9012-HRL-C	Micro switch
KPB25ER-02-R	
KH-5030L-24PCK	
KH-5001-1	
KH2203-TL 22mm (24VDC) (Orange)	Pilot Lamp
KSL16S2-1 (1a1b)	Manual Return Round Selector Switch
KSL16S2-2 (2a2b)	
KH-103-H2CL (AC110/220V)	Relay
KH-103-H2CL (DC6/48/110V)	Relay
KH-103-H2CL (DC12/24V)	Relay
KFS-ES3	Electrode holder
KH-103-4CL-AC110V	
KS2D-3BH	

Product	Description
KTM-3M10S-A2	On-Delay Time Delay Relay
KH-516L-B21-G(24)	Illuminated PushButton
KH-516L- B21-R(24)	Illuminated PushButton
KH-516L- A21-G(24)	Illuminated PushButton
KH-516L- A21-R(24)	Illuminated PushButton
KH-516L- B11-G(24)	Illuminated PushButton
KH-516L- A11-G(24)	Illuminated PushButton
KH-516L- B11-R(24)	Illuminated PushButton
KH-516L- A11-R(24)	Illuminated PushButton
KH-2204P-TL-G	Illuminated Push Buton
KH-5002-1 (34X34)	Signal light
KH-KBL30MP-L3C	
KH-3130	
KPL30W-L3C (24V)	
KPB30ER (1A1B)	
KH-2201S (2A)	
KTM-3M-10S-A22	Timing relay
KPB30ER-11	
KPL30W-L3C (24V) / Red, Green, Yellow	
KPL30W-L3C (24V) / White, Blue	
KH-513DL DC24V / Red, Green, Yellow	
KH-513DL DC24V / White, Blue	
KTM-3MN-1-A2-4P	Multi timer
KTM-3MN-7-A2-4P	Multi Timer
KBL25MP-L3C-11(White, Blue)	
KPB30WER-R11	Electric control button
square top for KH-4016D	