



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Leybold

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">230110 / COMBIVAC CM 51 - RS 232 C / 485</a>	Measuring, controlling and regulating vacuum
<a href="#">1128612</a>	rotary pump
<a href="#">11296 / TRIVAC D65B</a>	Rotary vane vacuum pump
<a href="#">12090 / IONIVAC ITR 90</a>	Combi Transmitter
<a href="#">12426</a>	Assembled cable
<a href="#">PTR 225 (15734)</a>	Elektronisches Vakuum-Druckmessgerät
<a href="#">16226</a>	Connecting cable
<a href="#">17496</a>	ball valve
<a href="#">18207</a>	Centering Ring
<a href="#">18327</a>	
<a href="#">18341</a>	Clamping ring
<a href="#">18972</a>	replacement filter element
<a href="#">230001</a>	Display One
<a href="#">230025</a>	Display
<a href="#">No:230035</a>	THERMOVAC Transmitter
<a href="#">230350V01</a>	electronic vacuum pressure gauge
<a href="#">71064763</a>	Exhaust filter element
<a href="#">71018850</a>	Oil filter Sogevac ST 200 / ST 300
<a href="#">71018858 / EK96006</a>	Oil filter
<a href="#">71076170</a>	Fan SOGEVAC SV280 / 300, PLASTIC
<a href="#">71219480</a>	oil sight glass
<a href="#">71403510</a>	
<a href="#">71403560</a>	Repair kit SOGEVAC SV 100 - BR2
<a href="#">71412010</a>	Slider, set of 3 pieces, SV300
<a href="#">71421180</a>	Filterelement
<a href="#">71436200</a>	SOGEVAC SV 300 repair kit - BR1/BR2
<a href="#">TMP 361 PN: 85670</a>	
<a href="#">86803</a>	Metal hose with flanges
<a href="#">88351</a>	
<a href="#">88352</a>	CENTERING RING
<a href="#">960305V2013</a>	
<a href="#">960305V2040</a>	Sogevac SV40 B
<a href="#">18811</a>	
<a href="#">E20010956</a>	Vacuum Generating Module
<a href="#">DIAVAC DV 1000</a>	Vacuum gauges
<a href="#">p/n: 89606, Type: DIAVAC DV 1000</a>	diaphragm vacuum gauge

Product	Description
<a href="#">E10565</a>	Seal kit for angle valve DN 250 ISO-K
<a href="#">E20010304</a>	Filter
<a href="#">E20010737</a>	Seal oil box
<a href="#">E210502</a>	
<a href="#">EK16291</a>	Replacement cathode plates
<a href="#">ES20010655</a>	Spare parts
<a href="#">P/N: L23953004, Type: 23953004</a>	Viton Shaft Seal
<a href="#">ES43171254</a>	Inlet/outlet connectors
<a href="#">FE 10 ES19081</a>	filter
<a href="#">L10020 LVO 100, 20 LITER</a>	
<a href="#">L10099</a>	Mineral Oil
<a href="#">L50005</a>	Vacuum pump oil LVO 500 (normal Diffelen) - 5L
<a href="#">L13020</a>	mineral oil
<a href="#">L21005</a>	Lubricant
<a href="#">TR 211</a>	Zubehör zu Vakuum-Druckmessgerät
<a href="#">TR211 DN16KF</a>	
<a href="#">11276</a>	
<a href="#">TRIVAC D 8 B 1-ph, 230 V, 50 Hz</a>	Vacuum pump – complete unit
<a href="#">WAU 1001</a>	Large maintenance - kit WAU 1001 Parts for vacuum pumps
<a href="#">E250, 221271/75</a>	Barrier valve vacuum pump COMPLETE WITH MOTOR
<a href="#">EK110002665 Teile für Vakuumpumpen</a>	Großes Wartungs - Kit WAU 251
<a href="#">71404982</a>	Wellendichtring 25x40x7, FPM
<a href="#">L21001</a>	ester oil for vacuum pumps
<a href="#">EK110002613 TRIVAC D40B</a>	Wartungs Kit
<a href="#">960180V2065 SOGEVAC SV16 D</a>	rotary vane vacuum pump
<a href="#">230002</a>	Electronic vacuum pressure gauge
<a href="#">12416 AF 16 - 25 DOT Auspuff-Filter Anschluss DN 25KF</a>	Apparat zur Gasfiltration (nicht für Luft)
<a href="#">20028656</a>	ERSATZTEIL FILTERELEMENT UL200
<a href="#">71234890</a>	SATZ MIT 3 SCHIEBERN
<a href="#">71118123V</a>	screw-in flange
<a href="#">71232023</a>	exhaust filter element
<a href="#">71067243</a>	Schmutzfänger
<a href="#">71237082</a>	O-Ring
<a href="#">L12005</a>	Schmieröl für Motore/Kompressoren/Turbinen
<a href="#">71237140</a>	O-RING
<a href="#">960211V2041</a>	rotary vane vacuum pump
<a href="#">20039059</a>	DICHT.SATZ F.BREMSFL
<a href="#">ES19083</a>	Replacement filter element
<a href="#">ES19080</a>	Ersatz-Filterelement FE 8
<a href="#">LEYBONOL LVO 200</a>	Schmiermittelzubereitung
<a href="#">960160 / SOGEVAC SV16 B</a>	rotary vane vacuum pump
<a href="#">11266 / TRIVAC D 16 B</a>	two stage rotary vane pump
<a href="#">11406 / TRIVAC D 16 B DOT</a>	pump
<a href="#">EK110002100</a>	major maintenance kit TRIVAC D16B DOT

Product	Description
<a href="#">TW 220/150/S</a>	DUAL INLET TW 220/150/S;Sperrgas; D-shap
<a href="#">71420400</a>	
<a href="#">971427690</a>	WARTUNGSKIT
<a href="#">71418750</a>	Satz mit 3 Schiebern
<a href="#">71420420</a>	REPARATUR SATZ
<a href="#">L20005</a>	Schmiermittelzubereitung
<a href="#">230070V02 / PENNINGVAC PTR 90 N</a>	combination transmitter
<a href="#">230350V02</a>	THERMOVAC Kombinationstransmitter
<a href="#">971464970</a>	
<a href="#">71212510</a>	Oil collection flange
<a href="#">157 34</a>	
<a href="#">15734V02</a>	PENNINGVAC Transmitter
<a href="#">230040V02</a>	THERMOVAC Transmitter
<a href="#">800160V0021N</a>	Vakuum-Turbo-Molekularpumpe
<a href="#">TTR 91N S (230040V02)</a>	
<a href="#">85675</a>	
<a href="#">LEYBONOL LVO 120 / L12001</a>	
<a href="#">ES19081 (1x5)</a>	
<a href="#">140160</a>	
<a href="#">18342</a>	Clamping ring
<a href="#">TRIVAC D 2.5 E</a>	Rotary vane vacuum pump
<a href="#">TRIVAC D 16 B.</a>	
<a href="#">D25B / EK110002101</a>	Large maintenance kit
<a href="#">960862</a>	Rotary vane vacuum pump
<a href="#">960507 SOGEVAC SV 100B</a>	Vacuum Pump
<a href="#">TTR 101N</a>	THERMOVAC Kombinationstransmitter
<a href="#">GRAPHIX TWO</a>	
<a href="#">Anschlussleitung Typ A</a>	
<a href="#">230024</a>	LEYBOLD VACUUM DISPLAY
<a href="#">SOGEVAC SV120 B</a>	Rotary vane vacuum pump
<a href="#">P/N: 971440510 SV300 B-750 B(F) ATEX 2&amp;3</a>	AUSPUFF-FILTER
<a href="#">P/N: 501592V00001000 Type: 90i.63ISO-K/DIVAC3.0/F/N</a>	Pumpsystem
<a href="#">P/N: 501592V02000000 TURBOLAB SL80H.63ISO-K/DIVAC0.8T/F/N</a>	Vakuum Pumsystem
<a href="#">P/N: 230035V02, Type: TTR 91N</a>	Electronic Vacuum Pressure Gauge
<a href="#">P/N: 15734V02 Type: PTR 225N</a>	Elektronisches Vakuum-Druckmessgerät
<a href="#">EK110002100</a>	TRIVAC D16B DOT maintenance kit
<a href="#">THERMOVAC TTR 91 N</a>	
<a href="#">Spare parts complet for SV300</a>	
<a href="#">P/N: 11406 Type: D 16 B DOT</a>	
<a href="#">SV40B 960305T</a>	VACUUM PUMP
<a href="#">971427660</a>	Kit,Maint/Service,SV40B
<a href="#">DN 250 ISO-F</a>	
<a href="#">MAG W 1600 iPL Booster; DN 250 ISO-F</a>	
<a href="#">Converter T1600-MAG + 24V DC Versorgung</a>	

Product	Description
<a href="#">71212640</a>	Rubber Mounting Feet for Sogevac Vacuum Pumps
<a href="#">71256380</a>	STOPFEN G3 / 4
<a href="#">215325</a>	
<a href="#">230354V02</a>	THERMOVAC TTR 101N, DN 16 ISO-KF
<a href="#">P/N: 88396 Type: DN 16 ISO-KF/FF/Inox</a>	
<a href="#">RUVAC WH7000 11KW</a>	Vacuum Pump
<a href="#">971452300</a>	Repair Kit
<a href="#">10101</a>	Small Compact Vacuum Pump S 1.5
<a href="#">960250 / SOGEVAC SV 25 B</a>	
<a href="#">L12001</a>	
<a href="#">19721</a>	gasket kit
<a href="#">971427640</a>	Gasket set
<a href="#">Typ 354003-YE</a>	
<a href="#">71417210</a>	FLOAT VALVE / VACUUM PUMP SAMPLER
<a href="#">230035V02 / TTR 91 N</a>	Electrical vacuum pressure gauge
<a href="#">EK96006</a>	Special oil filter for vacuum pumps
<a href="#">898698</a>	Motor
<a href="#">15812V01 / DI 200</a>	sensor
<a href="#">P/N: 230035V02, Type: THERMOVAC TTR 91 N</a>	Transmitter
<a href="#">71231643</a>	Exhaust filter rod
<a href="#">EK96005</a>	filter
<a href="#">p/n: 230302V02; Type: GERA VAC CTR 100 N</a>	Transmitter
<a href="#">P/N: 12090, Type: IONIVAC ITR 90</a>	Transmitter ITR 90
<a href="#">P/N: 16040, Type: BOURDONVAC A</a>	Rugged relative pressure vacuum gauge
<a href="#">L21020, Type: Leybonol LVO 210 (chemical)</a>	Synthetic oil (Ester oil with additives)
<a href="#">71412000</a>	Set
<a href="#">ES71213263</a>	spring/kit
<a href="#">P/N: 252003, Type: SL300</a>	Helium sniffer line with rigid sniffer tip for PHOENIX
<a href="#">971445400</a>	EXHAUST FILTER
<a href="#">11078</a>	
<a href="#">12416</a>	EXHAUST FILTER
<a href="#">18441</a>	Blank-Flange
<a href="#">88441</a>	Blank Flange
<a href="#">18326</a>	Centering Ring
<a href="#">88347</a>	ISO-KF centering ring
<a href="#">ES20010656</a>	Vane for trivac D16B
<a href="#">88346</a>	Centering Ring
<a href="#">SOGEVAC SV25 D (960215V2001)</a>	
<a href="#">800160V0009</a>	Vacuum Turbo Molecular Pump
<a href="#">89654V02</a>	
<a href="#">ES23955165</a>	o-ring
<a href="#">P/N: 11317, Type: TRIVAC D 8 B - without motor</a>	Trivac Rotary Vane Dual Stage
<a href="#">D16B-Ex (140092)</a>	Two-stage rotary vane pump
<a href="#">15813V01</a>	
<a href="#">71237023</a>	EXHAUST FLANGE GASKET

Product	Description
<a href="#">11333</a>	Two-stage rotary vane vacuum pump
<a href="#">L13005</a>	
<a href="#">71420410</a>	
<a href="#">252400V02</a>	
<a href="#">11256 / TRIVAC D 8 B</a>	TRIVAC Vacuum pump
<a href="#">960211V2051</a>	Rotary vane vacuum pump
<a href="#">960702 / SOGEVAC SV 300 B</a>	rotary vane vacuum pump
<a href="#">71403540</a>	Repair kit SOGEVAC SV 40 - BR2
<a href="#">971427650</a>	repair kit
<a href="#">17110</a>	
<a href="#">P/N: E41170206, Type: DN 25 ISO-KF</a>	Dirt trap
<a href="#">230081V01</a>	Sensor
<a href="#">230082V01</a>	
<a href="#">EK96004</a>	PUMP OIL FILTER
<a href="#">EK110002647</a>	
<a href="#">P/N: 11276, Type: D25 B</a>	Rotary Vane Pump
<a href="#">ES20010885</a>	
<a href="#">1127618</a>	
<a href="#">p/n: 230301V02; Type: CERAVAC CTR 100 N</a>	CERAVAC VACUUM GAUGE
<a href="#">18921</a>	Exhaust Filters
<a href="#">P/N: 18206, Type: ISO-KF DN 16 ISO-KF</a>	centring ring
<a href="#">P/N: R-115250V15, Type: LEYVAC LV 250</a>	Dry compacting vacuum pumps
<a href="#">p/n: L10005; Type: LEYBONOL LVO 100 (1 canister x 5 lit )</a>	Mineral oil
<a href="#">P/N: L41001, Type: LEYBONOL LVO 410</a>	Vacuum pump oil
<a href="#">960307</a>	vacuum pump
<a href="#">P/N: E32166160, Type: TRIVAC D 4 B</a>	HV-Rotor
<a href="#">71403500</a>	Gasket set
<a href="#">P/N: 140000, Type: TRIVAC D 2.5 E</a>	hydraulic pump
<a href="#">971427680</a>	Repair kit SOGEVAC SV 100 B
<a href="#">EK110002616</a>	Large Maintenance Kit
<a href="#">EK110002612</a>	Trivac D65B Large Maintenance Kit
<a href="#">SOGEVAC SV65 B (960405V1704)</a>	Rotary vane vacuum pump
<a href="#">EK110002618</a>	Major maintenance kit (excl. oil) TRIVAC D 16 B
<a href="#">971431120</a>	Exhaust filter cartridge
<a href="#">230680V01 GRAPHIX ONE</a>	control gear
<a href="#">old PN: 230045V02 THERMOVAC TTR 96 N - 2SP / new PN: 21L2211100</a>	Transmitter
<a href="#">71213293</a>	Filter cartridge
<a href="#">960703A20V3001</a>	
<a href="#">EK110002613</a>	Large Maintenance Kit
<a href="#">960557</a>	rotary vane vacuum pump
<a href="#">EK971445151</a>	
<a href="#">gasket set for 16-25 B</a>	gasket set
<a href="#">L10001</a>	LEYBONOL LVO 100, 1 Liter
<a href="#">971423440</a>	maintenance kit

Product	Description
<a href="#">AF 25 S</a>	Exhaust filters
<a href="#">E35111012 \ D 40-65 B</a>	bearing cap
<a href="#">p/n: 960305, Type: SOGEVAC SV 40 B</a>	
<a href="#">p/n: 504309V002, Type: CVS60 1XSV40B Basic</a>	Central Vacuum Supply System
<a href="#">11245</a>	two-stage rotary vane pump
<a href="#">LEYSPEC VIEW 100S (220011V01)</a>	Quadropole mass spectrometer
<a href="#">EK971473620 (SV 40/65 BR2)</a>	MAINTENANCE KIT SV 40/65 BR2
<a href="#">230682V01 \ GRAPHIX THREE</a>	
<a href="#">SV65B</a>	pump
<a href="#">21L1011100 / TTR91RN</a>	pressure sensor
<a href="#">EK110002677</a>	
<a href="#">P/N: 960875, Type: SOGEVAC SV750 B</a>	Rotary vane vacuum pump
<a href="#">P/N: 411600V0714, Type: TURBOVAC MAG W 1600 iP</a>	booster
<a href="#">TRIVAC D 25 B \ 11275</a>	
<a href="#">DI 201 \ 15814V01</a>	
<a href="#">L13020 / LEYBONOL LVO 130 20 liter</a>	mineral oil
<a href="#">800100V0003</a>	TURBO. POWER INTEGRA
<a href="#">800102V0002</a>	Power cable - EURO plug - 3 m
<a href="#">800096V0500</a>	
<a href="#">800134V0021</a>	Mounting kit TURBOVAC DN 100 CF
<a href="#">800110V0021</a>	Start-stop switch TURBOVAC i
<a href="#">800136V0005</a>	Air cooling TURBOVAC 350-450 i - radial
<a href="#">800132V0021</a>	Protective grille DN 100 CF (3.2 mm)
<a href="#">11256</a>	TRIVAC D8B
<a href="#">12092</a>	IONIVAC ITR 90
<a href="#">ES83943</a>	Copper gasket for CF flanges
<a href="#">12455</a>	Connection cable type C
<a href="#">88471</a>	
<a href="#">85414</a>	Adsorption trap DN 16 ISO-KF
<a href="#">88504</a>	reducer ISO-KF
<a href="#">83637</a>	CF crosspiece
<a href="#">ES83945</a>	Copper gasket for CF flanges
<a href="#">83615</a>	CF T-piece
<a href="#">230681V01</a>	GRAPHIX TWO
<a href="#">800100V0004</a>	
<a href="#">800110V0027</a>	24 V DC power supply TURBO.CONTROL i
<a href="#">800103V0029</a>	communication TURBOLAB - TMP, TURBOVAC i and TD 400, 5 m
<a href="#">E20005459</a>	Heating cartridge
<a href="#">E6513191</a>	Heating cartridge
<a href="#">E20006936</a>	Spare Heating Insert Dip
<a href="#">E20012572</a>	Spare heating insert
<a href="#">960322</a>	Pump
<a href="#">215313</a>	
<a href="#">21L1211100 / TTR91RNS</a>	Pirani pressure sensor



Product	Description
<a href="#">6513193</a>	
<a href="#">ES22161236</a>	compression spring
<a href="#">E40159153</a>	Vacuum pump parts
<a href="#">E20013786</a>	HOUSING
<a href="#">E20009068</a>	maintenance indicators
<a href="#">L12001 / LEYBONOL LVO 120</a>	
<a href="#">E20002958</a>	Replacement thermometer PT 100
<a href="#">E6534163</a>	floating bushing
<a href="#">L70005 / LEYBONOL LVO 700 5lt</a>	lubricant oil
<a href="#">L70001 / LEYBONOL LVO 700 1lt</a>	
<a href="#">15814V01 / DI 201</a>	Pressure sensor
<a href="#">E61400275</a>	inner ring
<a href="#">E61400682</a>	return clamping body
<a href="#">Helium leak detector PHOENIX Quadro EU version / 250000V02</a>	Helium leak detector PHOENIX Quadro EU version
<a href="#">SOGEVAC SV 300 B</a>	pump
<a href="#">960602V</a>	
<a href="#">971464960</a>	repair kit
<a href="#">86682</a>	KF flanges with pipe extension
<a href="#">EK110000793</a>	Maintenance kit 2 SCREWLINE SP 630
<a href="#">140081</a>	
<a href="#">230085V02 / PENNINGVAC PTR 90 N with Display</a>	Transmitter
<a href="#">E20010733</a>	
<a href="#">Nr. 960505V2016 Type SV100 B</a>	
<a href="#">TRIVAC D16B-Ex / 140092</a>	rotary vane pump
<a href="#">L10020 / LEYBONOL LVO 100</a>	
<a href="#">EK110002662</a>	oil seal replacement kit
<a href="#">EK110002670</a>	Great maintenance kit
<a href="#">20010656</a>	VANE 5*37.5*26MM
<a href="#">971423450</a>	Maintenance kit SOGEVAC SV 16 BI/ SV 25 B
<a href="#">71419490</a>	Seal kit SOGEVAC SV 16 BI/SV 25 B - FPM
<a href="#">SV300 B WASSER ATEX KAT.2 INT SONDER 1 GB (960702A20V3001)</a>	rotary vane vacuum pump
<a href="#">13512</a>	Pompa
<a href="#">ES83944</a>	
<a href="#">83503</a>	
<a href="#">83689</a>	
<a href="#">83687</a>	
<a href="#">800120V0013</a>	
<a href="#">83636</a>	
<a href="#">83504</a>	
<a href="#">21L1011120</a>	
<a href="#">18906</a>	
<a href="#">86801</a>	
<a href="#">800160V0020C</a>	
<a href="#">D40BCS (Part No. 113 88)</a>	two stage rotary vane pump



Product	Description
<a href="#">D65BCS (Part No. 113 98)</a>	two stage rotary vane pump
<a href="#">200 10 736</a>	GASKET 149 X 123 X 0.5
<a href="#">230680V01</a>	
<a href="#">E6529954</a>	SV300/630 B LEY exhaust filter
<a href="#">P/N: 960314, Type: SOGEVAC SV40 B</a>	rotary vane vacuum pump
<a href="#">EK9608M</a>	
<a href="#">E20010744</a>	
<a href="#">E20010741</a>	
<a href="#">EK110002624</a>	
<a href="#">Nr. 18328 Type DN 40 KF</a>	centering ring
<a href="#">TRIVAC D16B-DOT</a>	Two stage rotary vane pump
<a href="#">960702A20V3001</a>	rotary vane vacuum pump
<a href="#">960215V / SOGEVAC SV 25 D</a>	Pump
<a href="#">LEYBONOL LVO 100 (20L)</a>	
<a href="#">E6525604</a>	Replacement timing belt 50 Hz versions
<a href="#">EK110002637 / D 40 BCS - PFPE</a>	Major maintenance kit TRIVAC
<a href="#">D16B/11333 SN:210311898</a>	
<a href="#">21L2211100 / TTR96RNS</a>	pressure sensor
<a href="#">18973 / FE 40-65</a>	replacement filter element
<a href="#">15813V01 / DI 2000</a>	DI sensors
<a href="#">18346</a>	ISO-KF quick release ring
<a href="#">18343</a>	ISO-KF clamping ring
<a href="#">18348</a>	ISO-KF quick release ring
<a href="#">230301V01</a>	
<a href="#">L12005 / LEYBONOL LVO 120</a>	mineral oil with additives
<a href="#">EK96009 / SOGEVAC SV 1200</a>	Oil filter
<a href="#">TW220/150/15S</a>	double-inlet turbomolecular pump
<a href="#">140116T</a>	filter pot
<a href="#">230070 / PENNINGVAC PTR 90</a>	combination transmitter
<a href="#">19051</a>	AF 10 exhaust filter
<a href="#">MAG W 2200 iP</a>	Magnetic bearing turbomolecular pump
<a href="#">960331</a>	
<a href="#">971443160</a>	
<a href="#">971443170</a>	
<a href="#">31256TE</a>	Two stage rotary vane pump
<a href="#">18820</a>	deep freeze trap
<a href="#">L13020 / LVO 130</a>	
<a href="#">230012</a>	Type A connection cable
<a href="#">P/N: 15812V0, Type: DI200</a>	pressure transmitter
<a href="#">P/N: 18321, Type: ISO-KF DN 10 ISO-KF</a>	Centering ring
<a href="#">EK71232023</a>	maintenance kit
<a href="#">88396</a>	Centering ring with fine filter DN 16 KF VA
<a href="#">88398 / DN40 ISO-KF</a>	Fine filter on centering ring
<a href="#">230302V01</a>	Transmitter
<a href="#">230300V02</a>	Electronic vacuum pressure gauge

Product	Description
<a href="#">85541 / TMP600/ 1000</a>	AIR COOLER
<a href="#">840072V1000 / TURBOVAC 850 / DN 160 ISO-K</a>	turbomolecular vacuum pump
<a href="#">800100V0010 / TURBO.POWER 800</a>	power supply
<a href="#">411310V03</a>	power cable
<a href="#">800100V0110</a>	TP 800 bracket
<a href="#">971423100</a>	Repair set
<a href="#">SV25D 960215 V3002</a>	vacuum pump
<a href="#">P/N: 230031, Type: IONIVAC ITR 90 PB Profibus</a>	Active sensor
<a href="#">L81005 / LEYBONOL LVO 810</a>	
<a href="#">E12102</a>	
<a href="#">111100V15</a>	
<a href="#">111200v15</a>	
<a href="#">11963</a>	
<a href="#">127700V14 - RUVAC WH7000 11KW, LVO210</a>	
<a href="#">PN: 21L2211100</a>	
<a href="#">960365V3001</a>	Rotary vane vacuum pump
<a href="#">E6504160</a>	
<a href="#">Ruvac-WAU501</a>	pump
<a href="#">P/N: ES19082, Type: FE 16</a>	Replacement filter element
<a href="#">P/N: 16120 Type: BOURDONVAC C</a>	
<a href="#">P/N: 21L1011120 Type: Thermovac TTR 91 RN</a>	
<a href="#">P/N: 971464950, Type: Seal kit SOGEVAC SV 300 B - FPM</a>	Seal kit
<a href="#">EK96008</a>	
<a href="#">EK 960.08 / 714.05.310</a>	oil filter
<a href="#">TTR 911 PB</a>	TM-Transmitter
<a href="#">6518243</a>	Seal
<a href="#">L50001</a>	
<a href="#">ITR90 / 12090</a>	gauge
<a href="#">P/N: 960331, Type: SOGEVAC SV 40 BI</a>	rotary vane vacuum pump
<a href="#">71417300</a>	Exhaust filter cartridge
<a href="#">EK110002668</a>	RUVAC WAU 1001 Large Maintenance Kit
<a href="#">842110</a>	CP-MD Cold Head Cable
<a href="#">842112</a>	CP-MD Cold Head Cable
<a href="#">960867</a>	
<a href="#">230116</a>	
<a href="#">15867</a>	Immersion system
<a href="#">15088</a>	Measuring cable
<a href="#">971463030</a>	
<a href="#">960463V01</a>	
<a href="#">L13001</a>	
<a href="#">12239 S-TL6</a>	Calibrated escape
<a href="#">230031</a>	
<a href="#">960702</a>	SOGGEVAC SV300 Wide std GB
<a href="#">230071</a>	Transmitter
<a href="#">L52105</a>	Oil

Product	Description
<a href="#">21L2051100 / THERMOVAC TTR 96 RN</a>	THERMOVAC Transmitter
<a href="#">21L2251100 / THERMOVAC TTR 96 RNS</a>	THERMOVAC-Transmitter
<a href="#">71040762</a>	
<a href="#">960305</a>	VACUUM PUMP
<a href="#">L10001 LEYBONOL</a>	
<a href="#">GASKET KIT FOR S/D 16-25 B</a>	KIT
<a href="#">18256</a>	Centering Ring
<a href="#">87243</a>	Bellow
<a href="#">88397</a>	Centering ring with fine filter DN 25 KF VA
<a href="#">EK9603B001</a>	
<a href="#">960314</a>	
<a href="#">971446880</a>	Palette
<a href="#">960702FP</a>	Pump
<a href="#">CERAVAC CTR 100 / 230300V01</a>	pressure sensor
<a href="#">E6525983</a>	MOTOR STATOR