



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Robertshaw

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">5000-811</a>	Thermostat
<a href="#">365A-A2</a>	vibration switch explosion-proof
<a href="#">366-A2</a>	vibration switch
<a href="#">368-R</a>	Pneumatic Vibration Detector
<a href="#">376A-A1-CO</a>	Vibraswitch® Malfunction Detectors
<a href="#">613-NHU-TD07-B</a>	Liquid Level Detector
<a href="#">613-NLU-TD07-B</a>	Level indicator
<a href="#">913-NLU-000-T</a>	
<a href="#">913-NLU-TD10-T</a>	
<a href="#">EURO366G-D0-W2-H-FX-F</a>	VIBRASWITCH
<a href="#">PO112201</a>	Pressure piston
<a href="#">P011-2201</a>	pressure operator
<a href="#">U701ODERHC-S7C</a>	Gas Valve
<a href="#">TA-158A7585P052</a>	THERMOSTATIC ASSEMBLY FOR 4"RT-1010-A3 REGULATOR
<a href="#">EURO366G-D0-W3-H-FX-F</a>	
<a href="#">613-N??-0000-0</a>	Mini-Tek Miniature Liquid-Level Detector
<a href="#">EURO366G-D2-W2-H-FX-F</a>	VIBRASWITCH
<a href="#">EURO366G-D0-W2-H-FX-X</a>	VIBRASWITCH
<a href="#">900SA647-01</a>	SWITCH ASSEMBLY
<a href="#">904GC402-02</a>	SPACE HEATER
<a href="#">160KB044-03</a>	COIL ASSEMBLY
<a href="#">EURO366G-D2-W2-H-X-X</a>	VIBRASWITCH
<a href="#">PS2197/4</a>	SOLENOID
<a href="#">5500-208M</a>	SWITCH
<a href="#">571A-D</a>	Vibration transmitter
<a href="#">E365A-G0</a>	Vibraswitch (ATEX)
<a href="#">S291</a>	Coolant level sensor
<a href="#">613-N??-0000-B</a>	
<a href="#">613-N??-0000-C</a>	
<a href="#">613-N??-TD12-0</a>	
<a href="#">613-N??-TD12-B</a>	
<a href="#">365A-A0-E</a>	VIBRATION SWITCH,
<a href="#">UW-GE158A7585P0</a>	UPPER WORKS FOR GE158A7585P052
<a href="#">EAC-4L</a>	Thermostat
<a href="#">HAZMAT BOX</a>	SPECIAL PACKING HAZARDOUS MATERIAL
<a href="#">82179-S3</a>	Valve Repair Kit

Product	Description
<a href="#">82440-B1</a>	INDICATING LOCKOUT RELAY RED/GREEN
<a href="#">82653-B1</a>	Snap-Acting Position Indicator
<a href="#">83939-D23</a>	Aluminium High Capacity Relay
<a href="#">83939-E1</a>	Aluminium Lockout Relay
<a href="#">83939-G321</a>	KNOB-ACUTATED RELAY, ALUMINUM BODY
<a href="#">83939-H221</a>	ALUMIMUM LEVEL ACT INDICATING RELAY
<a href="#">83939-H323</a>	Lever Operated Relay
<a href="#">84370-B1</a>	PNEUM VALVE
<a href="#">84370-B2</a>	Pressure Sensor
<a href="#">83939-B21</a>	Aluminium Relay
<a href="#">81073-A1</a>	Check Valve
<a href="#">82653-B8</a>	SNAP-ACTING POSTN INDICATOR
<a href="#">82653-B3</a>	SNAP-ACTING POSITION INDICATOR
<a href="#">7000DERHC-S7C (700-059)</a>	Gas valve
<a href="#">624-NLU-TD12-B</a>	Level indicator
<a href="#">1720-801</a>	Electromagnet Replacement Kit
<a href="#">624-NLU-0000-0</a>	Oil Level Sensor
<a href="#">700-057</a>	Gas Valve
<a href="#">E365A-G2-E</a>	VIBRASWITCH
<a href="#">614-NHG-0000-C</a>	Robertshaw Mini-Tek Level Sensor
<a href="#">E365A-A-O--E</a>	
<a href="#">EURO366-A2-H2-A-FX-X</a>	VIBRATION SWITCH
<a href="#">365AD8</a>	
<a href="#">366-A0</a>	
<a href="#">EAC-4L , 203-05-SSH-450</a>	THERMOSTST
<a href="#">E87C515</a>	Thermostatic Control Valve
<a href="#">E87C514</a>	Thermostatic Control Valve
<a href="#">710-101</a>	Non Regulated LC valve 1/2" In x 1/2" Out Manual Model
<a href="#">Smart 2000</a>	Digital Programmable Thermostat
<a href="#">110-326</a>	Natural Gas Water Heater Valve Uni-Kit w/ 1-3/8"
<a href="#">631-NLU-TD07-B</a>	Mini-Tek Level Sensor
<a href="#">82665-A10</a>	
<a href="#">606-191-00400</a>	
<a href="#">606-191-00401</a>	
<a href="#">606-191-00412</a>	
<a href="#">606-191-00406</a>	
<a href="#">606-191-00407</a>	
<a href="#">606-191-00403</a>	
<a href="#">606-191-00405</a>	
<a href="#">606-191-00420</a>	
<a href="#">606-191-00421</a>	
<a href="#">606-191-00426</a>	
<a href="#">606-191-00427</a>	
<a href="#">606-191-00424</a>	
<a href="#">606-191-00425</a>	

Product	Description
<a href="#">606-191-00429</a>	
<a href="#">606-191-00404</a>	
<a href="#">571A-A</a>	STUD MOUNTED VIBRATION TRANSMITTER
<a href="#">167-A1</a>	Level Transmitter
<a href="#">366-A8</a>	VIBRATION SWITCH, SPDT, 120VAC
<a href="#">22777-C1</a>	O-ring
<a href="#">96995-A18</a>	POWER PILL
<a href="#">90-360013</a>	
<a href="#">RT-1010-A2</a>	
<a href="#">613-NLU-0000-C</a>	Sensor
<a href="#">365A-A8</a>	Vibration Switch
<a href="#">EURO366-D0-H1-H-FX-X</a>	VIBRATION SWITCH, DPDT, GOLD CONTACTS
<a href="#">CR 101-A2</a>	RATIO RELAY W/ ADJ. BIAS, 1:2 RATIO (81032-G1)
<a href="#">CR-101-A1</a>	VOLUME BOOSTER RELAY W/ ADJUSTABLE BIAS
<a href="#">EURO366-D9-H2-E-FX-M</a>	Robertshaw Vibraswitch Explosion Proof.
<a href="#">P/N: 5S4-501-889, Model: U701ODERHC-S7C</a>	Gas Valve
<a href="#">613-NLG-0000-B</a>	Mini-Tek Level Sensor
<a href="#">90-285-LSD-00</a>	Coolant Level Sensor
<a href="#">4290-006</a>	Robertshaw Commercial Gas Fryer Oven Thermostat
<a href="#">GSF 90602300</a>	
<a href="#">EURO366-D8-H2-E-FX-X</a>	
<a href="#">S18*24*JG1/4*BHB*A0.35</a>	
<a href="#">613-NHU-0000-B</a>	Coolant Level Detector
<a href="#">624-NHU-0000-B</a>	
<a href="#">82653-B2</a>	STATUS INDICATOR RELAY(ON/OFF)
<a href="#">83939-H321</a>	DRIVE RELAY.
<a href="#">83939-F211</a>	PUSH BUTTON RELAY
<a href="#">83939-Q3</a>	ALARM RELAY
<a href="#">83939-B34</a>	3-PORT RELAY ORIFICE
<a href="#">90-285-LSD-10</a>	
<a href="#">P/N: 100-00834-38 Model: SP 845</a>	Ignition Module
<a href="#">R-1220</a>	
<a href="#">366A-A8</a>	JB PUMP VIBRATION SWITCH
<a href="#">624-NLU-0000-B</a>	Mini-Tek Level Sensor
<a href="#">82059-C1</a>	Receiver Indicator Relay
<a href="#">81073-A2</a>	Check Valve
<a href="#">360026</a>	
<a href="#">MODEL 613-NLU-TD07-B</a>	Level Sensor
<a href="#">84370-A1</a>	Pressure Sensor
<a href="#">4350-040</a>	Gas Thermostat
<a href="#">1720-004</a>	Gas Safety Valve
<a href="#">EURO366-A0-H2-A-FX-X</a>	VIBRATION SWITCH
<a href="#">V180</a>	
<a href="#">UW-GE158A7585P052</a>	
<a href="#">S1615 S6660</a>	Water Valve

Product	Description
<a href="#">5500-202</a>	
<a href="#">EURO366-A0-HorW2-A-FX-X</a>	VIBRATION DETECTOR
<a href="#">VC-210-BQR 1/2"</a>	PNEUMATIC DIAPHRAGM CONTROL VALVE
<a href="#">EURO366-A7-H2-A-FX-X</a>	vibraswitch
<a href="#">R-700-059 (U7000 DERHC)</a>	gas valve
<a href="#">365A-D0</a>	
<a href="#">9200H</a>	THERMOSTAT
<a href="#">R-5500-202</a>	
<a href="#">12601530</a>	
<a href="#">6220</a>	
<a href="#">SP715A</a>	Intermittent Pilot Ignition Control
<a href="#">NGV 10MU</a>	Termostat
<a href="#">RT1001-R5413</a>	Temperature Regulator
<a href="#">780-845</a>	thermostat
<a href="#">R-402-811-460</a>	valve
<a href="#">P/N:1262780; Type:S 19 05 V19</a>	Water Valve
<a href="#">624-NLU-0000</a>	Level Sensor
<a href="#">571A-F</a>	transmitter
<a href="#">TA-GE158A7585P0 46</a>	thermostatic assembly
<a href="#">365A-A7</a>	Malfunction Detector
<a href="#">5318B-A1-A</a>	
<a href="#">700-059</a>	valve
<a href="#">5000-202</a>	
<a href="#">570B-E</a>	SENS.VIBRA
<a href="#">GE347A5759P001</a>	5" Temperature Regulator
<a href="#">MiniTek 613-NLG-TD12-C</a>	
<a href="#">U7010DERHC</a>	
<a href="#">613-NLU-TD12-C</a>	Coolant Level Detector
<a href="#">R-5000-811</a>	
<a href="#">RT1010A1</a>	3" temperature regulator
<a href="#">365A-D2</a>	
<a href="#">SP735P (R-780-746)</a>	
<a href="#">TA-GE158A7585P0</a>	THERMOSTATIC ASSEMBLY FOR 4"RT-1010-A3 REGULATOR
<a href="#">1950-001</a>	
<a href="#">E98B553 (RT1010-A1)</a>	3" Temperature Regulator
<a href="#">RX-2-24</a>	RX ASSEMBLY
<a href="#">82158-A1</a>	SPRING ASSEMBLY
<a href="#">22777-B1</a>	
<a href="#">82159-C4</a>	
<a href="#">376A-A1-D0</a>	
<a href="#">614-NLG-0000-C</a>	Mini-Tek Level Sensor
<a href="#">1265800</a>	solenoid valve
<a href="#">816291317 \ LED145/201</a>	Digital Timer Assembly
<a href="#">086568A0016</a>	Cable
<a href="#">RSCERT ( Certificate of conformance and origin )</a>	

Product	Description
<a href="#">R-700-522</a>	Gas control Valve
<a href="#">83939-Q1</a>	Lockout Relay
<a href="#">83939-H211</a>	Relay
<a href="#">366-D8</a>	VIBRATION SWITCH
<a href="#">EUR 366-A8-H2-A-FX-X</a>	
<a href="#">365A-D0E</a>	
<a href="#">83939-G221</a>	PUSH-BUTTON-OPERATED RELAY
<a href="#">82059-C2</a>	INDICATOR RELAY
<a href="#">VC-210-BR 3/4"</a>	
<a href="#">VC-210-BR 1/2"</a>	
<a href="#">SL-705-E3-S11-B21-1</a>	
<a href="#">365A-D8-H</a>	
<a href="#">84392-B2</a>	
<a href="#">84392-A3</a>	
<a href="#">EURO366-D0-H2-H-FX-X</a>	Vibration Switch
<a href="#">EURO366-A8-H2-A- FX-X</a>	VIBRATION DETECTOR
<a href="#">compression spring for 1010A200</a>	compression spring for fitting
<a href="#">571A-E</a>	Vibration Transmitter
<a href="#">624-NHG-000-C</a>	Level Sensor
<a href="#">1491350</a>	micropump
<a href="#">85380 E0012</a>	valve
<a href="#">624-NLU-TD12-C</a>	Level indicator
<a href="#">R-5300-711</a>	
<a href="#">7000DERHC</a>	GAS valve
<a href="#">E365A-A2</a>	Vibraswitch
<a href="#">613-NLU-TD12-B</a>	Level indicator
<a href="#">5500-213M</a>	Energy regulators
<a href="#">R-402-811-460 (7000BMVR nat 4)</a>	
<a href="#">7000ERHC-120-S7C</a>	
<a href="#">1009-A1</a>	Thermostatic Valve
<a href="#">366-A7</a>	VIBRATION SWITCH
<a href="#">7000derch s7c</a>	
<a href="#">Euro366-A7-W1-A-XX-X (USA version)</a>	vibraswitch malfunction detector
<a href="#">5318B-B1-A</a>	Level Switch
<a href="#">5000-814</a>	Hot Thermostat
<a href="#">375A-A3-F4</a>	Vibraswitch
<a href="#">365A-D2-E</a>	
<a href="#">K-79392</a>	
<a href="#">7000 DERHC-S7C</a>	Gas Valve
<a href="#">EURO366G-A2-W3-A-X-X</a>	Vibration switch
<a href="#">H2170840200</a>	
<a href="#">EA5-7-60U</a>	
<a href="#">WH9</a>	
<a href="#">1285QS102</a>	Temperature Regulator
<a href="#">22700130</a>	solenoid valve

Product	Description
<a href="#">375A-A1-C0</a>	
<a href="#">Z-94406-6</a>	FJ Coil 120 volt
<a href="#">84370-A2</a>	VALVE
<a href="#">7835800</a>	micro pump
<a href="#">365A-A8-E</a>	Switch
<a href="#">K-909-42</a>	
<a href="#">12602130</a>	
<a href="#">K-65354-2</a>	valve
<a href="#">41-604</a>	Oven igniter
<a href="#">570B-F</a>	Vibration sensor
<a href="#">2560021</a>	
<a href="#">366-A8 /117V</a>	VOLTAGE RESET=117V AC=DC 0,1A SPDT 7 A 120/460 50/60HZ
<a href="#">086568A0064</a>	cable for vibration transmitter
<a href="#">6000-005 (366-A8)</a>	
<a href="#">EURO366 D9-W2-G-FL-X</a>	sensor
<a href="#">086568A0032</a>	
<a href="#">614-NLU-0000-C</a>	LIQUID LEVEL DETECTOR
<a href="#">614-NLU-0000-0</a>	LIQUID LEVEL DETECTOR
<a href="#">9200V</a>	
<a href="#">365A-A2-E</a>	Malfunction Detector
<a href="#">376A-A3-D3</a>	VIBR. SENSOR
<a href="#">6000-007</a>	Vibrasw
<a href="#">D1AG0360400 (5000-071)</a>	
<a href="#">IMV-202</a>	Water Valve
<a href="#">DOCUMENTS FOR HAZARDOUS MATERIALS</a>	
<a href="#">HAZARDOUS BOX</a>	
<a href="#">EA5-10-36U</a>	thermostats
<a href="#">040KB132-10</a>	PLASTIC COVER FOR MODEL 366/368 VIBRATION SWITCH
<a href="#">904GC402-04</a>	RESISTOR, HEATER 120V