



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA,PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Elcis

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">I/72E10-2048-5-BZ-L-CL-R</a>	Encoder
<a href="#">115-1024-10305-BZ-N-CW-R-03</a>	Encoder
<a href="#">I/115-1024-10305-BZ-Z-CL-R</a>	Encoder
<a href="#">I/115-1024-10305-BZ-N-CW-R-03</a>	(I / 115-1024-10305-BZ-N-CW-R03 Optical encoder)
<a href="#">59C15-10-1230-BZ-C-VL-R-01</a>	Incremental Encoder
<a href="#">I/90-200-1828-BZ-L-CL</a>	(Encoder Optical encoder)
<a href="#">I/AZ115R-1000-824-BZ-L-CH</a>	Incremental encoder
<a href="#">I/38C8-12-824-B-B-CV-R-01</a>	encoder
<a href="#">I/59C12-1500-824-B-B-CV-R-05</a>	RUGGED ENCODER
<a href="#">I/59C15-2500-1828-B-B-CV-R-01</a>	Incremental encoder
<a href="#">I/62CD-2500-5-BZ-N-CV-R-01</a>	PINION-ENCODER
<a href="#">I/63-5000-5-BZ-Z-CL-R</a>	Encoder
<a href="#">I/X63 100 824 BZ B CM</a>	Encoder
<a href="#">I/Z115-2000-824-B-B CM-R</a>	Incremental Encoder
<a href="#">L/XEFK601-1828-B-B-1000-1-CM-R</a>	ENCODER
<a href="#">A/XZ390A-G-3600-5-CM5-R-AR</a>	Incremental Encoder
<a href="#">EFK150-824-B-B-1000-1-CM-R</a>	Optischer Drehgeber
<a href="#">A/X365-G-360-1828-B-F-CD4-R</a>	Encoder
<a href="#">I/63-5000-5-BZ-C-CL-R</a>	Incremental Encoder
<a href="#">Mating connector VLF</a>	Mating Connector
<a href="#">Q80-500-824-BZ-CW</a>	Optical encoder
<a href="#">Q80-1-824-BZ-CW</a>	Optical encoder
<a href="#">I/40-10-1224-BZ-H-CVK-R-02</a>	Incremental Encoder
<a href="#">I/A115T-200-1030-B-Z-CL-R</a>	Encoder Complete with tacho type BRB 11/6
<a href="#">I/63-1024-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">I/115K-2000/2000-5/5-9N-N-LL</a>	Encoder
<a href="#">XV-7210-1000-1828-B-B-CD-R</a>	Incremental Encoder
<a href="#">I/ 115-600-1828-M-K-CM-R</a>	Incremental Encoder
<a href="#">I/63-5000-5-BZ-N-CL</a>	Incremental encoder
<a href="#">I/38Z8-1024-5-BZ-N-CVC-R-01</a>	Incremental Encoder
<a href="#">L/EFK300-10305-BZ-Z-100-4-CL-R</a>	Encoder
<a href="#">I/H408-1500-5-BZ-N-CVK-R-02</a>	Tightening ruler
<a href="#">I/ZV38LP-2540-5-BZ-N-CV-R-01</a>	Incremental Encoder
<a href="#">I/115T-200-1230-BZ-Z-CL-R</a>	Tacho Encoder
<a href="#">A/958HP13-12-10-B-DP-0-3PG</a>	Encoder

<b>Product</b>	<b>Description</b>
<a href="#">I/115T-2048-5-BZ-Z-CL-R</a>	Encoder
<a href="#">A/390-G-256-5-CD4-R</a>	Encoder
<a href="#">I/63-2000-18285-B-N-CM</a>	Encoder
<a href="#">I/115-1000-1030-B-L-CL-R</a>	ENCODER
<a href="#">I/115-1024-1230-BZ-Z-CW-R-02</a>	Incremental encoder
<a href="#">I/X59CM15-2000-5-BZ-N-CL-R</a>	encoder
<a href="#">I/63-50-824-BZ-B-CM-R.</a>	INCREMENTAL ENCODER
<a href="#">Connector VFM.</a>	Connector
<a href="#">I/5910-500-824-BZ-B-CV-R-01</a>	encoder
<a href="#">I/115T-360-824-BZ-B-CM-R</a>	encoder
<a href="#">I/45CC-1000-815-BZ-C-CD</a>	ENCODER
<a href="#">I/115/1024/1230/BZ/CW</a>	Incremental encoder
<a href="#">I/172CD-2500-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">7210-1250-5-BZ-Z-CL-R</a>	encoder
<a href="#">L/F3C076-N-W-CV-01</a>	Encoder
<a href="#">I/63-2500-5-BZ-N-CL-R</a>	encoder
<a href="#">I/Z59C15-1024-1230-BZ-Z-VL-R-01</a>	Incremental encoder
<a href="#">I/63S-10000-5-BZ-Z-CL-R</a>	encoder
<a href="#">I/38C6-150-824-BZ-P-CV-R-02</a>	encoder
<a href="#">I/A9-466-500-5-BZ-N-CV-R-01</a>	Encoder
<a href="#">VD4F</a>	connector
<a href="#">I/62CD-267-824-BZ-B-VM-R-01</a>	Encoder
<a href="#">I/7210-1250-5-BZ-C-GL-R</a>	Encoder
<a href="#">V4-SS-2-U-AT</a>	Encoder
<a href="#">I/90A-10000-5-BZ-N-CW-0</a>	encoder
<a href="#">I/58H-900-5-BZ-N-CV-R-01</a>	encoder
<a href="#">I/XY63-1000-824-B-CM-R</a>	encoder
<a href="#">A/MM1001-B-2048-1828-KP-L-CM6</a>	Encoder
<a href="#">F3-2500-5-BZ-N-CL-R</a>	Encoder
<a href="#">I/F3-2500-5-BZ-N-CL-R old code/ I/63-2500-5-BZ-N-CL-R new code</a>	Encoder
<a href="#">V/XMVP51-100-5-B-N-VM5-08S</a>	complete device
<a href="#">I/XA59C12-60-824-B-B-CV-</a>	Incremental encoder
<a href="#">I/59C15-10-1230-BZ-Z-VL-R-03</a>	Incremental Encoder
<a href="#">I/X7210-1000-1828-B-B-CD-R</a>	Encoder
<a href="#">I/Z115-720-824-BZ-B-CM-R</a>	Incremental encoder
<a href="#">I/Z115-2000-824/5-B-N-CM-R</a>	Incremental Encoder
<a href="#">F3-5000-5-BZ-N-CL</a>	Incremental Encoder
<a href="#">I/Z115-720-824/5-B-N-CM-R</a>	Encoder
<a href="#">I/X59CM15-1024-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/58S-2000-5-BZ-N-CL-R</a>	Encoder
<a href="#">58S</a>	Encoder
<a href="#">I/115-5-1230-BZ-Z-CL-R</a>	encoder
<a href="#">A/959CP12-12-15-DP-0-3PG</a>	Incremental Encoder
<a href="#">I/X115-500-815-BZ-Z-CM-R</a>	Encoder
<a href="#">I/X59CA14-1024-85/85-5-N-CC-R-01</a>	ENCODER

<b>Product</b>	<b>Description</b>
<a href="#">I/XYM63-500-5-BZ-C-CL-R</a>	encoder
<a href="#">I/7210-1250-5-BZ-Z-CL-R</a>	Optical rotary encoder
<a href="#">I/63S-180-1828-BZ-L-CH-R</a>	Incremental Encoder
<a href="#">I/63-1500-824-B-B-CM-R</a>	Encoder
<a href="#">I/E6-300-18728-BZ-B-CD-MG1820053</a>	Incremental Encoder
<a href="#">I/115-1024-815-B-Z-CM</a>	Encoder
<a href="#">ESG 10/10/25</a>	
<a href="#">I/79B-1-1224-B-H-CVK-02</a>	Incremental Encoder
<a href="#">I/46P8-2250-1828-BZ-B-CV-R-01</a>	encoder
<a href="#">BRB 11/6</a>	Tachymetric dynamo
<a href="#">I/H6310-1250-5-BZ-CM</a>	Incremental Encoder
<a href="#">I/115-4096-5-B-N-CM-R</a>	encoder
<a href="#">I/58H-1250-1030-BZ-L-CV-01</a>	ENCODER
<a href="#">I/58H-100-530-BZ-Z-CV-R-02</a>	Encoder
<a href="#">A/959CP12-12-15-B-DP-0-3PG</a>	encoder
<a href="#">A/H759CP16-14-15-B-DP-0-3PG</a>	Incremental Encoder
<a href="#">I/ 45CC-2000-5-BZ-N-CD</a>	Encoder
<a href="#">I/115-2048-1230-BZ-Z-CW-R-02</a>	Incremental Encoder
<a href="#">L/XWF500-5-BZ-C-100-4-CL-R</a>	Encoder
<a href="#">I/Z59C15-150-824-BZ-CV-R-03</a>	encoder
<a href="#">I/Z0B80EXS5-1024-18285-BZ-N-CV1-R-05 Z=CUSC.STAGNI</a>	EXPLOSION-RESISTANT ENCODER
<a href="#">I/64C-5000-5-BZ-N-CD-R</a>	Incremental Encoder
<a href="#">I/X68-500-5-BZ-N-CD-R</a>	Incremental Encoder
<a href="#">I/V466-2500-5-BZ-N-CV-R-01</a>	Incremental Encoder
<a href="#">I/115-1000-815 BZ-Z-CL-R</a>	Incremental encoder
<a href="#">I/A7210-5-1230-BZ-Z-CL-R</a>	Encoder
<a href="#">L/23RPC-100-05</a>	Potentiometric Linear Transducer
<a href="#">I/X46P6-125-1828-BZ-B-CV-R-07</a>	Incremental Encoder
<a href="#">I/X90A-1400-5-BZ-Z-VG-R-0.50</a>	Encoder
<a href="#">I/59C12-50-824-B-B-CV-R-05</a>	Encoder
<a href="#">I/30-100-1224-BZ-H-CVK-03</a>	Encoder
<a href="#">I/X115-1024-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/72R10-3600-5-BZ-Z-CL-R</a>	Encoder
<a href="#">I/45CC-10000-5-BZ-N-CD</a>	Encoder
<a href="#">I/59C15-10-1030-M-B-CV-R-01</a>	encoder
<a href="#">I/38-1200-5-B-N-CV-R-02</a>	Encoder
<a href="#">A/X MM58H3-G-4096-1030-S-CV-01</a>	encoder
<a href="#">I/A115T-50-1230-BZ-Z-CL-R</a>	Incremental encoder
<a href="#">115T-1000-1230-BZ-C-CL-R</a>	Incremental encoder
<a href="#">I/115T-1000-1230-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">I/7210-50-824-B-B-CM-R</a>	ENCODER
<a href="#">I/58H-6000-824/5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/115-1024-1230-BZ-Z-CL-R</a>	Incremental encoder
<a href="#">I/58S-2500-5-BZ-N-VS-01</a>	Encoder
<a href="#">I/90K-10000/10000-82/82-9Z-Z-LL-R</a>	encoder

<b>Product</b>	<b>Description</b>
<a href="#">I/X486-100-824/5-BZ-N-CV-R-02</a>	Incremental Encoder
<a href="#">9601129 1 01/15</a>	encoder
<a href="#">I/58S-900-5-BZ-N-CW-R-01</a>	Incremental Encoder
<a href="#">L/XWFK200-5-BZ-N-100-4-CL-R</a>	Encoder
<a href="#">I/X64-1500-824-BZ-U-CD</a>	encoder
<a href="#">E6-500-1030-B-B CV-01</a>	Incremental Encoder
<a href="#">I/90D-5000-1828-BZ-Z-CL</a>	Encoder
<a href="#">I/115-1250-1230-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">I/115R-360-824-BZ-B-CL-R</a>	Encoder
<a href="#">I/90D-5000-1828-BZ-L-CL</a>	Encoder
<a href="#">I/63-1000-824/5-B-N-CM</a>	Encoder
<a href="#">I/115-1000-1230-BZ-Z-CL-R</a>	Encoder
<a href="#">I/80-360-1030-B-B-CP-R</a>	Incremental encoder
<a href="#">I/59Z12-1000-1030-BZ-B-CV-R-01</a>	Encoder
<a href="#">ESM6-6-20</a>	Propeller joint
<a href="#">I/X46P6-140-1828-BZ-B-CV-R-07</a>	Incremental encoder
<a href="#">I/G115R-1000-815-B-Z-CL-R</a>	Encoder
<a href="#">I/115TB-1024-1230-BZ-Z-CV-R-01</a>	Encoder
<a href="#">I/115R-1000-5-B-Z-CL-R</a>	Incremental encoder
<a href="#">I/45CC-200-5-BZ-N-CD</a>	Encoder
<a href="#">I/XYM63-500-1828-BZ-B-CM</a>	Encoder
<a href="#">I/XYM63-1000-5-BZ-Z-CL-R</a>	Encoder
<a href="#">I/63S-1024-1828-BZ-L-CH-R</a>	Incremental Encoder
<a href="#">I/63S-360-1828-BZ-L-CH-R</a>	incremental encoder
<a href="#">I/A7210-10-1230-BZ-Z-CL-R</a>	encoder
<a href="#">I/Z115-720-824-B-B CW-R-01</a>	Incremental encoder
<a href="#">I/38C6-2500-5-BZ-N-CV-R-02</a>	encoder
<a href="#">I/X47RC8-500-824-M-U-CQ1-R</a>	Incremental encoder
<a href="#">I/40Z635-1000-5-BZ-N-CVK-R-02</a>	Encoder
<a href="#">L/EFK300-1030-P-6-P-P-CD</a>	Linear Potentiometric Transducer
<a href="#">VDF female flying connector</a>	Connector Accessory
<a href="#">I/XYM63-500-5-BZ-Z-CL-R</a>	incremental encoder
<a href="#">I/115-1000-1828-BZ-B-CM-R</a>	encoder
<a href="#">I/ X59ZMA15-5000-824/5-B-N-CV-R-05</a>	Incremental Encoder
<a href="#">I/Z115-2000-824-B-B CW-R-01</a>	Incremental Encoder
<a href="#">I/ 115-500-824 / 5-BZ-N-CW-R-01</a>	Incremental Encoder
<a href="#">A/XZ390-G-3600-824-B-CD4-R</a>	encoder
<a href="#">I/W59C12-2880-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">I/7210-100-5-BZ-H-CM-R</a>	Encoder
<a href="#">I/XLA90A-1024-1828/5-BZ-N-CW-R-05</a>	Incremental encoder
<a href="#">I/45CC-1000-5-BZ-N-CD</a>	Incremental encoder
<a href="#">I/E6-120-1828-BZ-B-CD</a>	Incremental Encoder
<a href="#">I/63-150-824-BZ-B-CM-R</a>	encoder
<a href="#">I/63-300-824-BZ-B-CM-R</a>	encoder
<a href="#">I/63-230-824-BZ-B-CM-R</a>	encoder

Product	Description
<a href="#">A/XMM901-G-1024-1828-KP-CV-01</a>	Encoder
<a href="#">A/390-G-4096-1828-KP-CV-01</a>	Encoder
<a href="#">I/X90A-1400-5-BZ-N-VG-R-0,50</a>	Incremental encoder
<a href="#">I/45CC-1000-5-BZ-N-VL-R-0,30</a>	incremental encoder
<a href="#">10 m long Cable</a>	wired
<a href="#">I/59C10-14400-5-BZ-N-VL-R-01</a>	Encoder
<a href="#">I/4610-360-1828-BZ-P-CV-R-07</a>	Incremental Encoder
<a href="#">I/63-1500-824-B-B-CM-R</a>	Encoder
<a href="#">I/H6310-1024-528-B-Z-CW-R-03</a>	Incremental encoder
<a href="#">I/Z115-720-824-B-B-CM-R</a>	Incremental Encoder
<a href="#">I/59C15-10-1230-BZ-Z-VL-R-01</a>	Incremental Encoder
<a href="#">I/58H-25-1030-B-B-CE-R</a>	Encoder
<a href="#">L/XF5C075-N-24-I-CV-03</a>	Linear Potentiometric Transducer
<a href="#">A/958HC12-12-10-B-C2-W-3PG</a>	CANopen absolute encoder
<a href="#">21004095 2 04/21</a>	Encoder
<a href="#">I/63S-5000-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">I/68-2500-5-BZ-N-CV-R-03</a>	Incremental encoder
<a href="#">I/115TB-2000-824/5-BZ-N-CL-R</a>	Encoder
<a href="#">A/390-D-360-1828-KP-L-CM5-R</a>	Absolute encoder
<a href="#">cable for (A/390-D-360-1828-KP-L-CM5-R)</a>	Encoder cable
<a href="#">I/Y90A-1000-1230-BZ-Z-CL-R</a>	Incremental encoder
<a href="#">I/7210-500-5-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">L/CR80-200-824-BZ-B-100-1-CV-01</a>	Linear transducer
<a href="#">115TB-1024-1230-BZ-C-CL-R old code/ I/</a>	Incremental Encoder
<a href="#">I/Z115-720-824-B-B-CW-R-09</a>	Encoder
<a href="#">I/115TB-1024-1230-BZ-Z-CL-R</a>	centrifugal relay
<a href="#">I/80-2500-5-B-N-CL-R</a>	Incremental encoder
<a href="#">59C15-150-815-B-C--CM-R</a>	encoder
<a href="#">I/59C15-150-815-B-Z-CM-R</a>	ENCODER
<a href="#">L/YEFK300-1030-BZ-L-100-4-CL-R</a>	Encoder
<a href="#">L/XWF500-5-BZ-Z-100-4-CL-R</a>	Linear Potentiometric Transducer
<a href="#">I/X59ZP15-25-1828-B-B-VL-R-01</a>	Incremental Encoder
<a href="#">I/63S-10000-815-BZ-Z-CL-R</a>	Incremental encoder
<a href="#">I/115T-500-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/Y90A-1024-1230-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">I/115TB-1024-10305-BZ-Z-CV-R-02</a>	Incremental Encoder
<a href="#">1/115-1024-10305-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">I/80EXS5-500-5-BZ-N-CV1-R-01</a>	Explosion-Proof Incremental Encoder
<a href="#">L/XWFK200-5-BZ-N-100-4-CL</a>	Linear Potentiometric Transducer
<a href="#">I/W59C12-2400-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/58S-360-5-BZ-N-CW-R-01</a>	Incremental Encoder
<a href="#">I W90-3000-1828-b-I-cl-r</a>	Incremental encoder
<a href="#">I/ZM115-1024-1030-B-L-CM-R</a>	Incremental Encoder
<a href="#">I/38C6-2500-5-BZ-N-CV-R-01</a>	Incremental Encoder
<a href="#">I/QZD63-8192-5-BZ-N-SL-R</a>	Encoder

Product	Description
<a href="#">I/X63S-256-824-MZ-B-CV-R-01</a>	INCREMENTAL ENCODER
<a href="#">L/XEF500—P-W-P-P-CV4-R-0,75 X=9405018</a>	INCREMENTAL/ANALOG WIRE ENCODER
<a href="#">VEF</a>	Female steering wheel connector
<a href="#">S.A.C. 1420</a>	Signal converter
<a href="#">58796</a>	Cavo
<a href="#">I/63-5000-5-M-N-CL-R</a>	Incremental Encoder
<a href="#">1/115-1000-1030-B-L-CL-R</a>	ENCODER
<a href="#">I/115-1024-824-BZ-B-CM-R</a>	ENCODER
<a href="#">I/63-50-824-B-CM</a>	Incremental encoder
<a href="#">I/M50S-600-530-BZ-R-CV-02</a>	Incremental Encoder
<a href="#">I/M50-600-1224-BZ-R-CVK-02</a>	Incremental Encoder
<a href="#">I/XZH638-1000-824-BZ-B-VJ-2,50</a>	Incremental encoder
<a href="#">I/XLA59ZMA15-1024-824-BZ-L-CV</a>	ENCODER
<a href="#">I/XLA59ZMA15-1024-824-BZ-L-CV-R-01</a>	Incremental encoder
<a href="#">I/63S-10000-18285-B-N-CM-R</a>	Incremental encoder
<a href="#">A/368-G-1024-824-KP-CM5-R</a>	Absolute encoder
<a href="#">1/115-1024-1230-BZ-Z-CL-R</a>	Incremental encoder
<a href="#">I/56QE-1000-1828-B-B-CE-R</a>	Incremental encoder
<a href="#">I/K90CBB20-1024-1030-BZ-Z-CH6-R</a>	Incremental encoder
<a href="#">I/115T-2048-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">A7210-1024-1230-BZ-C-CL-R old code/ I/A7210-1024-1230-BZ-Z-CL-R new code</a>	Incremental encoder
<a href="#">I/A7210-1024-1230-BZ-Z-CL-R</a>	Incremental encoder
<a href="#">I/58H-1024-1828-BZ-B-CM-R</a>	Incremental encoder
<a href="#">I/X46P6-140-1828-BZ-B-CV-R-07 X = 9509149</a>	Incremental encoder
<a href="#">I/64C-2000-824-BZ-P-CD</a>	Incremental encoder
<a href="#">I/115-1024-18305-BZ-C-CL-R</a>	Encoder incrementale
<a href="#">I/Z59C15-1024-18285-BZ-N-CW-R03</a>	encoder
<a href="#">I/X115T-1024-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">I/115TB-1024-10305-BZ-N-CV-R-03</a>	Increment Encoder
<a href="#">I/Z 59C15-100-1230-BZ-Z-VL-R</a>	Incremental encoder
<a href="#">I/115T-1024-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">Dynamo BRB11/6</a>	Tachymeter Dynamo
<a href="#">I/X59C15-500-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/Z115-200-824/5 B-N-CM-R</a>	Incremental Encoder
<a href="#">I/63-300-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">1/X 46P6 140-1828-BZ-B-CV-R-07</a>	Incremental encoder
<a href="#">I/115-1024-1030-BZ-L-CW-R-02</a>	Incremental Encoder
<a href="#">I/115-720-824-BZ-B-CM-R</a>	Incremental Encoder
<a href="#">I/635005BZNCLR</a>	Incremental encoder
<a href="#">I/115T-600-824-B-B-CM-R</a>	Incremental encoder
<a href="#">I/X59ZP15-25-1828-B-B-VL-R-02</a>	Incremental Encoder
<a href="#">I/115T-3600-1828-B-B-B-CV-R</a>	ENCODER
<a href="#">I/LM159A-5000-824/5-BZ-N-CV-B-02</a>	Encoder
<a href="#">I/115-1024-1230-B-Z-CM-R</a>	Incremental Encoder

Product	Description
<a href="#">I/E6-320-1828-BZ-B-CD</a>	Incremental Encoder
<a href="#">I/E6-120-1828-M-B-CD</a>	Incremental Encoder
<a href="#">mod. I/E6-120-1828-M-B-CD</a>	Incremental Encoder
<a href="#">I/115-1000-815-bz-c-cl-r</a>	Incremental Encoder
<a href="#">I/X63S-5000-815-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">I/115R-1000-815-BZ-Z-CL-R</a>	Incremental Encoder
<a href="#">I/58S-256-5-BZ-N-SL-R</a>	Incremental Encoder
<a href="#">MS3108A18-1S</a>	Circular MIL Spec Connector
<a href="#">I/W59C12-2400-5-BZ-N-CL</a>	Incremental Encoder
<a href="#">I/30 -100 -1224 -BZ - H -CVK-03</a>	Incremental Encoder
<a href="#">I/X115-1000-815-BZ-C-CM-R-X</a>	Encoder
<a href="#">I/X115-1000-815-BZ-C-CL-R X</a>	Encoder
<a href="#">L/F5C100-N-24-6-CV-03</a>	Wire encoder
<a href="#">L/EF500-1830-P-6-P-P-CW-R-01</a>	Wire encoder
<a href="#">I/Y115-1000-1828-BZ-B-CM-R</a>	Incremental Encoder
<a href="#">I/115K-1024/1024-45/45-9C-C-LL-R</a>	Incremental encoder
<a href="#">I/59Z12-600-1030-BZ-B-CV-R-03</a>	PULSE ENCODER
<a href="#">I/63SC-1024-18285- BZ-N-CL</a>	Incremental Encoder
<a href="#">A/X363-G-360-1828-KP-CM5</a>	Absolute encoder
<a href="#">I/115-1024-10305-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/59ZP15-500-1828-BZ-B-CV-R-01</a>	encoder
<a href="#">I/63-1000-824/5-B-N-CM-R</a>	Incremental Encoder
<a href="#">I/7210-600-5-BZ-C-CL-R</a>	Incremental Encoder
<a href="#">I/7210-1000-824-BZ-B-CM-R</a>	Encoder
<a href="#">I/115R-2000-5-BZ-C-CL-R</a>	Incremental Encoder
<a href="#">I/58S-6000-5-BZ-N-CL-R</a>	Incremental Encoder
<a href="#">I/X59CA14-1024-85/85-5N-N-CC-R-01</a>	Incremental Encoder
<a href="#">I/63-360-824-BZ-B-CM-R</a>	Encoder
<a href="#">I/XE6-500-815-BZ-C-CV-R-01</a>	Encoder
<a href="#">I/58H-5-1030-B-B-CE-R</a>	Encoder
<a href="#">I/100D-18000-5-BZ-N-CV-R</a>	Incremental Encoder
<a href="#">I/63S-1000-1828-BZ-L-CH-R</a>	Incremental encoder
<a href="#">I/X63-3000-824-BZ-Z-CL-R</a>	Encoder
<a href="#">V/JMVP51S-100-5-B-N-V5A-08S</a>	Portable handwheel
<a href="#">I/X47RC8-500-824-B-B-CQ1-R</a>	Encoder
<a href="#">I/X115T-1000-815-BZ-C-MS-R</a>	Incremental Encoder
<a href="#">I/115-1024-10305-BZ-C-CL-R</a>	Incremental Encoder
<a href="#">I/X59ZP10-512-1828-BZ-B-CV-R-05</a>	Encoder
<a href="#">I/170C50-90000-5-BZ-N-CL-R</a>	encoder
<a href="#">I/115T-500-824-BZ-B-CM-R</a>	Incremental encoder
<a href="#">A/9115P13-12-11-B-DP-0-3PG</a>	Absolute Encoder
<a href="#">I/58H-1000-824-B-B-CM-R</a>	Encoder
<a href="#">I/XA59CA12-1024 1828-BZ-L-CV-R-10</a>	Encoder- Rotational
<a href="#">I/468-50-5-B-CV-R-01</a>	INCREMENTAL ENCODER
<a href="#">I/63SC-36000-5-BZ-N- CM-R</a>	Incremental encoder



Product	Description
<a href="#">VME</a>	Connector
<a href="#">1548</a>	Servo-mount pawl
<a href="#">I/56CJ8-500-1828-BZ-B-CV-R01</a>	Incremental encoder
<a href="#">I/40Z12 2500-1224-BZ-CVK-R02</a>	Incremental encoder
<a href="#">I/58S-2500-1828-BZ-P-CW-03</a>	Encoder
<a href="#">I/40Z12 2500-1224-BZ-H-CVK-R02</a>	Incremental encoder
<a href="#">I/S58S-2000-5-BZ-N-SL-R</a>	Encoder
<a href="#">I/63-3600-824-BZ-B-CW-01</a>	Incremental encoder
<a href="#">I/7210-1024-824-B-B-CV-R-01</a>	Incremental Encoder
<a href="#">I/XS59CA15-10000-815-BZ-Z-VL-R-0.30</a>	encoder
<a href="#">P/XPMV63X-10-24-6-CM-R</a>	Absolute encoder
<a href="#">M/M56CJ8-256-5-B-B-CV-R-01</a>	Encoder
<a href="#">I/115-1024-10305-B-Z-CM-R</a>	Incremental encoder
<a href="#">958HP12-12-10-B-DP-W-3PG</a>	Profibus absolute encoder
<a href="#">A/958HP12-12-10-B-DP-W-3PG</a>	Encoder
<a href="#">I/XYM63-1000-5-BZ-C-CL-R</a>	Encoder
<a href="#">115R-2000-5-BZ-N-CL-R</a>	ENCODER
<a href="#">L/MEFK300-1828-BZ-Q-100-1-SM-R</a>	Encoder
<a href="#">I/58-1000-824-BZ-B-CM-R</a>	Incremental Encoder
<a href="#">I/XAL59ZMA15-1024-824-BZ-L-CV-R-01</a>	ENCODER
<a href="#">I/Z59C15-100-1230-BZ-Z-VL-R-01</a>	encoder
<a href="#">I/LY90A-1024-1230-BZ-Z-CL-R</a>	encoder
<a href="#">I/W59C12-2000-5-BZ-N-CL-R</a>	Incremental encoder
<a href="#">X59ZMA15-5000-824-BZ-CV-R-05 X=MOLLA 81CM</a>	Encoder
<a href="#">90D-10000-824-BZ-B-VM-R-01</a>	Encoder
<a href="#">I/X45CC-400-1828-BZ-B-CV-08</a>	Incremental encoder
<a href="#">XF6-500-815-BZ-C-CV-R-01 / 612175 5</a>	Encoder
<a href="#">M/M56CJ8-500-1828-BZ-B-CV-R-01</a>	Encoder incrementale
<a href="#">I/X47RC8-60-824-M-CQ1-R</a>	Incremental encoder
<a href="#">I/63S-1024- 1030-BZ-Z</a>	Incremental Encoder
<a href="#">I/63/180/824/B/CM</a>	Incremental encoder
<a href="#">I/A 90A-200-18285-BN-CW-R-01</a>	Incremental encoder
<a href="#">I/59C15-1024-1230-BZ-C-VL-R-03</a>	Incremental encoder
<a href="#">I/159-500-824-B-B-CM-R</a>	Incremental encoder
<a href="#">L/F3C075-N-24-6-CV-02</a>	Wire transducer
<a href="#">I/63-720-824-BZ-B-CM-R</a>	Incremental encoder
<a href="#">I/X 64-2000-824-BZ-B-CD</a>	Incremental encoder
<a href="#">I/59C12-1500-5-B-Z-CV-R05</a>	Incremental encoder
<a href="#">1/115-1024-10305-BZ-N-CW-R-03</a>	Incremental encoder
<a href="#">I/E6-120-1828-BZ-B-CV</a>	ENCODER
<a href="#">VDF</a>	Connector
<a href="#">L/XEFK600</a>	Steel wire winder
<a href="#">I/63-10000-5-BZ-N-CL-R</a>	
<a href="#">I/59CA12-10000-5-BZ-Z-VL-R-01</a>	Absolute encoder