



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



Складова база „Онĝл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA,PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Aeco

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">MOD.15/4 M12 SL LC5 COC000026</a>	Female Connector Right
<a href="#">AOCR000017</a>	Relay
<a href="#">CRP000018</a>	Rotation controller
<a href="#">FT18SM-CR</a>	
<a href="#">SC30M-AE25 NO/NC K / CAP000023</a>	
<a href="#">CLC000002 SC-A300</a>	
<a href="#">SI 12-C2 PNP NC H</a>	PROXIMITY SWITCH
<a href="#">SI18-C5 PNP NC H</a>	
<a href="#">SI12SM-C2 PNP NO H S</a>	INDUCTIVE SENSOR
<a href="#">SI12CE4PNPNONC</a>	
<a href="#">SI12-NE4 (I12000161)</a>	
<a href="#">I18000059</a>	
<a href="#">SIA100-CE PNP NO+NC H R</a>	INDUCTIVE RING SENSOR
<a href="#">SIA12-CE PNP NO H1 R</a>	Ring Inductive Sensor
<a href="#">A0492942</a>	
<a href="#">SI12-C2 PNP NO+NC</a>	
<a href="#">SI65N1LC5</a>	
<a href="#">SC30SP-C20 PNP NO+NC H</a>	Capacitive sensor
<a href="#">CL-A</a>	Level detection probe
<a href="#">SIPC8C2PNPNO</a>	
<a href="#">SIP10-C2 PNP NO</a>	Inductive proximity switch
<a href="#">FTQSP-R-R</a>	Photoelectric Sensor
<a href="#">SC30P-RE25</a>	sensor
<a href="#">SC18SM-C5 PNP NO+NC</a>	capacitive sensor
<a href="#">S18-C1 PNP NO</a>	
<a href="#">SI18-CE8 PNP NO (I18000097)</a>	
<a href="#">A0080507 - SIA63-CE PNP NO+NC</a>	Inductive Sensor
<a href="#">I30000350</a>	Sondersensor
<a href="#">SI18-CE8 PNP NC H</a>	Inductive Sensor
<a href="#">SMC-12L NO</a>	Special sensor
<a href="#">SIP12-C2 PNP NO H1</a>	Rectangular Inductive sensor
<a href="#">SI30-C10 PNP NO K / I30000054</a>	Sensor
<a href="#">P/N: CAP000041 Model: SC30M-CE25 PNP NO+NC K</a>	capacitive sensor
<a href="#">SMP-305 NO SP-F2.8</a>	Special sensor
<a href="#">SIP40-CE20 PNP NO+NC / SIP000105</a>	limit switch
<a href="#">SI12-CE4 NPN NO</a>	Sensor

Product	Description
<a href="#">FT18SM-CP20 90</a>	Direct cell
<a href="#">SI12-CE4 PNP NO K</a>	
<a href="#">I12000004</a>	Sensor
<a href="#">P/N: I08000085 Type: SI8-DC2 PNP NO H1 S</a>	Inductive Sensors
<a href="#">SI12-DC4 PNP NO H</a>	Sensor
<a href="#">SI18-C5 PNP NO H (I18000057)</a>	inductive Proximity Sensor
<a href="#">SI12SS-DCE8 NPN NO S</a>	Sensor
<a href="#">SI12SS-DCE8 NPN NO H S (I12000715)</a>	Inductive sensor
<a href="#">SI 12-N2 / I12000154</a>	Sensor
<a href="#">I12000744 / SI12SS-DC4 PNP NO+NC H S</a>	Inductive Proximity Sensor
<a href="#">FT18SM-CP20 90 H</a>	Reflective light barriers
<a href="#">SI18-A5 NO / I18000006</a>	Inductive Sensor
<a href="#">C18000056</a>	Sensor
<a href="#">FT1000517</a>	
<a href="#">SI30-DC4 PNP NO 120 TB (I30000507)</a>	Sondersensor
<a href="#">SI12-A2 NO</a>	Sensor
<a href="#">FTQ000015</a>	
<a href="#">SI8-DC2 PNP NC</a>	
<a href="#">C30000016 , type SC30SP-C20 PNP NO+NC</a>	
<a href="#">C30000017</a>	Sensor
<a href="#">SIP000105</a>	
<a href="#">I12000719</a>	INDUCTIVE SENSOR
<a href="#">SI18SM-B5 NO/NC</a>	
<a href="#">SIP000077</a>	Inductive sensor
<a href="#">SI12SM-C2 PNP NC H S / I12000677</a>	Inductive Sensor
<a href="#">SC30SP-CE25 PNP NO+NC / C30000045</a>	Sensor
<a href="#">SMC12 NO</a>	
<a href="#">AOI08000087</a>	
<a href="#">SMC-12L NO SAL 130 LC1.1</a>	Special sensor
<a href="#">SC F800 24 VDC</a>	
<a href="#">SI12-CE4 PNP NO H</a>	Sensor
<a href="#">CRTP 24VAC/DC</a>	Sensor
<a href="#">FT1000647</a>	Special sensor
<a href="#">CLC000012</a>	AECO Capacitive Level Control
<a href="#">I08000014 , type SI8-C1 NPN NO S</a>	
<a href="#">SIA000146 , type SIA22-CE PNP NO H1</a>	
<a href="#">SI18-A5 NO (Art. Nr.I18000006)</a>	
<a href="#">SI30-AE15 NO (Art. Nr. I30000013)</a>	
<a href="#">SIP10-C2 PNP NC (Art. Nr. SIP000078)</a>	
<a href="#">SI12-CE4 PNP NO K (Art. Nr. I12000111)</a>	
<a href="#">Art.Nr. FTQ000098 Model: FT13-CF PNP NO</a>	Special sensor
<a href="#">SI12-C2 PNP NO H</a>	Inductive sensor
<a href="#">SIP10-C2 PNP NC (SIP000078)</a>	
<a href="#">FT18SM-CP20 H</a>	
<a href="#">SMC-12 NO SS LT50 SIL LC5 (SMC000313)</a>	

Product	Description
<a href="#">SI12-DC4 PNP NO LC10</a>	Sensor
<a href="#">SC30SP-C20 PNP NO+NC H (C30000017)</a>	
<a href="#">I30000507 (SI30-DC4 PNP NO 120 TB)</a>	
<a href="#">SI12-DC4 PNP NO S 120C I12000593</a>	
<a href="#">SIA000140</a>	Ring Inductive Sensor
<a href="#">SIQ80-CE50 PNP NO+NC K</a>	Inductive sensor
<a href="#">Nr. C18000090, Model: SC18SM-A5 NO/NC H</a>	capacitive sensor
<a href="#">SC-A250 24VDC</a>	Special sensor
<a href="#">SM-85 (CLM000016)</a>	
<a href="#">SC30SM-CE25 PNP NO+NC H</a>	
<a href="#">C30000045</a>	
<a href="#">SI12-N2LT55</a>	Sensor
<a href="#">FT1000648 FT08M-CBE H1 LC0.07</a>	Special sensor
<a href="#">I12000456 (SI12-C2 PNP NO S 100C)</a>	Special sensor
<a href="#">C18000098</a>	
<a href="#">S1A22-CE PNP NO H1</a>	
<a href="#">SLM/P-08 NO (SLM000001)</a>	Level sensor
<a href="#">FT1000647 (FT08M-CBR H1 LC0.07)</a>	special sensor
<a href="#">SIP000456 SIQ80-BE50 NO/NC K</a>	
<a href="#">FTQSP-CP</a>	infrared photoelectric sensor
<a href="#">SIA05-CE NPN NO+NC H R</a>	Sensor
<a href="#">RL-A 110/220Vac</a>	
<a href="#">FT18SM-CP50 H</a>	
<a href="#">SIQ80-CE50 PNP NO+NC</a>	Inductive Sensor
<a href="#">FT13-CF NPN NC</a>	Sensor
<a href="#">FT13-CF NPN NO</a>	special sensor
<a href="#">SI5-C0.8 PNP NC</a>	Sensor
<a href="#">CL1001/O 220VAC</a>	Conductivity Level Controls
<a href="#">FINDER 9020</a>	8 pole socket
<a href="#">SI8-DC2 PNP NO H1</a>	Proximity switch
<a href="#">SMC000086</a>	
<a href="#">SI18SM-B5 NO/NC H</a>	Inductive Sensor
<a href="#">SIA63-CE PNP NO+NC H R</a>	Sensor
<a href="#">SI18-C5 PNP NO K (I18000059)</a>	Inductive Sensor
<a href="#">SC-A200</a>	Special sensor
<a href="#">AOI18000065 M12 NO+NC</a>	
<a href="#">AOI18000510 M12 NO+NC</a>	
<a href="#">SMC000256</a>	Magnetic sensor
<a href="#">AOI12000054</a>	Inductive proximity switch
<a href="#">SI12-AE4 NO</a>	
<a href="#">SI12-AE4 NC</a>	
<a href="#">I12000344 , type SI12-DC4 NPN NO S 100 C</a>	Proximity Sensor
<a href="#">FTQSP-CAR H</a>	
<a href="#">SI4-C0.8 PNP NO</a>	
<a href="#">SIA000143</a>	Inductive ring sensor

Product	Description
<a href="#">FT18SM-CP20</a>	Sensor
<a href="#">I12000111 / SI12-CE4 PNP NO K</a>	
<a href="#">SMC-12L NO SP / SMC000030</a>	Special sensor
<a href="#">FT1000546 / FT18SM-CP50 H</a>	sensor
<a href="#">FT08M-CBE H1 LC0.07</a>	special sensor
<a href="#">FT08M-CBR H1 LC0.07</a>	special sensor
<a href="#">SC30P-RE25 TA10 AD3</a>	sensor
<a href="#">SIP 10 - C2 PNP NC LC.0.20 M8</a>	Special sensor
<a href="#">SC30P-AE25-NO/NC-K</a>	SENSOR
<a href="#">FT18SP-CP50</a>	SENSOR
<a href="#">SI12SS-DC4 PNP NO H S</a>	inductive sensors
<a href="#">SI18-CE8 PNP NO+NC</a>	Inductive Sensor
<a href="#">SI12-CE4 PNP NO</a>	sensor
<a href="#">SIA12-CE PNP NO+NC H R</a>	Inductive Ring Sensor
<a href="#">SI8 DC2 PNP-NO-H</a>	Inductive sensor
<a href="#">I12000399 / SI12-DC4 PNP NO H</a>	sensor
<a href="#">I12000354</a>	sensor
<a href="#">AOFTQ000023</a>	THREAD BREAKAGE SENSOR
<a href="#">FT13-CF PNP NO LC0.30+M8/4</a>	
<a href="#">CL1001/O 24Vac</a>	Sensor
<a href="#">CLL000008</a>	
<a href="#">CLL000007</a>	
<a href="#">I65000146</a>	Special sensor
<a href="#">I12000038</a>	Inductive sensor
<a href="#">I12000376</a>	special sensor
<a href="#">SI50-C20 PNP NO+NC K</a>	Special sensor
<a href="#">SMC000285</a>	Special sensor
<a href="#">SIP000069</a>	sensor
<a href="#">SIP10-C2-PNP-NC</a>	Inductive proximity switch
<a href="#">SIQ80-CE50 PNP NO+NC H</a>	
<a href="#">ALN2 110/220 Vac</a>	RELAY
<a href="#">APL000040</a>	Amplifiers for Sensors
<a href="#">SI8 DC2 NPN NO LC0.30 M8F (I08000338)</a>	sensor
<a href="#">CL1001/U 110/220Vac 10</a>	
<a href="#">CLC000004</a>	
<a href="#">SIP 00069 SIP25-C5 NPN NO + NC</a>	
<a href="#">FT18SM-CP20 90 ( 50 pcs)</a>	Direct cell
<a href="#">FT18SM-CP20 90 ( 100 pcs)</a>	Direct cell
<a href="#">FTQ000141</a>	
<a href="#">FTQ000146</a>	
<a href="#">SI12SS-DCE8 PNP NO H S</a>	
<a href="#">I12000699</a>	
<a href="#">FT1000024 FT18-AP2</a>	
<a href="#">FT1000087 FT18M-AP2</a>	
<a href="#">A0269574</a>	

Product	Description
<a href="#">I30000508 (SI30-DC4 PNP NO 120C ST TB-Pin)</a>	Special sensor
<a href="#">C18000055</a>	
<a href="#">SI12-A2 NO H</a>	
<a href="#">SI12-A2 NC H</a>	
<a href="#">SIP25-C5 NPN NO H1</a>	Rectangular Inductive Sensor
<a href="#">SIP25-C5 PNP NO H1</a>	Inductive proximity switch
<a href="#">SI30-CE15 NPN NO K</a>	Sensor
<a href="#">SI12-CE4 PNP NC H</a>	inductive Sensor
<a href="#">SI12-CE4 PNP NO+NC H</a>	inductive Sensor
<a href="#">FTQ00098</a>	
<a href="#">SC30SP-CE25 PNP NO+NC AD3 LC5</a>	
<a href="#">CLC000010</a>	Capacitive Level Controller
<a href="#">SI12SS-DC4 NPN NO S</a>	
<a href="#">SMC-06 NO</a>	
<a href="#">SC30M-A20 NO/NC K</a>	
<a href="#">CL1004/U</a>	controller
<a href="#">FT18SP-CP 20</a>	
<a href="#">SI12EL-DC4 NPN NO</a>	sensor
<a href="#">CRTP 110/220 Vac</a>	
<a href="#">A0269960</a>	Inductive proximity sensor
<a href="#">SI12-C2 PNP NC</a>	Inductive Sensor 12mm
<a href="#">SI30-C10 PNP NO H</a>	PROXIMITY SWITCH
<a href="#">FT08M-CBR LC5.5</a>	
<a href="#">FT18SM-CBR 90</a>	cell
<a href="#">SI18-DCE16 PNP NO H</a>	INDUCTIVE SENSOR
<a href="#">SI8-DCE3 PNP NO S</a>	
<a href="#">I12000741/ SI12SS-DC4 PNP NO+NC S</a>	ROTATION SENSOR
<a href="#">FT18SM-CR H</a>	
<a href="#">FT1000420</a>	
<a href="#">SI5-C0.8</a>	
<a href="#">C18000071</a>	
<a href="#">AOC18000091</a>	Capacitive Sensors
<a href="#">AOC18000080</a>	Capacitive Sensors
<a href="#">SC-A500</a>	sensor
<a href="#">FT18SP-CP20 H</a>	Photoelectric Sensor
<a href="#">C18000079</a>	Inductive sensor
<a href="#">SIP000104 / SIP40-CE20 PNP NO+NC K</a>	
<a href="#">SI30-A10 NO</a>	
<a href="#">SMC-12L NO SAL 130C</a>	
<a href="#">SIP000033</a>	SENSOR
<a href="#">SIP000034</a>	SENSOR
<a href="#">FTQ000126, FTQSP-P-R</a>	
<a href="#">SI12-NE4 AGD1</a>	
<a href="#">FTQ-P-R-30</a>	sensor
<a href="#">SI12-C2 PNP NO K</a>	Sensor

Product	Description
<a href="#">SMC000030</a>	special sensor
<a href="#">FTQ-R-R IP66</a>	
<a href="#">SI12-C2 PNP NO</a>	Inductive Proximity Sensor
<a href="#">SI18SS-DC8 NPN NC S</a>	
<a href="#">FT18SM-CAR / FT1000540</a>	Photoelectric Sensors
<a href="#">SI18-C5 PNP NO (I18000056)</a>	DETECTOR
<a href="#">SI12SM-C2 PNP NO H S / I12000669</a>	Proximity switches
<a href="#">SIP000114</a>	
<a href="#">I12000074</a>	
<a href="#">SI8-DC2 PNP NO</a>	INDUCTIVE SENSOR
<a href="#">SIP10-C2 PNP NO H1</a>	
<a href="#">p/n: SEH000012 type: SHP-6T PNP NO</a>	
<a href="#">AOC18000058/SC18SP-CE10 PNP NO+NC</a>	sensor
<a href="#">SI30SM-BE15 NO/NC</a>	
<a href="#">SI18SM-BE8 NO/NC</a>	
<a href="#">SC18SM-C5 PNP NO+NC H / C18000071</a>	
<a href="#">SC-A200 24 VDC / SC-A200 24 VDC</a>	special sensor
<a href="#">I18000067</a>	PNP Sensor
<a href="#">SI12SM - CE4 PNP NC S I12000690</a>	
<a href="#">SI12SS - DCE8 PNP NC HS I12000727</a>	
<a href="#">FT18SM-CP50</a>	
<a href="#">SI18-CE8 PNP NO H</a>	
<a href="#">SIP000076</a>	sensor
<a href="#">SIP000385</a>	special sensor
<a href="#">CL1001/O 110VAC</a>	
<a href="#">AOFT1000055</a>	photocell
<a href="#">CL1001/U R5 110/220Vac</a>	LEVEL SENSOR
<a href="#">CL1001/U 110/220Vac</a>	
<a href="#">FT18SM-CFR</a>	Sensor
<a href="#">ST18</a>	Bracket
<a href="#">FDL311</a>	Optical fiber
<a href="#">FDL120</a>	Optical fiber
<a href="#">SC30P-RE25 T1</a>	Capasitive sensor
<a href="#">SIA000148</a>	
<a href="#">SIA000149</a>	RING INDUCTIVE SENSOR
<a href="#">SIA30-CE PNP NO+NC H R / SIA000150</a>	Inductive Proximity Sensor
<a href="#">SIA000318</a>	Ring Inductive Sensor
<a href="#">SIA000320</a>	Ring Inductive Sensor
<a href="#">CL1001/U 110/220Vac 500K</a>	Conductive level control
<a href="#">C30000006 / SC30P-RE25 T10</a>	Capacitive sensor
<a href="#">RotoStar RL-A AD 1/3 24VDC</a>	ROTATIVE LEVEL CONTROL
<a href="#">YRL000006 RL-A AD 1/2 24 Vdc</a>	ROTATIVE LEVEL CONTROL
<a href="#">SI30-C10 PNP NC</a>	sensor
<a href="#">SI8-C1 NPN NO</a>	
<a href="#">SI8-DC2 NPN NO S</a>	Inductive Position Sensor



Product	Description
<a href="#">DPC M18 PNP NO+NF</a>	Capacitive proximity sensor
<a href="#">FTQ000026</a>	sensor
<a href="#">(I18000678) SI18-DC10 NPN</a>	Inductive Sensor
<a href="#">Nr. C18000087, Model SC18SM-A5 NO/NC</a>	capacitive sensor
<a href="#">(I12000030) SI12-C2 NPN NC</a>	Position sensor
<a href="#">(I30000087) SI30-CE15 PNP NO</a>	Inductive Proximity Sensor
<a href="#">SI30-CE15 PNP NO+NC K</a>	sensor
<a href="#">(FTQ000098) FT13-CF PNP NO LC0.30+M8/4</a>	fork shape photoelectric sensor
<a href="#">Nr. FTQ000025 Type FT13-CF PNP NO</a>	
<a href="#">SI18-A5 NO H   A0080365</a>	Inductive proximity sensor
<a href="#">(A0180872) CO-M12-F-D-4P/5M PUR</a>	Connector
<a href="#">SMC000006</a>	
<a href="#">SMC-18M NO   A0080550</a>	
<a href="#">FTQ000142 / FTQSP-BE-R</a>	Cell
<a href="#">FTQ000138 / FTQSP-BR-R</a>	Cell
<a href="#">A0080512</a>	Sensor
<a href="#">SIA05-CE PNP NO+NC R</a>	
<a href="#">SIP000028</a>	
<a href="#">A0080452</a>	
<a href="#">CLC000002</a>	AECO Capacitive Level Control
<a href="#">S18-DC2 PNP NC</a>	proximity sensor
<a href="#">SI12SS-DC4 NPN NO S 100C</a>	
<a href="#">SI30-DC4 PNP NO 120C ST TB</a>	
<a href="#">ARX-G</a>	
<a href="#">AR-112-A0</a>	
<a href="#">YSM000037</a>	
<a href="#">SMC000258</a>	
<a href="#">P/N: SI12SS-DC4 PNP NO+NCS</a>	
<a href="#">SMC-12 NO SS BC HF LC2 AGD2</a>	
<a href="#">SC-A300 110/220Vac</a>	Capacitive level probe
<a href="#">I08000108 SI8-NE2</a>	Sensor
<a href="#">CLC000003 / SC-A500 24Vac</a>	
<a href="#">SMC-12 NO LTF70 / SMC000186</a>	
<a href="#">CRC000005</a>	
<a href="#">CRC000006</a>	
<a href="#">SC18SM-CE10 NPN NO+NC</a>	
<a href="#">SI5-DC1.5 PNP NO</a>	
<a href="#">FTQSP-P-R-H.</a>	
<a href="#">SIA22-CE PNP NO+NC H R</a>	
<a href="#">YSM000027</a>	sensor
<a href="#">SI18-CE8 NPN NO+NC H</a>	Inductive Sensor 18mm
<a href="#">SI6.5 - DC2 PNP NO S</a>	
<a href="#">CL-A-LC5</a>	
<a href="#">Typ SMC000004</a>	magnet
<a href="#">Typ ACM000007</a>	magnet



Product	Description
<a href="#">SC30SP-CE25 PNP NO+NC H / A0080296</a>	
<a href="#">SC-A800 24Vac - Type CLC000005</a>	LEVEL MEASUREMENT SENSOR
<a href="#">SIA30-CE PNP NO+NC R</a>	
<a href="#">SMC000187</a>	
<a href="#">SC30SP-CE25 PNP NO+NC H</a>	
<a href="#">I08000086 / SI8-DC2 PNP NO K</a>	Proximity Sensor
<a href="#">I18000098</a>	Proximity Sensor,
<a href="#">ZBR000013</a>	
<a href="#">SC18SM - CE10 PNP NO + NC H</a>	
<a href="#">SI18-AE8 NO</a>	capacitive sensor
<a href="#">RL-A 24/48Vac</a>	Rotary Level Control
<a href="#">CLC000052</a>	AECO Capacitive Level Control
<a href="#">FT13-CF PNP NC</a>	Fork Sensor
<a href="#">SI5-C0.8 PNP NO</a>	Inductive Proximity Sensor
<a href="#">SC30SM-CE25 PNP NO+NC H</a>	
<a href="#">4702186</a>	
<a href="#">CL1002/U 220Vac</a>	
<a href="#">C18000053</a>	
<a href="#">SMC-12 NO SS BC HF LC10 50W</a>	
<a href="#">SI12-DC4-PNP-NO-H-S-100C</a>	sensor
<a href="#">YSM000036, type SMC-12 NO SS BC HF LC5 AGD2</a>	Sensor
<a href="#">SI18-DC8 NPN NO</a>	
<a href="#">SI8-DC2 PNP NO H1 S</a>	
<a href="#">SI8-DC2 PNP NO H1 (M8x57)</a>	
<a href="#">AOSMP000005</a>	MAGNETIC SENSOR
<a href="#">M-304 ACM000003</a>	
<a href="#">SMP-304</a>	
<a href="#">SMP000005</a>	
<a href="#">A0080546</a>	
<a href="#">SMP302</a>	
<a href="#">M-302</a>	
<a href="#">SI18-DC8 PNP NO H</a>	
<a href="#">FT1000421</a>	
<a href="#">A0492302 // SMC-12 NO SS BC HF LC2 50W</a>	
<a href="#">A0497899</a>	
<a href="#">I65000046 / SI 6.5 DC2 PNP NO H1</a>	sensor
<a href="#">SIA30-CE NPN NO+NC</a>	
<a href="#">SIA05-CE PNP NO+NC H R</a>	
<a href="#">SMC-12L NO LC025 M8M 90</a>	Magnetic Reed Sensor
<a href="#">SC-A500 24Vdc</a>	
<a href="#">SC18SP-AE10 NO+NC</a>	PROXIMITY SENSOR
<a href="#">SI4-C0.8 NPN NO</a>	Inductive Sensor
<a href="#">I08000008</a>	
<a href="#">SIPA8-C2 NPN NO</a>	Inductive Sensor
<a href="#">SIPA8-C2 NPN NO H1</a>	Inductive Sensor

Product	Description
<a href="#">SI12-DC4 NPN NO</a>	
<a href="#">A0498130</a>	
<a href="#">SI30-C10 PNP NC K</a>	Inductive Sensor
<a href="#">SI18-CE8 PNP NC</a>	
<a href="#">I18000104</a>	
<a href="#">SI30-C10 PNP NC K 100C</a>	Inductive Proximity Switch
<a href="#">SC30SM-C20PNP NO + NC</a>	
<a href="#">SMC-12S</a>	
<a href="#">SIA30-CE NPN NO+NC H R</a>	
<a href="#">CLM000053</a>	SENSOR ROTOBIN
<a href="#">SIA05-CE PNP NO H1 R</a>	
<a href="#">SMC000019</a>	SENSOR PROXIMITY MAGNETIC
<a href="#">SC18SP-CE10 PNP NO+NC</a>	
<a href="#">SI12-CE4 PNP NO+NC K</a>	Inductive Sensor
<a href="#">SIA63-CE PNP NO+NC R/SIA000155</a>	
<a href="#">SIPA8-C2 PNP NO H1</a>	
<a href="#">SIA63-CE NPN NO+NC H R</a>	
<a href="#">CRT30-R10 L</a>	
<a href="#">4702376/ CLC000002</a>	level probe
<a href="#">4702382/ CLC000006</a>	level probe
<a href="#">CRT30-R10 V</a>	
<a href="#">SI18-CE8 PNP NO</a>	Inductive Proximity Sensor
<a href="#">CLC000149</a>	
<a href="#">FT18-AP2-90-H</a>	Photoelectric Sensor
<a href="#">SI12-CE4 PNP NC AD3</a>	
<a href="#">SC30M-C20 PNP NO+NC K</a>	
<a href="#">SC18SM-CE10 PNP NO+NC</a>	Capacitive Sensor 18mm
<a href="#">SI18-CE8-PNP-NO-LC2-IP68-W2W</a>	
<a href="#">SI12-CE4 PNP NO+NC AD3</a>	
<a href="#">FT13 CF NPN NO-C0.30M8/4</a>	PHOTOELECTRIC SENSOR
<a href="#">SI12-CE4 PNP NC</a>	
<a href="#">FT18SM-CFR-H</a>	Photoelectric Sensor
<a href="#">SIM-C2 PNP NO 6 POS.LC5</a>	SENSOR
<a href="#">A0492973</a>	PNP FORK SENSOR
<a href="#">MOD.14/4 LC5</a>	cable
<a href="#">SI8-C1 PNP NO H</a>	Inductive Sensor 8mm **I08000025*
<a href="#">A0503051</a>	
<a href="#">SMC-12LM S H LTF65</a>	Magnetic Sensor