



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)





Product	Description
<a href="#">SI12-DC4 PNP NO LC10</a>	Sensor
<a href="#">SC30SP-C20 PNP NO+NC H (C30000017)</a>	
<a href="#">I30000507 (SI30-DC4 PNP NO 120 TB)</a>	
<a href="#">SI12-DC4 PNP NO S 120C I12000593</a>	
<a href="#">SIA000140</a>	Ring Inductive Sensor
<a href="#">SIQ80-CE50 PNP NO+NC K</a>	Inductive sensor
<a href="#">Nr. C18000090, Model: SC18SM-A5 NO/NC H</a>	capacitive sensor
<a href="#">SC-A250 24VDC</a>	Special sensor
<a href="#">SM-85 (CLM000016)</a>	
<a href="#">SC30SM-CE25 PNP NO+NC H</a>	
<a href="#">C30000045</a>	
<a href="#">SI12-N2LT55</a>	Sensor
<a href="#">FT1000648 FT08M-CBE H1 LC0.07</a>	Special sensor
<a href="#">I12000456 (SI12-C2 PNP NO S 100C)</a>	Special sensor
<a href="#">C18000098</a>	
<a href="#">S1A22-CE PNP NO H1</a>	
<a href="#">SLM/P-08 NO (SLM000001)</a>	Level sensor
<a href="#">FT1000647 (FT08M-CBR H1 LC0.07)</a>	special sensor
<a href="#">SIP000456 SIQ80-BE50 NO/NC K</a>	
<a href="#">FTQSP-CP</a>	infrared photoelectric sensor
<a href="#">SIA05-CE NPN NO+NC H R</a>	Sensor
<a href="#">RL-A 110/220Vac</a>	
<a href="#">FT18SM-CP50 H</a>	
<a href="#">SIQ80-CE50 PNP NO+NC</a>	Inductive Sensor
<a href="#">FT13-CF NPN NC</a>	Sensor
<a href="#">FT13-CF NPN NO</a>	special sensor
<a href="#">SI5-C0.8 PNP NC</a>	Sensor
<a href="#">CL1001/O 220VAC</a>	Conductivity Level Controls
<a href="#">FINDER 9020</a>	8 pole socket
<a href="#">SI8-DC2 PNP NO H1</a>	Proximity switch
<a href="#">SMC000086</a>	
<a href="#">SI18SM-B5 NO/NC H</a>	Inductive Sensor
<a href="#">SIA63-CE PNP NO+NC H R</a>	Sensor
<a href="#">SI18-C5 PNP NO K (I18000059)</a>	Inductive Sensor
<a href="#">SC-A200</a>	Special sensor
<a href="#">AOI18000065 M12 NO+NC</a>	
<a href="#">AOI18000510 M12 NO+NC</a>	
<a href="#">SMC000256</a>	Magnetic sensor
<a href="#">AOI12000054</a>	Inductive proximity switch
<a href="#">SI12-AE4 NO</a>	
<a href="#">SI12-AE4 NC</a>	
<a href="#">I12000344 , type SI12-DC4 NPN NO S 100 C</a>	Proximity Sensor
<a href="#">FTQSP-CAR H</a>	
<a href="#">SI4-C0.8 PNP NO</a>	
<a href="#">SIA000143</a>	Inductive ring sensor

Product	Description
<a href="#">FT18SM-CP20</a>	Sensor
<a href="#">I12000111 / SI12-CE4 PNP NO K</a>	
<a href="#">SMC-12L NO SP / SMC000030</a>	Special sensor
<a href="#">FT1000546 / FT18SM-CP50 H</a>	sensor
<a href="#">FT08M-CBE H1 LC0.07</a>	special sensor
<a href="#">FT08M-CBR H1 LC0.07</a>	special sensor
<a href="#">SC30P-RE25 TA10 AD3</a>	sensor
<a href="#">SIP 10 - C2 PNP NC LC.0.20 M8</a>	Special sensor
<a href="#">SC30P-AE25-NO/NC-K</a>	SENSOR
<a href="#">FT18SP-CP50</a>	SENSOR
<a href="#">SI12SS-DC4 PNP NO H S</a>	inductive sensors
<a href="#">SI18-CE8 PNP NO+NC</a>	Inductive Sensor
<a href="#">SI12-CE4 PNP NO</a>	sensor
<a href="#">SIA12-CE PNP NO+NC H R</a>	Inductive Ring Sensor
<a href="#">SI8 DC2 PNP-NO-H</a>	Inductive sensor
<a href="#">I12000399 / SI12-DC4 PNP NO H</a>	sensor
<a href="#">I12000354</a>	sensor
<a href="#">AOFTQ000023</a>	THREAD BREAKAGE SENSOR
<a href="#">FT13-CF PNP NO LC0.30+M8/4</a>	
<a href="#">CL1001/O 24Vac</a>	Sensor
<a href="#">CLL000008</a>	
<a href="#">CLL000007</a>	
<a href="#">I65000146</a>	Special sensor
<a href="#">I12000038</a>	Inductive sensor
<a href="#">I12000376</a>	special sensor
<a href="#">SI50-C20 PNP NO+NC K</a>	Special sensor
<a href="#">SMC000285</a>	Special sensor
<a href="#">SIP000069</a>	sensor
<a href="#">SIP10-C2-PNP-NC</a>	Inductive proximity switch
<a href="#">SIQ80-CE50 PNP NO+NC H</a>	
<a href="#">ALN2 110/220 Vac</a>	RELAY
<a href="#">APL000040</a>	Amplifiers for Sensors
<a href="#">SI8 DC2 NPN NO LC0.30 M8F (I08000338)</a>	sensor
<a href="#">CL1001/U 110/220Vac 10</a>	
<a href="#">CLC000004</a>	
<a href="#">SIP 00069 SIP25-C5 NPN NO + NC</a>	
<a href="#">FT18SM-CP20 90 ( 50 pcs)</a>	Direct cell
<a href="#">FT18SM-CP20 90 ( 100 pcs)</a>	Direct cell
<a href="#">FTQ000141</a>	
<a href="#">FTQ000146</a>	
<a href="#">SI12SS-DCE8 PNP NO H S</a>	
<a href="#">I12000699</a>	
<a href="#">FT1000024 FT18-AP2</a>	
<a href="#">FT1000087 FT18M-AP2</a>	
<a href="#">A0269574</a>	

Product	Description
<a href="#">I30000508 (SI30-DC4 PNP NO 120C ST TB-Pin)</a>	Special sensor
<a href="#">C18000055</a>	
<a href="#">SI12-A2 NO H</a>	
<a href="#">SI12-A2 NC H</a>	
<a href="#">SIP25-C5 NPN NO H1</a>	Rectangular Inductive Sensor
<a href="#">SIP25-C5 PNP NO H1</a>	Inductive proximity switch
<a href="#">SI30-CE15 NPN NO K</a>	Sensor
<a href="#">SI12-CE4 PNP NC H</a>	inductive Sensor
<a href="#">SI12-CE4 PNP NO+NC H</a>	inductive Sensor
<a href="#">FTQ00098</a>	
<a href="#">SC30SP-CE25 PNP NO+NC AD3 LC5</a>	
<a href="#">CLC000010</a>	Capacitive Level Controller
<a href="#">SI12SS-DC4 NPN NO S</a>	
<a href="#">SMC-06 NO</a>	
<a href="#">SC30M-A20 NO/NC K</a>	
<a href="#">CL1004/U</a>	controller
<a href="#">FT18SP-CP 20</a>	
<a href="#">SI12EL-DC4 NPN NO</a>	sensor
<a href="#">CRTP 110/220 Vac</a>	
<a href="#">A0269960</a>	Inductive proximity sensor
<a href="#">SI12-C2 PNP NC</a>	Inductive Sensor 12mm
<a href="#">SI30-C10 PNP NO H</a>	PROXIMITY SWITCH
<a href="#">FT08M-CBR LC5.5</a>	
<a href="#">FT18SM-CBR 90</a>	cell
<a href="#">SI18-DCE16 PNP NO H</a>	INDUCTIVE SENSOR
<a href="#">SI8-DCE3 PNP NO S</a>	
<a href="#">I12000741/ SI12SS-DC4 PNP NO+NC S</a>	ROTATION SENSOR
<a href="#">FT18SM-CR H</a>	
<a href="#">FT1000420</a>	
<a href="#">SI5-C0.8</a>	
<a href="#">C18000071</a>	
<a href="#">AOC18000091</a>	Capacitive Sensors
<a href="#">AOC18000080</a>	Capacitive Sensors
<a href="#">SC-A500</a>	sensor
<a href="#">FT18SP-CP20 H</a>	Photoelectric Sensor
<a href="#">C18000079</a>	Inductive sensor
<a href="#">SIP000104 / SIP40-CE20 PNP NO+NC K</a>	
<a href="#">SI30-A10 NO</a>	
<a href="#">SMC-12L NO SAL 130C</a>	
<a href="#">SIP000033</a>	SENSOR
<a href="#">SIP000034</a>	SENSOR
<a href="#">FTQ000126, FTQSP-P-R</a>	
<a href="#">SI12-NE4 AGD1</a>	
<a href="#">FTQ-P-R-30</a>	sensor
<a href="#">SI12-C2 PNP NO K</a>	Sensor

Product	Description
<a href="#">SMC000030</a>	special sensor
<a href="#">FTQ-R-R IP66</a>	
<a href="#">SI12-C2 PNP NO</a>	Inductive Proximity Sensor
<a href="#">SI18SS-DC8 NPN NC S</a>	
<a href="#">FT18SM-CAR / FT1000540</a>	Photoelectric Sensors
<a href="#">SI18-C5 PNP NO (I18000056)</a>	DETECTOR
<a href="#">SI12SM-C2 PNP NO H S / I12000669</a>	Proximity switches
<a href="#">SIP000114</a>	
<a href="#">I12000074</a>	
<a href="#">SI8-DC2 PNP NO</a>	INDUCTIVE SENSOR
<a href="#">SIP10-C2 PNP NO H1</a>	
<a href="#">p/n: SEH000012 type: SHP-6T PNP NO</a>	
<a href="#">AOC18000058/SC18SP-CE10 PNP NO+NC</a>	sensor
<a href="#">SI30SM-BE15 NO/NC</a>	
<a href="#">SI18SM-BE8 NO/NC</a>	
<a href="#">SC18SM-C5 PNP NO+NC H / C18000071</a>	
<a href="#">SC-A200 24 VDC / SC-A200 24 VDC</a>	special sensor
<a href="#">I18000067</a>	PNP Sensor
<a href="#">SI12SM - CE4 PNP NC S I12000690</a>	
<a href="#">SI12SS - DCE8 PNP NC HS I12000727</a>	
<a href="#">FT18SM-CP50</a>	
<a href="#">SI18-CE8 PNP NO H</a>	
<a href="#">SIP000076</a>	sensor
<a href="#">SIP000385</a>	special sensor
<a href="#">CL1001/O 110VAC</a>	
<a href="#">AOFT1000055</a>	photocell
<a href="#">CL1001/U R5 110/220Vac</a>	LEVEL SENSOR
<a href="#">CL1001/U 110/220Vac</a>	
<a href="#">FT18SM-CFR</a>	Sensor
<a href="#">ST18</a>	Bracket
<a href="#">FDL311</a>	Optical fiber
<a href="#">FDL120</a>	Optical fiber
<a href="#">SC30P-RE25 T1</a>	Capacitive sensor
<a href="#">SIA000148</a>	
<a href="#">SIA000149</a>	RING INDUCTIVE SENSOR
<a href="#">SIA30-CE PNP NO+NC H R / SIA000150</a>	Inductive Proximity Sensor
<a href="#">SIA000318</a>	Ring Inductive Sensor
<a href="#">SIA000320</a>	Ring Inductive Sensor
<a href="#">CL1001/U 110/220Vac 500K</a>	Conductive level control
<a href="#">C30000006 / SC30P-RE25 T10</a>	Capacitive sensor
<a href="#">RotoStar RL-A AD 1/3 24VDC</a>	ROTATIVE LEVEL CONTROL
<a href="#">YRL000006 RL-A AD 1/2 24 Vdc</a>	ROTATIVE LEVEL CONTROL
<a href="#">SI30-C10 PNP NC</a>	sensor
<a href="#">SI8-C1 NPN NO</a>	
<a href="#">SI8-DC2 NPN NO S</a>	Inductive Position Sensor

Product	Description
<a href="#">DPC M18 PNP NO+NF</a>	Capacitive proximity sensor
<a href="#">FTQ000026</a>	sensor
<a href="#">(I18000678) SI18-DC10 NPN</a>	Inductive Sensor
<a href="#">Nr. C18000087, Model SC18SM-A5 NO/NC</a>	capacitive sensor
<a href="#">(I12000030) SI12-C2 NPN NC</a>	Position sensor
<a href="#">(I30000087) SI30-CE15 PNP NO</a>	Inductive Proximity Sensor
<a href="#">SI30-CE15 PNP NO+NC K</a>	sensor
<a href="#">(FTQ000098) FT13-CF PNP NO LC0.30+M8/4</a>	fork shape photoelectric sensor
<a href="#">Nr. FTQ000025 Type FT13-CF PNP NO</a>	
<a href="#">SI18-A5 NO H   A0080365</a>	Inductive proximity sensor
<a href="#">(A0180872) CO-M12-F-D-4P/5M PUR</a>	Connector
<a href="#">SMC000006</a>	
<a href="#">SMC-18M NO   A0080550</a>	
<a href="#">FTQ000142 / FTQSP-BE-R</a>	Cell
<a href="#">FTQ000138 / FTQSP-BR-R</a>	Cell
<a href="#">A0080512</a>	Sensor
<a href="#">SIA05-CE PNP NO+NC R</a>	
<a href="#">SIP000028</a>	
<a href="#">A0080452</a>	
<a href="#">CLC000002</a>	AECO Capacitive Level Control
<a href="#">S18-DC2 PNP NC</a>	proximity sensor
<a href="#">SI12SS-DC4 NPN NO S 100C</a>	
<a href="#">SI30-DC4 PNP NO 120C ST TB</a>	
<a href="#">ARX-G</a>	
<a href="#">AR-112-A0</a>	
<a href="#">YSM000037</a>	
<a href="#">SMC000258</a>	
<a href="#">P/N: SI12SS-DC4 PNP NO+NCS</a>	
<a href="#">SMC-12 NO SS BC HF LC2 AGD2</a>	
<a href="#">SC-A300 110/220Vac</a>	Capacitive level probe
<a href="#">I08000108 SI8-NE2</a>	Sensor
<a href="#">CLC000003 / SC-A500 24Vac</a>	
<a href="#">SMC-12 NO LTF70 / SMC000186</a>	
<a href="#">CRC000005</a>	
<a href="#">CRC000006</a>	
<a href="#">SC18SM-CE10 NPN NO+NC</a>	
<a href="#">SI5-DC1.5 PNP NO</a>	
<a href="#">FTQSP-P-R-H.</a>	
<a href="#">SIA22-CE PNP NO+NC H R</a>	
<a href="#">YSM000027</a>	sensor
<a href="#">SI18-CE8 NPN NO+NC H</a>	Inductive Sensor 18mm
<a href="#">SI6.5 - DC2 PNP NO S</a>	
<a href="#">CL-A-LC5</a>	
<a href="#">Typ SMC000004</a>	magnet
<a href="#">Typ ACM000007</a>	magnet



Product	Description
<a href="#">SC30SP-CE25 PNP NO+NC H / A0080296</a>	
<a href="#">SC-A800 24Vac - Type CLC000005</a>	LEVEL MEASUREMENT SENSOR
<a href="#">SIA30-CE PNP NO+NC R</a>	
<a href="#">SMC000187</a>	
<a href="#">SC30SP-CE25 PNP NO+NC H</a>	
<a href="#">I08000086 / SI8-DC2 PNP NO K</a>	Proximity Sensor
<a href="#">I18000098</a>	Proximity Sensor,
<a href="#">ZBR000013</a>	
<a href="#">SC18SM - CE10 PNP NO + NC H</a>	
<a href="#">SI18-AE8 NO</a>	capacitive sensor
<a href="#">RL-A 24/48Vac</a>	Rotary Level Control
<a href="#">CLC000052</a>	AECO Capacitive Level Control
<a href="#">FT13-CF PNP NC</a>	Fork Sensor
<a href="#">SI5-C0.8 PNP NO</a>	Inductive Proximity Sensor
<a href="#">SC30SM-CE25 PNP NO+NC H</a>	
<a href="#">4702186</a>	
<a href="#">CL1002/U 220Vac</a>	
<a href="#">C18000053</a>	
<a href="#">SMC-12 NO SS BC HF LC10 50W</a>	
<a href="#">SI12-DC4-PNP-NO-H-S-100C</a>	sensor
<a href="#">YSM000036, type SMC-12 NO SS BC HF LC5 AGD2</a>	Sensor
<a href="#">SI18-DC8 NPN NO</a>	
<a href="#">SI8-DC2 PNP NO H1 S</a>	
<a href="#">SI8-DC2 PNP NO H1 (M8x57)</a>	
<a href="#">AOSMP000005</a>	MAGNETIC SENSOR
<a href="#">M-304 ACM000003</a>	
<a href="#">SMP-304</a>	
<a href="#">SMP000005</a>	
<a href="#">A0080546</a>	
<a href="#">SMP302</a>	
<a href="#">M-302</a>	
<a href="#">SI18-DC8 PNP NO H</a>	
<a href="#">FT1000421</a>	
<a href="#">A0492302 // SMC-12 NO SS BC HF LC2 50W</a>	
<a href="#">A0497899</a>	
<a href="#">I65000046 / SI 6.5 DC2 PNP NO H1</a>	sensor
<a href="#">SIA30-CE NPN NO+NC</a>	
<a href="#">SIA05-CE PNP NO+NC H R</a>	
<a href="#">SMC-12L NO LC025 M8M 90</a>	Magnetic Reed Sensor
<a href="#">SC-A500 24Vdc</a>	
<a href="#">SC18SP-AE10 NO+NC</a>	PROXIMITY SENSOR
<a href="#">SI4-C0.8 NPN NO</a>	Inductive Sensor
<a href="#">I08000008</a>	
<a href="#">SIPA8-C2 NPN NO</a>	Inductive Sensor
<a href="#">SIPA8-C2 NPN NO H1</a>	Inductive Sensor

Product	Description
<a href="#">SI12-DC4 NPN NO</a>	
<a href="#">A0498130</a>	
<a href="#">SI30-C10 PNP NC K</a>	Inductive Sensor
<a href="#">SI18-CE8 PNP NC</a>	
<a href="#">I18000104</a>	
<a href="#">SI30-C10 PNP NC K 100C</a>	Inductive Proximity Switch
<a href="#">SC30SM-C20PNP NO + NC</a>	
<a href="#">SMC-12S</a>	
<a href="#">SIA30-CE NPN NO+NC H R</a>	
<a href="#">CLM000053</a>	SENSOR ROTOBIN
<a href="#">SIA05-CE PNP NO H1 R</a>	
<a href="#">SMC000019</a>	SENSOR PROXIMITY MAGNETIC
<a href="#">SC18SP-CE10 PNP NO+NC</a>	
<a href="#">SI12-CE4 PNP NO+NC K</a>	Inductive Sensor
<a href="#">SIA63-CE PNP NO+NC R/SIA000155</a>	
<a href="#">SIPA8-C2 PNP NO H1</a>	
<a href="#">SIA63-CE NPN NO+NC H R</a>	
<a href="#">CRT30-R10 L</a>	
<a href="#">4702376/ CLC000002</a>	level probe
<a href="#">4702382/ CLC000006</a>	level probe
<a href="#">CRT30-R10 V</a>	
<a href="#">SI18-CE8 PNP NO</a>	Inductive Proximity Sensor
<a href="#">CLC000149</a>	
<a href="#">FT18-AP2-90-H</a>	Photoelectric Sensor
<a href="#">SI12-CE4 PNP NC AD3</a>	
<a href="#">SC30M-C20 PNP NO+NC K</a>	
<a href="#">SC18SM-CE10 PNP NO+NC</a>	Capacitive Sensor 18mm
<a href="#">SI18-CE8-PNP-NO-LC2-IP68-W2W</a>	
<a href="#">SI12-CE4 PNP NO+NC AD3</a>	
<a href="#">FT13 CF NPN NO-C0.30M8/4</a>	PHOTOELECTRIC SENSOR
<a href="#">SI12-CE4 PNP NC</a>	
<a href="#">FT18SM-CFR-H</a>	Photoelectric Sensor
<a href="#">MOD.14/4 LC5</a>	cable